







93 S Railroad Avenue Unit C Bergenfield NJ 07621 USA www.enapart.com sales@enapart.com



Via del Canneto 35. Borgosatollo, Brescia - Italia www.enapart.it vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Ağaoğlu My Newwork No:3/15 Ataşehir / İstanbul www.enapart.net satis@enapart.net



PRIVADA 10 B SUR #3908 COL. ANZUREZ, C.P. 72530, PUEBLA, PUE www.enapart.com.mx sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325 Frankfurt am Main, Germany www.enapart.de anfrage@enapart.de



4 boulevard Carnot, 95400 villiers-le-bel, Paris, France www.enapart.fr sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА ФРАНКА, БУДИНОК 55, ПОВЕРХ 3 www.enapart.com.ua sales@enapart.com.ua



MUNICIPIUL BUCUREŞTI, SECTOR 3, B-DUL BASARABIA, NR.250, CORP P+5 Hempstead, HP1 3AF , United Kingdom www.enapart.ro sales@enapart.ro



〒584-0023 大阪府富田林市若松町 東2丁目2番16号 www.enapart.co.jp sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS NIEVES 12 ,LOCAL ,50012,ZARAGOZA www.enapart.es ventas@enapart.es



Складова база "Онгъл", Склад А2, п.к. 4006, гр. Пловдив, България www.enapart.bg sales@enapart.bg



3 Austin Mews, High Street, Hemel www.enapart.co.uk sales@enapart.co.uk





Hirose Valve

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
<u>GNT-03</u>	Needle Valve Screwed
<u>HF-4211-10-23</u>	Directional Control Valve
<u>HG-4211-32-23</u>	2 STOP VALVE
<u>HG-4211-50-23</u>	
HIC-FJ-25-A04-12	Hirose brand Inline Check Valve
Q-B15B16010 (HK-4251-32-S STOP VALVE CARTRIDGE FOR	Stop valve cartridge for hydraulics
<u>HYDRAULICS)</u>	
<u>HRV-M01-W-25-21</u>	Relief Valve
<u>HSO-G02-A10C-LZ</u>	HIROSE VALVE
HSO-M03-W-D02C	valve
<u>HT-0210-10</u>	
<u>HT-720-01-S</u>	Grease valve QB14XEI010
<u>HT-728N-04</u>	valve
<u>HG-4211-10-23</u>	Stop Valve
<u>HG-6211-20-50-25</u>	Hirose valve
<u>HG-4211-D-10-23</u>	Hirose valve
<u>HF-4211-50H-23</u>	2" MK stop valve
<u>QR/P1-16S-C(51)</u>	Connector
<u>QR/P1-16P-C(51)</u>	Connector
<u>HF-6211-20-25</u>	CHECK STOP VALVE
<u>HF-6211-32-25</u>	CHECK STOP VALVE
<u>HF-6211-40-25</u>	CHECK STOP VALVE
<u>HF-4211-20-23</u>	STOP VALVE
<u>HF-4211-25-23</u>	STOP VALVE
<u>BV-T03-21</u>	VALVE BALL
<u>HF-8210-15-24-166</u>	Stop Valve
<u>HF-1280-32-11 OEM</u>	
<u>FDC-T08-70-61</u>	Flow Divider/combiner valves
<u>HSO-M03-W-D02C-21</u>	SOLENOIDE VALVE
<u>HR10-7P-6P</u>	socket
<u>HF-4211-50-23</u>	Stop Valve
<u>HG-4211-20-23</u>	Stop valve
HRV-M01-A-25-21	
<u>HFZ-4211-80-23</u>	STOP VALVE
<u>DF13-30DS-1.25C</u>	
<u>HF-8210-20-H</u>	NEEDLE VALVE ¾"

Enapart Group ! Unit 3 Green Lane Workshops Ashington NE63 0EF United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk

Hirose Valve Page 1 / 6





HF-9210-10-H	Product	Description
### HT-1211-20-23	HF-9210-10-H	-
### Split and split flow valves ### 3763M3V/03-233-1 ### IDC_195-A04-12 ### IDC_24211-32-23 ### IDC_24211-32-24 ### IDC_24211-32-24 ### IDC_24211-32-23 ### IDC_24211-32-24 ### IDC_24221-32-32-32-32-32-32-32-32-32-32-32-32-32-		
3763M3VVC3-233-1 HIC-FL65-A-04-12 HGZ-4211-32-23 Seal kit W-HG-4211-10J-23 JMV-10-SC JMV-10-SC JMV-10-SC HRMIVJ-306S Connector Jack HSO-G02-002C-LZ-31 HT-728-02 W-H64211-20-23 W-H64211-50-23 W-H64211-50-23 W-H64211-50-23 STOP VALVE W-H64211-50-23 STOP VALVE W-H64211-65-23 STOP VALVE W-H64211-32-23 HF-4211-32-23 HF-4211-32-23 HF-4211-30-22 HRV-M06-W-25-21 HRV-M06-W-25-21 HRV-M06-W-25-21 HRV-M06-B-25-21 Direct operated relief valve (HRV) HRV-M06-B-25-21 Direct operated relief valve (HRV) HRV-M06-B-25-21 Direct operated relief valve Direct operated relief valve HRV-M06-B-25-21 Direct operated relief valve HRV-M06-B-25-21 Direct operated relief valve Direct operated relief		
HIC-FJ65-A-04-12		op.n. and op.n. non-rance
HGZ-4211-32-23 Seal kit		
W-HG-4211-10J-23		seal kit
JMV-10-SC JMV-06-SC HRM(V)-306S Connector Jack		
MNV-06-SC		VINLA
HRM(V)-306S Connector Jack		
HSO-G02-D02C-L2-31		Connector Jack
### HT-728-02 W-HF4211-20-23		Connector sack
W-HF4211-20-23 STOP VALVE W-HG4211-50-23 STOP VALVE W-HG4211-50-23 STOP VALVE W-HG-4350-10-23 STOP VALVE HF-4211-32-23 STOP VALVE HF-4211-40-23 Check valve HG-4211-10,2-3 Globe valve HG-4211-08-34 Globe valve HF-4211-80-22 Hydraulic Valve RELIEF VALVE,250kg/cm2 HRV-M06-W-25-21 DIRECT RELIEF VALVE HRV-M03-A-25-21 Direct operated relief valve (HRV) HRV-M06-A-25-21 Direct operated relief valve (HRV) HRV-M06-B-25-21 Direct operated relief valve HTC2-R-03-04-21-SS Stainless steel valve (for hydraulic / water pressure) GV-G22-N Stop valve HT-4211-10-23 Stop valve HT-4211-32-24 Stop valve HT-4211-32-23 Stop valve HT-4211-20-23 Stop valve GNT-02 Throttle valve GNT-03-L		
W-HG4211-50-23		STOD VALVE
W-HF4211-65-23 STOP VALVE		
### WHG-4350-10-23 ### HF-4211-32-23 ### HF-4211-40-23 ### HF-4211-40-23 ### HG-4211-10J-23 ### HF-4211-80-22 ### HRV-M06-W-25-21 ### HRV-M06-W-25-21 ### HRV-M06-W-25-21 ### HRV-M06-A-25-21 ### Direct operated relief valve (HRV) ### HRV-M06-B-25-21 ### Direct operated relief valve ### Direct operated relief valve ### HRV-M06-B-25-21 ### Direct operated relief valve ### Direct operated relief valve ### HRV-M06-B-25-21 ### Direct operated relief valve ### Direct operated relief valve ### Direct operated relief valve ### HRV-M06-B-25-21 ### Direct operated relief valve #### Stainless steel valve (for hydraulic / water pressure) ### Stainless steel valve (for hydraulic / water pressure) #### Stop valve ##### Stop valve ######## Stop valve ########### Stop valve ####################################		
HF-4211-32-23 HF-4211-40-23 HAPT-03-11 Check valve HG-4211-10J-23 Globe valve HG-4211-10-8-34 HF-4211-80-22 HRV-M06-W-25-21 HRV-M06-W-25-21 HRV-M03-A-25-21 HRV-M06-A-25-21 Direct operated relief valve (HRV) HRV-M03-B-25-21 Direct operated relief valve (HRV) HRV-M06-B-25-21 Direct operated relief valve (HRV) HRV-M06-B-25-21 DIRECT RELIEF VALVE Stainless steel valve (for hydraulic / water pressure) GV-G22-N Stop valve HT-0210-15 Stop valve HT-4211-10-23 Stop valve HT-4211-20-23 Stop valve HT-4211-32-24 Stop valve GNT-02 Throttle valve GNT-02-L Throttle valve GNT-03-L Needle valve HT-720-01 Check valve HTC-03-04-10 Check / pilot check valve HTC-06-04-10 Check / pilot check valve HTC-06-04-10 Check / pilot check valve		
HF-4211-40-23		STOP VALVE
HAPT-03-11 Check valve		
HG-4211-10J-23 Globe valve HG-4211-08-34 HF-4211-80-22 HRV-M06-W-25-21 Hydraulic Valve RELIEF VALVE HRV-M03-A-25-21 DIRECT RELIEF VALVE HRV-M06-A-25-21 Direct operated relief valve (HRV) HRV-M03-B-25-21 Direct operated relief valve HRV-M06-B-25-21 DIRECT RELIEF VALVE Stainless steel valve (for hydraulic / water pressure) GV-G22-N Stop valve HT-0210-15 Stop valve HT-0210-15 Stop valve HT-4211-10-23 Stop valve HT-4211-20-23 Stop valve HT-4211-30-24 Stop valve W-HT-4211-20-23 Stop valve GNT-02 Throttle valve GNT-02 Throttle valve GNT-02-L Needle valve GNT-03-L Needle valve GNT-04 Needle Valve Screwed HT-930-10-P Throttle valve HT-930-10-P Throttle valve HTIC-03-04-10 CHECK VALVE HTIC-03-05-10 Check/Pilot Check Valve HTIC-04-04-10 Check / pilot check valve		
HG-4211-08-34 HF-4211-80-22 HRV-M06-W-25-21 Hydraulic Valve RELIEF VALVE,250kg/cm2 HRV-M03-A-25-21 DIRECT RELIEF VALVE HRV-M06-A-25-21 Direct operated relief valve (HRV) HRV-M03-B-25-21 Direct operated relief valve (HRV) HRV-M06-B-25-21 Direct operated relief valve HRV-M06-B-25-21 DIRECT RELIEF VALVE HRV-M06-B-25-21 DIRECT RELIEF VALVE HTICZ-R-03-04-21-SS Stainless steel valve (for hydraulic / water pressure) GV-G22-N Stop valve HT-0210-15 Stop valve HT-0210-15 Stop valve HT-4211-10-23 Stop valve HT-4211-20-23 Stop valve HT-4211-32-24 Stop valve GNT-02 Throttle valve GNT-02 Throttle valve GNT-03-L Needle valve GNT-03-L Needle valve GNT-04 Needle Valve Screwed HT-720-01 Check valve HT-930-10-P Throttle valve HTIC-03-04-10 CHECK VALVE HTIC-03-04-10 Check / Pilot check valve HTIC-04-04-10 Check / Pilot check valve	<u> </u>	
HF-4211-80-22		Globe valve
HRV-M06-W-25-21		
HRV-M03-A-25-21 DIRECT RELIEF VALVE	<u> </u>	
HRV-M06-A-25-21 Direct operated relief valve (HRV)	<u>HRV-M06-W-25-21</u>	<u> </u>
HRV-M03-B-25-21 Direct operated relief valve	HRV-M03-A-25-21	DIRECT RELIEF VALVE
HRV-M06-B-25-21 DIRECT RELIEF VALVE HTICZ-R-03-04-21-SS Stainless steel valve (for hydraulic / water pressure) GV-G22-N	HRV-M06-A-25-21	Direct operated relief valve (HRV)
Stainless steel valve (for hydraulic / water pressure) GV-G22-N	HRV-M03-B-25-21	Direct operated relief valve
Stop valve	HRV-M06-B-25-21	DIRECT RELIEF VALVE
HT-0210-15 Stop valve HT-4211-10-23 Stop valve HT-4211-20-23 Stop valve HT-4211-32-24 Stop valve W-HT-4211-20-23 Stop valve W-HT-4211-20-23 Stop valve GNT-02 Throttle valve GNT-02 Throttle valve GNT-03-L Needle valve GNT-03-L Needle valve Screwed HT-720-01 Check valve HT-930-10-P Throttle valve HTIC-03-04-10 CHECK VALVE HTIC-03-35-10 Check/Pilot Check Valve HTIC-04-04-10 Check / pilot check valve	HTICZ-R-03-04-21-SS	, , , , , , , , , , , , , , , , , , ,
HT-4211-10-23 Stop valve HT-4211-20-23 Stop valve HT-4211-32-24 Stop valve W-HT-4211-20-23 Stop valve GNT-02 Throttle valve GNT-02-L Throttle valve GNT-03-L Needle valve GNT-04 Needle Valve Screwed HT-720-01 Check valve HT-930-10-P Throttle valve HTIC-03-04-10 CHECK VALVE HTIC-03-35-10 Check/Pilot Check Valve HTIC-04-04-10 Check / pilot check valve	<u>GV-G22-N</u>	Stop valve
HT-4211-20-23 Stop valve HT-4211-32-24 Stop valve W-HT-4211-20-23 Stop valve GNT-02 Throttle valve GNT-02-L Throttle valve GNT-03-L Needle valve Screwed GNT-04 Needle Valve Screwed HT-720-01 Check valve HT-930-10-P Throttle valve HTIC-03-04-10 CHECK VALVE HTIC-03-35-10 Check/Pilot Check Valve HTIC-04-04-10 Check / pilot check valve	<u>HT-0210-15</u>	Stop valve
HT-4211-32-24 Stop valve W-HT-4211-20-23 Stop valve GNT-02 Throttle valve GNT-02-L Throttle valve GNT-03-L Needle valve GNT-04 Needle Valve Screwed HT-720-01 Check valve HT-930-10-P Throttle valve HTIC-03-04-10 CHECK VALVE HTIC-03-35-10 Check/Pilot Check Valve HTIC-04-04-10 Check / pilot check valve	<u>HT-4211-10-23</u>	Stop valve
W-HT-4211-20-23 Stop valve GNT-02 Throttle valve GNT-02-L Throttle valve GNT-03-L Needle valve GNT-04 Needle Valve Screwed HT-720-01 Check valve HT-930-10-P Throttle valve HTIC-03-04-10 CHECK VALVE HTIC-03-35-10 Check/Pilot Check Valve HTIC-04-04-10 Check / pilot check valve	<u>HT-4211-20-23</u>	Stop valve
GNT-02 Throttle valve GNT-02-L Throttle valve GNT-03-L Needle valve GNT-04 Needle Valve Screwed HT-720-01 Check valve HT-930-10-P Throttle valve HTIC-03-04-10 CHECK VALVE HTIC-03-35-10 Check/Pilot Check Valve HTIC-04-04-10 Check / pilot check valve	<u>HT-4211-32-24</u>	Stop valve
GNT-02-L Throttle valve GNT-03-L Needle valve GNT-04 Needle Valve Screwed HT-720-01 Check valve HT-930-10-P Throttle valve HTIC-03-04-10 CHECK VALVE HTIC-03-35-10 Check/Pilot Check Valve HTIC-04-04-10 Check / pilot check valve	W-HT-4211-20-23	Stop valve
GNT-02-L Throttle valve GNT-03-L Needle valve GNT-04 Needle Valve Screwed HT-720-01 Check valve HT-930-10-P Throttle valve HTIC-03-04-10 CHECK VALVE HTIC-03-35-10 Check/Pilot Check Valve HTIC-04-04-10 Check / pilot check valve	GNT-02	Throttle valve
GNT-03-L Needle valve GNT-04 Needle Valve Screwed HT-720-01 Check valve HT-930-10-P Throttle valve HTIC-03-04-10 CHECK VALVE HTIC-03-35-10 Check/Pilot Check Valve HTIC-04-04-10 Check / pilot check valve		Throttle valve
GNT-04 Needle Valve Screwed HT-720-01 Check valve HT-930-10-P Throttle valve HTIC-03-04-10 CHECK VALVE HTIC-03-35-10 Check/Pilot Check Valve HTIC-04-04-10 Check / pilot check valve		
HT-720-01 Check valve HT-930-10-P Throttle valve HTIC-03-04-10 CHECK VALVE HTIC-03-35-10 Check/Pilot Check Valve HTIC-04-04-10 Check / pilot check valve		
HT-930-10-P Throttle valve HTIC-03-04-10 CHECK VALVE HTIC-03-35-10 Check/Pilot Check Valve HTIC-04-04-10 Check / pilot check valve		
HTIC-03-04-10 CHECK VALVE HTIC-03-35-10 Check/Pilot Check Valve HTIC-04-04-10 Check / pilot check valve		
HTIC-03-35-10 Check/Pilot Check Valve HTIC-04-04-10 Check / pilot check valve		
HTIC-04-04-10 Check / pilot check valve		
· · · · · · · · · · · · · · · · · · ·		
	HTIC-06-04-10	Check / pilot check valve

Hirose Valve Page 2 / 6





Product	Description
HTICZ-G-10-04-21	Check / pilot check valve
<u>OFSV-T03-50-11</u>	Excess flow shutoff valve
HSO-T03-D02C-LZ	Electromagnetic operated stop valve
<u>HSO-T03-D02F</u>	Electromagnetic operated stop valve
BV-T02-21	Ball Valve
FDC-T03-15-72	Split and split flow valves
FDC-T03-6-72	Split and split flow valves
FDC-T06-50-61	Split and split flow valves
<u>F-HT-4211-10-23</u>	Stop valve
FVP-720-T02-12	
FVP-720-T04-12	Throttle valve
HFC-4211-65	Check / pilot check valve
HGC-4211-50-23	Check / pilot check valve
RMV-06-SCC-E	Maintenance valve for relief valve
HIC-FJ80-A-04-12	Compact flange check valve
HIC-FJ15-B- 04-12	Compact flange check valve
HIC-FJ20B-04-12	Check valve
HSO-G02-D02C-LZ	Electromagnetic operation stop valve
FMTC-06-W-X-21	
JMVZ-G-04-SC	
KMVZ-04-AB-OS-Y2	
KMVZ-04-AB-SS-Y2	
HGZ-4211-10-23	
HGZ-4211-10J-23-166	
HGZ-4211-10-23-166	
HGZ-4211-20-23	
HGZ-4211-20-23-166	
HGZ-4211-32-23-166	
W-HG-4211-20-23	stop valve
HGZ-6211-20-25-166	valve
HGZ-6211-32-24-166	valve
HF-4211-25-24-166-7M	valve
HFZ-ACC-20x10-M42-23	valve
HFZ-ACC-32x10-M60-R-23	valve
HGZ-ACC-32x10-23	valve
RG 174	174 TYPE RG
HF-8210-32-24-166	valve
HSO-M03-A-A22C	vaive
HF-4211-K-32-24	Stan valva
	Stop valve Throttle valve
HT-728-04-S	
HFZ-ACC-32x10-23-2	Accumulator Stop val VE
HG-6211-32-24	CHECK STOP VALVE
JMV-01-SCC-E	MAINTENANCE VALVE
JMV-01-SC-E	PT port control maintenance valve
JMV-01-SS-E	MAINTENANCE VALVE

Hirose Valve Page 3 / 6





Product	Description
JMV-03-SCC-E	MAINTENANCE VALVE
JMV-03-SC-E	MAINTENANCE VALVE
JMV-03-SCS-E	MAINTENANCE VALVE
JMV-03-SS-E	MAINTENANCE VALVE
JMV-06-SC-E	MAINTENANCE VALVE
JMV-06-SS-E	MAINTENANCE VALVE
PT # HFZ-ACC-32 x 10 -23-2	Accumulator stop valve
LF10WBR-4P	'
HR10A-10P-12P(73)	Connector
HR10A-10R-10P(male)	
HR10A-7R-4SC(female)	
HR10A-10R-10S(female)	
HG-4211-8-34	length stop valve
FMPCD-06-B-20-22	and the same
HSO-G02-A10F	Solenoid valve
HF-4211-50-23-166	
HS0-M03-A-A22C	SOLENOID OPERATED DIRECTIONAL valve
JMV-10-SCC	hydraulic sandwich check valves
HT-728-03	Valve
HSO-G02-A11F	SOLENOID OPERATED STOP VALVE
HS0-G02-D02F	Normal Open Stop Valve
HTIC-08-04-10.	CONTROL VALVE
HTIC-10-04-10.	CONTROL VALVE
W-HF-4211-25-24	Valves SBV
HF-8210-15-24	
HF-8210-25-24	
HF-8210-10-24	
HG-4350-10-23	stop valve
HBV-F04SS-14	Hydraulic Valve BALL VALVE
HIPT 03-04-22	VALVE
W-HG-4211-32-24	
JMV-R-06-SC-E	
JMV-R-10-SC-E	
HF-9210-20-23	HYDRAULIC VALVE
HG-6211-20-25-Y	
HGD-4211-10J-23	
HGD-4211-20-23	
HGD-4211-32-23	
HGD-4211-50-23	
<u>HF-4211-80-23</u>	lock valve
HF-8210-10-23	Valve
<u>HK-4251-32-S</u>	
HRV-M01-B25-21	Relief Valve
HPCZ-102-10G-40-D-30	Check valve
HF-4211-15-23	Directional Control Valve
	

Hirose Valve Page 4 / 6





Product	Description
F-HRV-G03-25-11	
HGF-4211-20-23-25 FL-ASI	Valve
HSO-M02-W-D02C-LZ	
HSOH-G06-D02C-LZ-21	
HG-735-02-33	
HG-6211-10-25-Y-166	valve
HSO-M02-W-D02C	Valve
HR22-SC-122	Small High Performance Circular Connector
HF-8210-20-24	Hirose Valve
HS0-G02-A10F	VALVE
FDC-T04-40-72	flow divider/combiner
HSO-G03-D02C-LZ	valve
HT-728-03-S	valve
HSO-M03-A-D02C-21-432	Vaivo
HT-720N-02	1 / 4´ VALVE
HS0-G02A10C	1/4 VALVE
JMV-03-AB-SS-E	Isolation valve
JMV-G-03-SC	lso 5 isolation block
HSO-T03-D02C-31	STOP VALVE
Lever for HBV-T03-0833	STOF VALVE
OFSV-F06-180-11	Overflow cut-off valve
	Overnow cut-on valve
DF14-30S-1.25C	
DF14-2628SCFA	A.F
OFSV-F06-180-12	Adjustable overflow shutoff valve
HT-4211-8-23	Stop valve
<u>GNG-02</u>	
<u>DF62B-3EP-2.2C</u>	CONN PLUG HOUSING 3 POS BLK
DF62-2428SCF	CONN CRIMP SKT 22-28 AWG
DF11-4DS-2C	4 PIN CRAMP PLUG CONNECTOR
<u>DF11-2428SCF</u>	24-28AWG CONNECTOR PIN
<u>DF11-4DP-2DS (24)</u>	4 PIN CONNECTOR
<u>HR10A-10P-10PC(73)</u>	,
<u>HR10A-10P-10P(73)</u>	
<u>HT-720N-01</u>	Throttle valve
RMV-03-SCC-E	
<u>HF-1280-40-11</u>	Stop valve (valve remote control line)
<u>HR10A-13P-20P(73)</u>	
HIIC-03-10-375	
Gasket sets for HF-4211-32-23	Gasket sets
Gasket sets for HF-4211-40-23	Gasket sets
<u>JMVZ-03-SCC-166</u>	hydraulic valve
<u>HT-728-04</u>	check valve
JMV-R-01-SC-E	valve
<u>HF-4211-K-25-24</u>	
<u>HF-4211-25-24</u>	STOP VALVE 1" MK

Hirose Valve Page 5 / 6





Product	Description
<u>HF-4211-32-24</u>	stop valve
HK-4251-20-S-10	CARTRIDGE SHUT-OFF VALVE
<u>HGZ-4211-50-23</u>	SHUT-OFF VALVE
<u>JMV-10-SCC-166</u>	Maintenance valve
HRV-G06-25-11	
<u>GT17H-4S-HU</u>	
<u>GT17H-4S-R</u>	
<u>HSO-T03-D02C</u>	Electromagnetic operated stop valve
FMCQ-06-A-07-21	
HDF-4211-K-65-23	
<u>HBV-GF-12-32</u>	
FDCS-G04-30-61	Valve
FDCS-G03-15-61	Valve
FDCS-G03-20-61	Valve
HG-8210-32-22	
<u>11-9BP6P</u>	round plug
HSO-G03-A22C-LZ-21-432	
HSO-M03-W-D024C-21	
HFP-T02-1.0-12	FIXED FLOW CONTROL VALVE FV HYDRAULIC
<u>HVR-M10-A-25-21</u>	
HSO-G02-A20C-31	
<u>DF11-10DS-2C</u>	Connector
HS0-G02-A22C-31	Valve
<u>HF-4211-65-23</u>	Stop valve
<u>F-GNT-02-L</u>	throttle valve
<u>F-GNT-03</u>	
<u>HBV-G03-1032</u>	
HSO-M03-W-DC24VC-21	Solenid valve
HSO-G02-A10C-31	
HT305/DF50-2830HC	
JMV-CR-06-SC	
JMV-06-SCC	
<u>OFS-T03-20-12T</u>	Valve
JMV-06-AB-SS	AB port control maintenance valve
JMV-10-AB-SS-E	AB port control maintenance valve
<u>HT-728-06</u>	
<u>JRC-SC2-112</u>	
HG-9210-10J-23	
HSO-SOL02-A20	

Hirose Valve Page 6 / 6