



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Ağaoğlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Robertshaw

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">5000-811</a>	Thermostat
<a href="#">365A-A2</a>	vibration switch explosion-proof
<a href="#">366-A2</a>	vibration switch
<a href="#">368-R</a>	Pneumatic Vibration Detector
<a href="#">376A-A1-CO</a>	Vibraswitch® Malfunction Detectors
<a href="#">613-NHU-TD07-B</a>	Liquid Level Detector
<a href="#">613-NLU-TD07-B</a>	Level indicator
<a href="#">913-NLU-000-T</a>	
<a href="#">913-NLU-TD10-T</a>	
<a href="#">EURO366G-D0-W2-H-FX-F</a>	VIBRASWITCH
<a href="#">RT-1009-A1</a>	TEMPERATURE REGULATOR EXACTLY PER SERIAL NUMBER E98B759
<a href="#">GE158A7585P065, 3" RT-1010-A1</a>	Temperature Regulator
<a href="#">613 NLU-0000-0</a>	DETECTOR, MINITEK LOLVL ( BTO)
<a href="#">PO112201</a>	Pressure piston
<a href="#">P011-2201</a>	pressure operator
<a href="#">U701ODERHC-S7C</a>	Gas Valve
<a href="#">TA-158A7585P052</a>	THERMOSTATIC ASSEMBLY FOR 4"RT-1010-A3 REGULATOR
<a href="#">EURO366G-D0-W3-H-FX-F</a>	
<a href="#">613-N??-0000-0</a>	Mini-Tek Miniature Liquid-Level Detector
<a href="#">EURO366G-D2-W2-H-FX-F</a>	VIBRASWITCH
<a href="#">EURO366G-D0-W2-H-FX-X</a>	VIBRASWITCH
<a href="#">900SA647-01</a>	SWITCH ASSEMBLY
<a href="#">904GC402-02</a>	SPACE HEATER
<a href="#">160KB044-03</a>	COIL ASSEMBLY
<a href="#">EURO366G-D2-W2-H-X-X</a>	VIBRASWITCH
<a href="#">PS2197/4</a>	SOLENOID
<a href="#">5500-208M</a>	SWITCH
<a href="#">571A-D</a>	Vibration transmitter
<a href="#">E365A-G0</a>	Vibraswitch (ATEX)
<a href="#">S291</a>	Coolant level sensor
<a href="#">613-N??-0000-B</a>	
<a href="#">613-N??-0000-C</a>	
<a href="#">613-N??-TD12-0</a>	
<a href="#">613-N??-TD12-B</a>	
<a href="#">365A-A0-E</a>	VIBRATION SWITCH,

Product	Description
<a href="#">UW-GE158A7585P0</a>	UPPER WORKS FOR GE158A7585P052
<a href="#">EAC-4L</a>	Thermostat
<a href="#">HAZMAT BOX</a>	SPECIAL PACKING HAZARDOUS MATERIAL
<a href="#">UW-RT1010-A1</a>	COMPLETE UPPERWORKS
<a href="#">82179-S3</a>	Valve Repair Kit
<a href="#">82440-B1</a>	INDICATING LOCKOUT RELAY RED/GREEN
<a href="#">82653-B1</a>	Snap-Acting Position Indicator
<a href="#">83939-D23</a>	Aluminium High Capacity Relay
<a href="#">83939-E1</a>	Aluminium Lockout Relay
<a href="#">83939-G321</a>	KNOB-ACUTATED RELAY, ALUMINUM BODY
<a href="#">83939-H221</a>	ALUMIMUM LEVEL ACT INDICATING RELAY
<a href="#">83939-H323</a>	Lever Operated Relay
<a href="#">84370-B1</a>	PNEUM VALVE
<a href="#">84370-B2</a>	Pressure Sensor
<a href="#">83939-B21</a>	Aluminium Relay
<a href="#">81073-A1</a>	Check Valve
<a href="#">82653-B8</a>	SNAP-ACTING POSTN INDICATOR
<a href="#">82653-B3</a>	SNAP-ACTING POSITION INDICATOR
<a href="#">7000DERHC-S7C (700-059)</a>	Gas valve
<a href="#">624-NLU-TD12-B</a>	Level indicator
<a href="#">1720-801</a>	Electromagnet Replacement Kit
<a href="#">624-NLU-0000-0</a>	Oil Level Sensor
<a href="#">700-057</a>	Gas Valve
<a href="#">E365A-G2-E</a>	VIBRASWITCH
<a href="#">614-NHG-0000-C</a>	Robertshaw Mini-Tek Level Sensor
<a href="#">E365A-A-O--E</a>	
<a href="#">EURO366-A2-H2-A-FX-X</a>	VIBRATION SWITCH
<a href="#">365AD8</a>	Vibration Switch Dpdt 5a 120vac
<a href="#">366-A0</a>	Vibration Switch: SPDT, 7 A @ 460 V, Manual, Mechanical
<a href="#">EAC-4L , 203-05-SSH-450</a>	THERMOSTST
<a href="#">E87C515</a>	Thermostatic Control Valve
<a href="#">E87C514</a>	Thermostatic Control Valve
<a href="#">710-101</a>	Non Regulated LC valve ½" In x ½" Out Manual Model
<a href="#">Smart 2000</a>	Digital Programmable Thermostat
<a href="#">110-326</a>	Natural Gas Water Heater Valve Uni-Kit w/ 1-3/8"
<a href="#">631-NLU-TD07-B</a>	Mini-Tek Level Sensor
<a href="#">82665-A10</a>	
<a href="#">606-191-00400</a>	
<a href="#">606-191-00401</a>	
<a href="#">606-191-00412</a>	
<a href="#">606-191-00406</a>	
<a href="#">606-191-00407</a>	
<a href="#">606-191-00403</a>	
<a href="#">606-191-00405</a>	
<a href="#">606-191-00420</a>	









