



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Ağaoğlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## ASA Hydraulik

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">AWU 2000K16S032</a>	Compensator
<a href="#">AWU910000000000</a>	mechanical limit switch
<a href="#">Metri Pack 280</a>	Mating plug
<a href="#">Connector for Metri Pack 280</a>	Connector/ Gegenstecker
<a href="#">AWU 2000K16S063</a>	Compensator
<a href="#">SDAK0125T</a>	Suction unit
<a href="#">AWU 2000K16S125 / SDKSS126</a>	
<a href="#">ASA0177AH22BP</a>	Kühler, kompl
<a href="#">ASA 0929SA6FB</a>	Luftkühler
<a href="#">ABM20220VIR</a>	Zahnradmotor
<a href="#">AWK 10300114066 / ASA0176AD02</a>	oil air cooler
<a href="#">ASA 0176 - 0257 (AWKL85000405022)</a>	
<a href="#">SDKSS032 (AWU 2000K16S032)</a>	Compensator with SAE flanges, NG 32
<a href="#">Nr.: AWU 2000K16S040 Type: SDKSS040</a>	Expansion joint with SAE flanges
<a href="#">ASA0177AA25</a>	Oil Air Blast Oil Cooler
<a href="#">ASA0075GA47CCS</a>	Kühleinheit
<a href="#">VA73-BP71/VLL/M/I-65A</a>	fan
<a href="#">ILWPL53060EK</a>	
<a href="#">NG80 SDK0080</a>	
<a href="#">AWU 2000K16S050</a>	Compensator
<a href="#">SDKSS080</a>	Compensator
<a href="#">ASATT06GD04</a>	cooler
<a href="#">ASA0257AD02F</a>	Oil-air coolers
<a href="#">Ursprungszeugnis // Certificate of Origin</a>	Certificate
<a href="#">ASA0176AD01 (ASA 0176 - 12 V-DC)</a>	Oil-air cooler axially
<a href="#">SDAK0100T</a>	Suction Unit
<a href="#">ASA0256AD02KT</a>	Oil-air cooler
<a href="#">SDAK0050T (AWU 11040205014)</a>	
<a href="#">Nr.: AWU 2000K16S063 Type: SDKSS063</a>	Compensator with SAE flanges
<a href="#">ASA0256AD02U00</a>	whole cooler
<a href="#">F45-12L8201-03S WPC</a>	fan
<a href="#">AWKL66062245015</a>	fan unit
<a href="#">ASATT11RDO1</a>	radiator
<a href="#">10(1)/250 IP67 90°C</a>	
<a href="#">AWK 25300114224</a>	Oil-air cooler, axial
<a href="#">AWKU12010000032</a>	ASA connection block set - 1 1/4 "

Product	Description
<a href="#">ILLZTH4765K</a>	temperature switch
<a href="#">ILLZTT5069K - R 1/2"</a>	temperature sensor
<a href="#">SDA00100</a>	
<a href="#">ILLELE0295O6</a>	X-TEILE F KUEHLER
<a href="#">ILLELE0295A2</a>	Fan unit for oil coolers
<a href="#">ASA0176AD02</a>	Cooler package with fan 24V
<a href="#">ILLEA0176K</a>	oil cooler
<a href="#">ASATT07GD02</a>	oil cooler
<a href="#">AWK 15150100026</a>	Oil-air cooler
<a href="#">AWKU12010000003</a>	ASA connection block set 1"
<a href="#">ILLEVA0385A4</a>	heat exchanger
<a href="#">ASA0115AD02GT</a>	Fan motor
<a href="#">ASA 0176 - 0257</a>	Fan unit for oil air coolers - 12 V
<a href="#">LL 01 - 24 V-DC</a>	oil cooler
<a href="#">AWE 5024934001K</a>	fan controller
<a href="#">SDAK0063T (AWU 11040206314)</a>	
<a href="#">SDAK0040T (AWU 11040204014.)</a>	
<a href="#">ASA0467AA49CC</a>	Oil Air Cooler
<a href="#">AWKL65016324075</a>	Fan unit for oil cooler
<a href="#">SDA00080W</a>	
<a href="#">ASA LL06 - AC - Compact</a>	Oil Air Cooler, Axial
<a href="#">ASA0115AD02KT</a>	oil air cooler
<a href="#">SDAK0080TU00</a>	Suction unit
<a href="#">SDKSS050U00</a>	Compensator
<a href="#">Fan motor for ILLELE0385A1</a>	Fan Motor
<a href="#">0115AD02BP</a>	oil cooler with fan and housing)
<a href="#">ASA0257AD02 (AWK 16300212071)</a>	Axial oil air cooler
<a href="#">ASATT11RD02</a>	
<a href="#">ILLZSET5G25</a>	
<a href="#">SDAK0050TU00</a>	
<a href="#">NG100 K16S-100 - SAE 4"</a>	Compensator with SAE flanges
<a href="#">SDKSS100</a>	Flexible Coupling
<a href="#">SDA0050</a>	Shut-off flange valve
<a href="#">ASA0176-0257 OKO40-5/OKO50-5/ECO16 ILLELE0385S2(4)</a>	Fan unit for oil air cooler - 24 V
<a href="#">ILWPL70060EPU00</a>	
<a href="#">ILLZTH6069K</a>	
<a href="#">SDKSS090</a>	
<a href="#">ASATT06GD03</a>	oil air cooler
<a href="#">ILWPL20020EK</a>	Plate heat exchangers
<a href="#">ASA connection block set - 1" for TT 5-11 (-25)</a>	ASA Terminal Block Set - 1"
<a href="#">ILLELE0385A2</a>	fan unit
<a href="#">ASA0023UD01</a>	
<a href="#">ASA 0023 / TT02 - 12 V-DC (AWK 25030034026)</a>	Oil Air Cooler, Axial
<a href="#">Metri Pack 280 ESMP</a>	mating plug
<a href="#">ILLEA0115BPV</a>	

Product	Description
<a href="#">ASA-TT 07 (ASATT07RC2E)</a>	Oil Air Cooler - Comact
<a href="#">ASA0367AD01</a>	oil air cooler
<a href="#">ASATT11RC2E</a>	oil air cooler
<a href="#">WO-1036234</a>	Temparatur Control
<a href="#">NG 50K16S-50-SAE 2"</a>	
<a href="#">AWU 2000K16S080</a>	compensator
<a href="#">ILLELE0295A6</a>	fan with housing
<a href="#">ASATT16RA27U00</a>	
<a href="#">AWE 5012931001K / ILLZTC12-2K</a>	fan controller
<a href="#">ILLELE0295A6 / ASA 0115 24VDC</a>	
<a href="#">AWKL85000405022 / ASA 0176 - 0257</a>	fan
<a href="#">ASA0177AD02BP</a>	
<a href="#">ILZTT5067K</a>	
<a href="#">ILLELE0385A2 (ASA 0176)</a>	
<a href="#">ASA0367AA48U00</a>	
<a href="#">ASA0567AA66</a>	Radiator
<a href="#">ASA0567AA4A</a>	Radiator
<a href="#">ASA0727AA4A</a>	Radiator
<a href="#">ASATT07GD03BPGT</a>	radiator
<a href="#">WO-1048568 OEM</a>	
<a href="#">ILLEVA0295A4</a>	Fan unit for oil cooler
<a href="#">AWU 2000K16S100</a>	Compensator with SAE flanges, NG100
<a href="#">ASA0043GD02</a>	oil-air cooler
<a href="#">SDAK0100T 4" , ESAF-100</a>	
<a href="#">ILLZTC24K</a>	Fan control
<a href="#">ILLZTT5067K</a>	temperature sensor
<a href="#">ILLEA0075</a>	exchanger
<a href="#">AWU 11040205014</a>	suction unit
<a href="#">P/N: AWU 100SDAET050, Type: SDAET063K</a>	adapter flange
<a href="#">SDA0080</a>	Butterfly Flange Valve NG80, 3"
<a href="#">SDA0040</a>	
<a href="#">AWU911000000000</a>	inductive limit switch
<a href="#">P/N: AWK 25300114012 , Type: ASA TT-16-12 V-DC-0,21 kW</a>	Axial oil-air cooler
<a href="#">ASA0115AD01U00</a>	Oil/ Air cooler
<a href="#">ILLELE0295A5</a>	ventilator
<a href="#">P/N: AWK 25300114212, Type: ASA TT 16 - 12 V-DC - Ra</a>	Axial oil-air cooler
<a href="#">ILLELE1434A2</a>	
<a href="#">SDA0063</a>	
<a href="#">ASA0567AH11</a>	
<a href="#">ILLZASA32G32</a>	
<a href="#">ILLELE1434A2U00</a>	fan kit
<a href="#">ILLZTC24-2KU00</a>	Control unit
<a href="#">ILLZTT5069KU00</a>	Temperature sensor
<a href="#">ASATT06GC2E</a>	
<a href="#">AWK 8100TT5069K</a>	Temperature sensor

Product	Description
<a href="#">SDA0125</a>	
<a href="#">EAFSMK</a>	
<a href="#">SDKSS080U00</a>	Compensator Bellows
<a href="#">AWU 1000000100A</a>	Butterfly valve
<a href="#">ASA0043GE02</a>	
<a href="#">ASA0257AD04BP</a>	
<a href="#">ASA0367AD02BP</a>	
<a href="#">IB-017980</a>	fan
<a href="#">EAFSM</a>	LIMIT SWITCH
<a href="#">ILLET16K</a>	radiator
<a href="#">ILLELE0295A1 (WO-1043007)</a>	fan
<a href="#">AWKL65016312075</a>	
<a href="#">AWKL66062125015</a>	
<a href="#">ASATT16GD01 / AWK 25300114012</a>	Oil-air cooler
<a href="#">K16S SDKSS050</a>	Compensator
<a href="#">ILLELE0385A1U00</a>	
<a href="#">Type: ASA-PL 53-20</a>	plate heat ashtray
<a href="#">ILWPL53020EP</a>	
<a href="#">WO-1042215</a>	ventilator
<a href="#">ASATT16RA25 / AWK 24300114212</a>	oil-air cooler, axial
<a href="#">ILLZTH6065KU00</a>	
<a href="#">ILLZSET5G32 / AWKU12010000032</a>	terminal block set
<a href="#">AWU 2000K16S040</a>	compensator
<a href="#">ILLELE0295A6U00</a>	Fan
<a href="#">WO-1085794</a>	
<a href="#">ILLELE1434A2 / AWKL65016328005</a>	fan unit for oil cooler
<a href="#">ASATT25GD02D</a>	Oil cooler with fan
<a href="#">ILLEVA0385S4 (ILLELE0385S2)</a>	
<a href="#">Metri Pack 280 / AWE 50999310010</a>	Counterplug
<a href="#">EAFSIK</a>	
<a href="#">ASATT11RA25</a>	oil air cooler
<a href="#">ILLEGAK0176GT</a>	
<a href="#">AWK 81000540050</a>	temperature sensor
<a href="#">ILLZTC12-2KU00 / WO-1151537 / ILLZTC12-2K</a>	
<a href="#">SDAK0040TU00</a>	
<a href="#">AWE 5024934001K / ILLZTC24-2K</a>	fan controller
<a href="#">K16S-50-SAE 2" / SDKSS050 / AWU 2000K16S050</a>	Compensator
<a href="#">K16S-80 - SAE 3" / SDKSS080 / AWU 2000K16S080</a>	Compensator
<a href="#">Nr. SDA0080 Type NG80</a>	butterfly flange valve
<a href="#">Nr. SDA0040 Type NG40</a>	butterfly flange valve
<a href="#">ASATT10UD01X</a>	
<a href="#">ILWPL70070</a>	
<a href="#">AWK 16150100023</a>	oil-air cooler, axial
<a href="#">ILWPL70060EK (ASA-PL 70-60 E Kit)</a>	
<a href="#">ILWPL70120EK (ASA-PL 70-120 E Kit)</a>	

Product	Description
<a href="#">AWK 14100034093</a>	oil air cooler
<a href="#">WO-1136649</a>	
<a href="#">ILLEVA0240A1</a>	fan unit
<a href="#">ASATT07RD01U00</a>	
<a href="#">ASATT07RD02U00</a>	
<a href="#">ASATT16RD01U00</a>	
<a href="#">ASATT16RD02U00</a>	Rail heat exchanger
<a href="#">ASA0367AD01U00</a>	
<a href="#">ILLZASA32U20U00</a>	
<a href="#">ILLZSET5U16U00</a>	
<a href="#">ILLZSET5U16</a>	radiator
<a href="#">ASATT16RD02 / AWK 25300114224</a>	oil air cooler
<a href="#">ASATT16RD01</a>	oil air cooler
<a href="#">ASATT07RD02</a>	oil air cooler
<a href="#">ASATT07RD01</a>	oil air cooler
<a href="#">ILLZASA32U20</a>	ASA Connector
<a href="#">AWK 80100050608</a>	plate heat exchangers
<a href="#">AWK980150034100</a>	mounting plate
<a href="#">ILLELE0385A2U00</a>	fan unit
<a href="#">ILLELE0385A2</a>	
<a href="#">ILLELE0385S2</a>	fan
<a href="#">ABP W 090 S 20 H P 02 B00</a>	pump
<a href="#">ESDU6P2.8K</a>	mating plug
<a href="#">ASA0115AD02</a>	oil air cooler
<a href="#">ILLZTC24-2K / AWE 5024934001K</a>	
<a href="#">ASA0257AD02</a>	Oil-air cooler axial
<a href="#">ILLZTH5069K</a>	Temperature Control Switch for Oil Cooler
<a href="#">ILLZASA40G40</a>	Connector
<a href="#">ILLEFTFDK</a>	
<a href="#">0295</a>	ASA0257AD04BP (WO-1074761) hydraulic radiator motor
<a href="#">ILLZTH5069KU00</a>	
<a href="#">SDKSS040</a>	
<a href="#">ILLEVA0385S3 (ILLELE0385S1)</a>	Fan
<a href="#">AWK 25300114012</a>	
<a href="#">ILLZTH4765KU00</a>	
<a href="#">MW03693</a>	
<a href="#">ASA0075GA25</a>	
<a href="#">ASA0075UA25</a>	
<a href="#">WO-1094176</a>	
<a href="#">WO-1093341</a>	
<a href="#">AWK 10300124067</a>	axial oil-air cooler
<a href="#">ASA0043UD02</a>	
<a href="#">SDKSS063</a>	hydraulic flange
<a href="#">ABM20080VIR.</a>	

Product	Description
<a href="#">SDAK0040T</a>	Suction unit
<a href="#">ASATT11RD02U00</a>	chiller
<a href="#">MDGQ403008IHK</a>	Vibration dampers
<a href="#">ASATT06GD03BP - 12V</a>	X-OIL AIR COOLER
<a href="#">ILLELE0385A2B02</a>	Fan unit - 24V
<a href="#">ILLZTC12-2K - 12V DC</a>	fan controller
<a href="#">SM 10 T26R Z (8032 1292)</a>	Subminiature lamp/ special
<a href="#">ILLZTH9067K / sensor for ASA0043GD01TB0</a>	temperature switch/sensor
<a href="#">ILLELE0385A2 / 4 (ILLEVA0385A4)</a>	
<a href="#">ILLZTC12-2KU00</a>	TEMPERATURE CONTROL
<a href="#">IB-010622</a>	
<a href="#">ILLCO0701D</a>	AIR COOLER
<a href="#">ASATT07R A44U00</a>	TT Rail Series Oil / Air Cooler
<a href="#">ASATT07RA44</a>	
<a href="#">IB-024157</a>	sticker
<a href="#">ASATT20RD04</a>	chiller
<a href="#">WO-1059018</a>	radiators
<a href="#">SDA0125 / AWU 1000000125A</a>	
<a href="#">ASA 0115 AA25</a>	
<a href="#">WO-1109319 / ASA0467AA47</a>	
<a href="#">SDA0063U00</a>	LIMIT SWITCHLI BUTTERFLY VALVE
<a href="#">ASA0467AA48U00</a>	
<a href="#">ASA0115AD02BP</a>	oil cooler
<a href="#">ILLZTT5069K</a>	temperature sensor
<a href="#">SDKSS050- EU Version</a>	
<a href="#">SDA0100</a>	
<a href="#">AWU 10000000100</a>	
<a href="#">F29P-24E8001-12S WPC (ILLELE1434A2)</a>	oil cooler fan
<a href="#">WO-1123920</a>	
<a href="#">ASATT07RD04 / AWK 15150100216</a>	
<a href="#">ASA0176AH11</a>	exchanger
<a href="#">ASATT07RD02/24V</a>	
<a href="#">SDKSS100U00</a>	Kompensator mit SAE-Flanschen
<a href="#">AWU 2000K16S090</a>	
<a href="#">SDKSS063U00</a>	
<a href="#">AWU 2000K16S025</a>	
<a href="#">SDKSS090U00</a>	
<a href="#">SDKSS025U00</a>	
<a href="#">ILLOK2512KTPB00</a>	
<a href="#">SDKSS063SS</a>	
<a href="#">AWKL69099225057</a>	
<a href="#">ILLZTH9069K</a>	Temperature switch
<a href="#">SDAET063KU00</a>	Adapter Flange
<a href="#">SDA00063</a>	Butterfly Flange
<a href="#">AWK 16300124057</a>	



Product	Description
<a href="#">WO-1063758</a>	ventilator
<a href="#">ILLZSET5G32U00</a>	Rail Connector
<a href="#">ASA0176AD02U00</a>	Oil/Air Cooler
<a href="#">SDKSS050SSU00</a>	
<a href="#">SDKSS050SS</a>	
<a href="#">ILLELE0295A6B02 / AWKL66062245015</a>	Fan unit for oil cooler
<a href="#">SDAK0063TU00</a>	
<a href="#">SDAK0050T</a>	ASPIRING GROUP
<a href="#">SDAK0063T</a>	
<a href="#">SDAK0080T</a>	
<a href="#">SDA0125U00</a>	Butterfly Flange
<a href="#">SDKSD080</a>	compensator
<a href="#">SKH BSPP 1-1/2"</a>	Ball valve
<a href="#">SDKSD050</a>	compensator
<a href="#">AWKL65016328005</a>	Hydraulik fan
<a href="#">ILLEGAKTT16GT / AWK 90000116003</a>	
<a href="#">WO-1121850</a>	
<a href="#">AWK 17400230035</a>	
<a href="#">AWKU12401120003</a>	
<a href="#">ILLEC06UBPVU00</a>	OIL RADIATOR
<a href="#">ILLZTC122K</a>	ASA Temperature Control Kit 12V DC
<a href="#">HFSE000074B01</a>	
<a href="#">ABPG0200ASK</a>	Gerotor pump
<a href="#">AWK 26150100356 / ASA 0115 - GT - 24 V-DC / ASA 0115AD02GT</a>	
<a href="#">AWKU12251000003</a>	
<a href="#">AWK 42200100223</a>	
<a href="#">AWK 15200100241</a>	
<a href="#">AWK 94030032752</a>	oil/air circulating coolers
<a href="#">AWK 16300166425</a>	oil air cooler
<a href="#">AKKU12457835457</a>	Connection - set 1
<a href="#">ILLZTH9067K</a>	
<a href="#">ASATT25RD01BP</a>	TT 25 12V DC oil cooler with bypass valve
<a href="#">ILLZTH6065K</a>	radiator temperature transducer, IP65, 60°C setting
<a href="#">AWK 80100050320</a>	plate heat exchanger
<a href="#">WO-1141820</a>	Temperature Controller
<a href="#">MDGQ0200758GB00</a>	
<a href="#">SDKSS090U00 K16 S 90</a>	
<a href="#">ILLELE0240A1U00</a>	