



ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Barksdale

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

eRAND'S PRODUCTS

Pkaouct	Drickdptdan
/:0:1//5/	7ervice package
551::5/:1T//	UNSPNPS68PGA3SE43ES N5GEM
:T1/T5:F/	
ASL1ET/ 1 8dent.1Gr. 251::T-T-1T//5/	8ntermittent controller
NCGO 221::T-T-1/2//;. 6ypeO ASL1ET/	AussetRregler
TF5 EIP	relief valve
EIG T2-	
H/FF-0F2	7pare parts package xA9:/
xKHH2;-1//5K	
9L002:	pump, gear
xl/-TT/ C D71 -5T KE /F G	-C51directional seat valve
xl/F::F	Nrop.1Lontrol lalve
xl/F::2	valve
xl/F2T:	V8SEL68PGA3 IA3IE
xl/0:TF C 7AD5/-NL/FN4 7PH2- BK5z	7liding valve
7IG555KET5NVx7/HHT Bxl/005z	5C5 Wege17itRventil
xl/0HF2 C 8IG55TKE/0NV B45z	lalve
9L-25-	Nressure switch
IVKE/FE-:/ B9L:T;Tz	Virectly controlled pressure regulating valve
93 -:/F PK7P3E6E SEN3ALEV KX N0714SLx(sensor
T0T0x193-/-1N9	Dagnetic switch Seed
93-:/F	7EG7PS
9XH-H-	Lonnector
9)-:551//	LP83
D971/0	j836ES1SE43ES
xl/-TTT C D71-5TKE/FN 5:l	xydraulic seat valve
xl/-TTTOD71-5TKE/FN	xydraulic seat valve with emergency control
xl/-TT; C D71-55KE/FN	hydraulic valve
xl/-;- C D71-55NL/FNBA:z	Virectional 7eat lalves
N7T//5T1FTTA	-C51way solenoid valve
NATFT2T1FT-	valve
NAT/525 C 9H -5TSj1TC0	-C51way valve
NAT/-T-1//--	valve
NAT/-H/1/5--100	;C51Wegeventil7T/ ;0TSj1T C 0th
NAT5F2T	electro valve
NAT5F2H1/5--	valve

Product	Description
0221-374 / XT-R12 5250 >= Lm > 5000	Transmitter for Bypass Level Indicators
0419-037 / 9A21-PL1-V	pressure switch
BPS34GVM00.5BP (500mbR/420-2/G1/4E/E)	Pressure switch
BPS34GVM0001BVP	electronic pressure switch
P/N: 0403U401, Type: E1H-G90-RD-LC	Pressure switch-UL
BT5-T5-36BG-P16P	Temperature Switch
E1H-R-VAC-P6/ 0403-179	Econ-O-Trol Mechanical Pressure Switch
E1H-H500-P8/ 0403-118	pressure switch
BNA-S22-3/4"150-RF-VA30/ /02-MA-GE409 LM=1.0<1.5m (0332=1037)	Mini Bypass Level Indicator
UTA2/0+120C/420/G1/4E/F/ (0631-063)	Temperature Transmitter
455ET4-01-P4-Z050	Intelligent Pressure Transmitter
0801U057 / A147R3WC2	Valve
BPS312FM0040BPQ6	pressure switches
BPS342FM0040BPQ6	pressure switch
UPA2-DMP333	Electronic Pressure Transducer
506925	Fresh water level sensor
0711-339.7	Flow Switch
6143R3HC3/ 0801-130	High Pressure OEM Valve
82C1-PL1-B-UL	pressure switch
XT-R12-LM600	LEVEL TRANSMITTER
T96201-BB3SS-T5-W36	Compact Pressure Switch
0602-121 / T2H-H251S-A	temperature switch
0417-385/ 8141-PL1-B-LH-ES	pressure switch
9681X-1CC-2-W79	PRESSURE SWITCH
CERTIFICATE OF COMPLIANCE-B	Certificate of Compliance
P/N: 0303-038 Type: GK03L 2m	Limit Switch for Bypass Level Indicator
0111-704 / UNS-PP16-PP18-G3/4-GE298 5m PVC-Kabel	Level Switch
0417-710	Pressure switch
0713-354.3 / BFS-30-O-G1-MS-WE-ST	Flow sensor
9681X-1CC-3-B-K	PRESS SWITCH, EXPLOSION PROOF
BFS-30-N-G1-MS-WE-ST / 0713-349.6	
BFS-30-N-G1-MS-WE-ST / 0713-349.10	
P/N: 0231-016	
P/N: 0499-027	
0111-631	BILGE LEVEL SWITCH
0112=1086 / UNS1000-MS/T1/2-M12x1	
0402-169 / DPD2T-GH150SS-ST3	pressure switch
96201-BB2-T2-P1Z17	Pressure Switch
0417-021 / 8251-PL1-B	pressure switch
906-0919	
906-0946	
906-0947	
BPS34GEM0600BP	Pressure Sensor

Product	Description
230VAC SN H190043801 CXVE-217-0812-15L	TERMINAL BOX
926-0811	Junction Box
0406U123 / 96201-BB2-T2	pressure switch
0406U172 / 96201-BB2-T2-P1	Pressure switch
0417-775	
UNS2000 SN H190043801 CXVE-217-0812-15L	FLOAT SWITCH
0332-592/ BNA-S22-DN15/PN16-VA30/02-MA	
PN: E1H-H90	Dia-Seal Piston Pressure Switch
0111-759 / UNS-VA/SB5-PE33/2 NC	
ML1S-100-I-O	temperature switch
0406-114 / TC9622-2	
0406-113 / TC9622-2	
5625R6WQ3	Valve
KD2447	MAJOR REPAIR KIT
0111-468 / UNS-MS1/8-K3-BN25/3 3m PVC-K. WE	Float Switch
0112-829	liquid level probe
pn 0113-776 / UNS2000-ABS/VA/FLS-PG-K316318.1/001	sensor
0332-628 / BNA-S22-R1/2"Male- TT30/02P- MA LM<1.0m	
0112-557	
0401-462 / D2X- M150SS-UL	Pressure Switch
UNS2000-VA/T3/4-ST1-VA52 T-HT-GE392-L1/1 Lo135	
0303-056 / GK03-UL	
0713-351.1 / BFS-30-L-G1/2-SS-WE-ST	Flow Switch
0713-351.2 / BFS-30-L-G1/2-SS-WE-ST	Flow Switch
0713-351.3 / BFS-30-L-G1/2-SS-WE-ST	Flow Switch
0713-351.4 / BFS-30-L-G1/2-SS-WE-ST	Flow Switch
0111-652 / UNS-VA/SB5-PE33	
PN: 0711-257.5 / Type: BFS-10-N-G1/2-MS-NO-ST	flow switch
D2X-M80SS-UL	Explosion Proof Diaphragm Pressure Switches
0232-014 BLP2/C/xbar/PUxM/F	
0499-026	
8251-PL1-B-D-LH-PC-GE380 typ 0417-716	
BT5-T4-41BG-P9P	Transducer
BPS35EVM3000P	
0710-023.4 / BFS-10-N-AIR-G1/2-SS-WE- ST 10...35 NL/min	
0403U407 / E1S-H90-PLS	pressure switch
UNS2000-special 230V AC/ 0113=1433	junction box
0801U474 / 921P3WQ3	Shear-S. Valve Pnl mount
6181S3HC3-MC	VALVE
8142R1HO3-O/SN:082317	Control Valve
0405-344 / B2X-H12SS-UL	PRESSURE SWITCH

Product	Description
0801-128 6142R3HO3	
E1H-H90-P6-PLS	
B1T-M12SS	Pressure switch
0403-081 / E1H-H250-P4-EXI	Pressure switch
0225-025	
0603-081 / T1X-H251S-A-EX	temperature switch
0711-257.8	
L96211-BB4-S0074	Pressure Switch
0416-176	
B2T-H32SS	pressure switch
BFS-10-N-G1/4-MS-NO-ST / 0711-256.6	flow switch
E1H-R15-BR-V	
0711-261.1 BFS-10-N-G1-SS-NO-ST	
423T4-13	Barksdale Control Products Transducers, 420 Series
0401-404 / D2T-M18SS-EXI	pressure switch
0417-582 8151-PL1-B-D	pressure switch
0122-178	
0601-331 / MT1H-M251S-12-A	temperature switch
28-010099/0111-739	
0111-577/ UNS-VA1/8NPT-K1- VA27/1(2) 1m PVC-Cable	level switch
BPS31EVM3000P	3000p/2SP/7/16E/F
A923R3WQ2-B / TBD	
6922M3HC3	
PN: 0401-116, type: D1T-GM3SS-EXI	Pressure switch
425H3-04-U	Transducer
625H3-16-Z23	PRESSURE TRANSMITTER
B1T-A32SS	HIGH AND LOW PRESSURE SWITCH
0423-126	pressure switch
BT5-H3-04BG-P	
8141-PL1-B/0417-014	
UNS-VA1/8-K2/2-PP19/2(1) / 0111-542	
BPS38GVM0020B	20b/420-2 IOL/G1/4E/F El. pressure switch
E1H-G250-F2-RD	
0221-358 / XT-R12 1250 >= Lm > 1000 LM 1200 mm	
P/N: 0405-318 Type: B2T-M48SS	
P/N: 0401U938 Type: D2T-M80SS-CS	
T2H-H154S-12A	
TC9612-0	pressure switch
0403-531	pressure switch
0712-265.6	
0712-265.7 8-24 I	
BPS344VM0050B	Barksdale device
PT100	
0712-262.2	

Product	Description
C9612-3-W60	Control Products Pressure Switch
P/N: 0221-293, Type: USE3000-VA/T2-ST1-VA52-R12-800 Lo910	
0405-302B2T-M12SS-EXI	pressure switch
KLM-006-G1-S1-1	pressure switch
D2X-A80SS-UL	Explosion-Proof Diaphragm Pressure Switch
P/N: 0111-507, Type: UNS-PA16-PA18-G3/4 5m PVC-Kabel	
T1X-L351S-12-A-EX	
P/N: 0423-117, Type: UDS3V3/10bar/4-20mA EI.	4-way pressure switch
0417-651	pressure switch
C9622-1	
0712-263.9	FLOW DETECTOR
0702-069	FLOW DETECTOR
0702-081	FLOW DETECTOR
0401-224	METAL MEMBRANE PRESSURE SWITCH
999-0121	
UNS-VA1/8-K1-VA27/1(2)HT / 0111-455	
0713-267.10/BFS-30-N-G1-MS-NO-ST	
L96211-BB1SS-S1361	
E1H-H15-Z27	Pressure switch
ML1H-S351S	LOCAL MOUNT TEMPERATURE SWITCH
SST-7200D	
XT-R12 750 >= Lm > 500	
0434-172 / 26.600-1002-R-1-5- 100-200-1-000	pressure switch
0406U527 / 96201-BB3SS-T5	Pressure switch
0631-030	
BT5-H3-10G-P	TRANSDUCER
SST7100 - - I R10	DIGITAL SPEED SWITCH AND TRANSMITTER
0416-181 KLM-025-M4-ST0-1-V	
UNS100-VA/T1-KL6-VA27- L2/1-UL-GE293 Lo500 Gr.1	float switch
371MT73-W400	
TR-DMP333	
0423-118	Pressure switch
M321-A-L4.5-P	
T9692X-1-EE-2-001	
0111-501 / UNS-VA3/8-K3-VA52/1(2) HT	
BPS32PVM3000P	
0112=1943 / UNS1000-MS/T3/4-M12x1	Level sensor
0112=1944 / UNS1000-MS/T3/4-M12x1	
UNS-MS1/8-K5-BN25/3	
6942S3HC3	
BNA-S22 / 0332-540	TRANSMIT CO2 0332-540 BNA-S22 K420806 1/001 G1/4
0111-730 / UNS-VA/SB5-PE33/2 NC	

Product	Description
0431-897 / UPA2-DMP343-100-2500-1-3 TR0-100-000	pressure transmitter
0401-985 / D2X-A3SS-UL	Pressure switch
D1T-H80SS-U	
UNS-VA/G1/8-K2-PP19/1(2) 2m	cable
P/N: 0111-629, Type: UNS-VA/SB1-VA52/3 2m marine cable	float switch
BT5H3 05 BG P	Industrial pressure transducer
0801-138 / 6145R3HC3	Valve
8241-PL1-B-D-LH-PC-GE380	
Pre-setting pressure	
BT5-T9-42BG-P9C	
0406U006 / C9612-2	Pressure switch
0122-328 / UNS1000-MS/T1/2-M12x1 BN18-L2-UL	
Lo501-1000	
C9612-2	Products Pressure Switches, C9622 Series
0631-054	Temperature Transmitter Barksdale UTA2
B1T-S48SS	Switch, Bourdon Tube
9045ROAC3-MC-H	
B1S-S48SS	Switch
D2T-M150SS-L6	Pressure switch
0712-262.5 / BFS-20-OL-G1/2-MS-NO-ST	magnetic flowmeter
E1H-H-90-P6-FX	pressure switch
D2T-M80SS-FX	switch
T2H-M251S-A	switch
BPS342VM0050BP	
0711-257.5 / BFS-10-N-G1/2-MS-NO-ST	Setting 2 - 7 l/min