



ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Bd Sensors

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
P/N: 110-4000-1-5-100-100-1-000, Type: DMP 331	Pressure transmitters
26.600 G-1002-R-1-5-100-200-1-000	Pressure transmitter
26.600 G-1002-R-4-5-100-300-1-000	OEM pressure transmitter 26600 G
730-D-2501-1-5-100-200-1-000	DMD 331 Druckmessumformer
110-2500-E-5-100-F00-1-000	Druckmessumformer DMP 331
DMP 331 Code: 110-D733-1-5-100-F00-1-000	Pressure transmitter
110-M400-3-5-M00-F00 - 1-000	Pressure Transmitter DMP 331
110-4002-E-3-100-C00-1-006 / DMP 331	Pressure Transmitter
DMP 331 Code: 110-4000-3-3-M00-300-1-000	pressure transmitter
DMP 331 Code: 110-6001-3-3-M00-300-1-000	Druckmessumformer
DMP 331 Code: 110-M400-3-5-M00-300-1-000	Druckmessumformer
DMP 333 130-4003-1-3-100-300-5-000	Pressure transmitter
DMP 333 CODE: 130-1003-1-2-100-800-5-000	pressure transmitter
DMP 331 110-4000-3-3-M10-300-1-000	pressure transmitter
600-2502-1-3-G10-100-1-000	Pressure Transmitters
68-D049-K-1-2-1-1-4-2-006-000	Tauchsonde LMK 458
PA 430	sensor
DMP-331 110-1600-1-5-100-100-1-000	PRESSURE TX sensor
DMP 331 Code (aktualisiert): 111-1002-4-3-100-700-1-000	Druckmessumformer
DMP343 100-S250-E-3-M10-300-1-000	PRESSURE TRANSMITTER
LMP 308i	Tauchsonde
DMP 343 100-S050-3-5-100-300-1-000	Druckmessumformer
130-2503-3-3-100-100-5-000	Druckmessumformer DMP 333
DS 200.	Druckmessumformer
PAC-99X - PS32 / USB / UI4 / UI4 / UI4 - 005 - N1	Multichannel Process Display
PAC-141X - PS32 / USB / UI4 / UI4 / UI4 - 005 - N1	Multichannel Process Display
PAC-99X - PS32 / USB / E / E / UI4 - 005 - N1	Multichannel Process Display
PAC-141X - PS32 / USB / E / E / UI4 - 005 - N1	Multichannel Process Display
LMK 351	Einschraubsonde
DMK 351P / Code: 295-D204-1-3-E00-C63-1-1-2-000	Pressure transmitter
100-S050-E-5-M10-300-1-000	Druckmessumformer DMP 343 Ex
26.600 G-1602-R-1-5-100-300-1-070	OEM-Druckmessumformer 26.600G
LMP 308	Tauchsonde
26.600G-1003-R-1-5-100-R40-1-000	OEM-Druckmessumformer
100-S250-E-5-M10-300-1-000	Druckmessumformer

Product	Description
LMK 351 Code: 470-Z030-1-3-100-M00-1-1-2-000	Screw-in probe
26.600G-6001-R-3-5-C10-N40-1-000	OEM Druckmessumformer
787-4003-1-2-5-N01-Z00-1-5-1-000	Elektronischer Druckschalter DS 201P
26.600-G-6001-R -1-5-100-300-1-000	Druckmessumformer
LMK 351	Einschraubsonde LMK 351
DMP 457 Code: 600-2500-E-5-G10-400-1-000	Druckmessumformer DMP 457
DMP 457 Code: 600-6003-E-3-G10-N40-5-070	Druckmessumformer DMP 457
DMP 457 Code: 600-6003-E-3-G10-400-5-000	Druckmessumformer DMP 457
DMP 334 Code: 140-1004-E-3-100-V00-2-000	Druckmessumformer DMP 334
DMP 457 Code: 600-6003-1-3-G10-N00-1-070	Druckmessumformer DMP 457
600-2500-E-5-G10-400-1-000	Druckmessumformer DMP 457
600-6003-E-3-G10-N40-5-070	Druckmessumformer DMP 457
600-6003-E-3-G10-400-5-000	Druckmessumformer DMP 457
140-1004-E-3-100-V00-2-000	Druckmessumformer DMP 334
600-6003-1-3-G10-N00-1-070	Druckmessumformer DMP 457
591-D581-1-B5-TR3-H00-1-1-2-000	Druckmessumformer DMK 457
11C-6002-7-1-100-N00-3-000	Druckmessumformer DMP 320
780-X102-E-1-3-N01-300-1-000	Elektronischer Druckschalter DS 200
M0E-1601-0-B5-0K0-200-1-1-1-1-000	Digitalmanometer BAROLI 02
M0E-4000-0-B5-0K0-200-1-1-1-1-000	Digitalmanometer BAROLI 02
600-1602-E-3-G10-300-1-000	Druckmessumformer DMP 457
M0G-2501-0-B2-0K0-C62-0-1-1-2-000	Digitalmanometer Baroli 02P
110-1002-1-3-100-300-1-000	DMP 331 pressure transmitter
785-LS02-1-1-2-200- C62-1-0-2-000	Elektronischer Druckschalter DS 200P
110-6002-3-3-100-100-5-000	Druckmessumformer DMP 331
110-1002-1-2-100-800-1-000	Druckmessumformer DMP 331
110-2502-1-2-100-800-1-000	Druckmessumformer DMP 331
130-1003-1-2-100-800-5-000	Druckmessumformer DMP 333
130-1603-1-2-100-800-5-000	Druckmessumformer DMP 333
130-2503-1-2-100-800-5-000	Druckmessumformer DMP 333
130-6003-1-2-100-800-5-000	Druckmessumformer DMP 333
DMP-331-110-6001-3-5-1-3-1-000	Druckmessumformer DMP 331
110-M100-3-5-M00-F00 - 1-000	Pressure Transmitter DMP 331
110-M160-3-5-M00-300 - 1-000	Pressure Transmitter DMP 331
430-V152-1-1-3-1-100-3-000	Pressure Transmitter LMP 331
110-V152-3-3-100-300-1-000	TRANSMITTER,PRESS -1TO+1.5BAR 0-10V/3-WI
250-4000-1-5-100-H00-1-B-2-000	Druckmessumformer DMK 331
250-4001-1-5-100-H00-1-B-2-000	Pressure transmitter
DMP331P 500-1000-T2-2-TR1-M95-1-0-1-000	pressure transmitter
Type LMK 331 / Code 460-D172-1-5-TA0-K00-7-B-2-000	LMK 331 screw-in probe
130-1003-2-3-M00-D15-5-520	DMP 333 pressure transmitter
RKT 4-07S +2M KAB	Kabeldose Lumberg RKT-4-07S
LMK 351 Code: 470-1001-1-3-TA0-M00-1-1-2-000	Einschraubsonde
785-1002-1-1-5-TA0-D04-1-1-1-200	Elektronischer Druckschalter DS 200P

Product	Description
110-1302-1-2-100-400-1-000	Druckmessumformer DMP 331
250-1302-1-5-100-H00-1-B-2-000	Druckmessumformer DMK 331
Code: 17.600 G-1002-R-1-5-100-300-P-000	OEM Druckmessumformer 17.600G
17.600G-1002-R-1-5-100- N40-2-000 - OEM for Bd Sensors	Druckmessumformer 17.600G
17.600G-4002-R-1-5-100- N40-2-000	17,600 G pressure transmitter
18.601G-6000-R-1-5-100-N40-1-000	Druckmessumformer 18.601G
18.601G-4001-R-1-5-100-N40-1-000 - OEM for Bd Sensors	Druckmessumformer 18.601G
78H-4000-0-2-3-N01-N00-1-000	Druckschalter DS 200
782-2502-E-1-5-N01-N00-3-1-2-000	Druckschalter DS 201
Nr. 110-M400-3-3-M10-F00-1-000, Typ DMP 331	Pressure transmitter
110-2000-1-5-TR0-H00-1-000	Druckmessumformer
46.606-6001-2-TR0-000	Pressure Transmitter
46.606-1002-2-TR0-000	Pressure Transmitter
46.606-1602-2-TR0-000	Pressure Transmitter
46.606-2502-2-TR0-000	Pressure Transmitter
46.606-4002-2-TR0-000	Pressure Transmitter
LMK 458 768-D049-K-1-2-1-3-4-2-025-000	Tauchsonde
LMK458-768-D290-K-1-2-1-3-4-2-025-000	Tauchsonde
DMP 331 Code - 110-1001-E-3-850-100-1-000	Industrial Pressure Transmitter
18.601G-1601-R-1-5-100-300-3-000	Pressure Transmitter
18.605G-4000-M-1-5-1-006-300-1-000	Tauchfähiger OEM Transmitter 18.605 G
850-1-1-100-1-N-000	Plug-on Display for Current Loop with Contacts
110-M400-3-3-M00-F00-1-000	DMP 331 pressure transmitter
DMP 457	Druckmessumformer
590-V602-E-5-TR3-100-1-1-2-000	Pressure Transmitter
591-1002-E-5-TR3-100-1-1-2-000	Pressure Transmitter
210-1503-1-5-100-N40-2-008	Pressure Transmitter
Code: 500-2501-1-3-100-C61-1-0-2-000	Pressure Transmitter
Code: 17.600G-4002-R-1-5-100-300-P-000	Pressure transmitter
18.601G-1000-R-1-8-100-300-1-000	pressure transmitter
Code: 100-4000-1-5-100-300-1-000	Pressure Transmitter
Code: 100-4000-1-5-100-400-1-000	Pressure Transmitter
Code: 100-0600-1-5-100-400-1-000	Pressure Transmitter
Code: 592-3150-1-5-TR3-100-1-1-2-000	Pressure Transmitter
Code: 110-M400-3-3-M10-F00-1-000	Industrial Pressure Transmitter DMP 331
ILAC-MRA	calibration certificate
Code: 18.601G-1600-R-1-8-100-300-1-000	Submersible Pressure Transmitter
Code: 600-V502-E-3-G10-100-1-000	Pressure Transmitter
DMP 343 (0 ... 100 mbar)	Low-Pressure Transmitter
DMP 343 (0 ... 300 mbar)	Low-Pressure Transmitter
Code: 18.600G-V502-R-1-5-100-400-1-000	ANALOUGE PRESSURE SENSOR1-5 BAR 4-20mA 1/4"
Code: 250-2003-37-5-210-P00-1-1-2-008	pressure sensor
130-4502-2-3-M00-D15-5-520	PRESSURE TRANSMITTER

Product	Description
250-2503-1-5-TR0-400-1-1-2-000 DMK 331	Druckmessumformer
26.600G-1002-R-1-5-100-300-1-000	Pressure transmitter
OXI14B	Wrench
780-6002-1-2-3-N11-500-3-000	sensor
780-1603-1-2-3-N11-500-3-000	sensor
DMD 331/ Code 730-D-1001-1-8-100-200-1-000	Differenz - Druckmessumformer
46.607-3502-2-TR0-055	High-Pressure Transmitter
DMP331 Code:110-1000-1-5-100-F00-1-000	Pressure transmitter
DMP-343 Code: 100-S025-3-5-100-300-1-000	Pressure transmitters
DMP343 Code: 100-S050-3-5-100-300-1-000	Druckmessumformer
DMK 331 250-V152-1-5-100-F00-1-1-2-000	Druckmessumformer
600-1002-1-3-G10-100-1-000	Pressure transmitter
782-4000-1-1-5-N01-F00-1-1-2-000	Pressure Transmitter
730-E-1602-E-8-100-200-1-000	Differential Pressure Transmitter
500-2501-1-3-100-Z00-1-1-2-000	Industrial Pressure Transmitter
DMK 351P / Code: 295-0400-1-3-100-M00-1-1-2-000	Transmitter with flush diaphragm
DMP 331P, Code: 500-1002-1-3-100-Z33-1-1-1-200	Pressure Transmitter
590-1002-E-5-TS3-Z36-1-K-2-000	Submersible Pressure Transmitter
DMP 331 110-M400-3-5-M00-300-1-000	Pressure Transmitter
ZMF2540	Montageflansch
26.600G-V502-R-1-100-300-1-000	26.600 G
DMP 333 130-4003-1-3-100-100-5-000	Industrial pressure transmitter
17.600 G-7003-R-1-5-M10-300-P-000	Pressure Transmitter
18.605G-4000-B-1-5-1-006-300-1-000	Pressure Transmitter
59B-D049-1-2-TR3-H00-1-8-2-000 Type DMK 458	Pressure Transmitter
DMP 331 , code 110-W070-1-3-100-100-1-000	pressure transmitter
DMK 457	Pressure transmitter
18.605G-1001-M-1-5-1-012-300-1-000	OEM pressure transmitter
590-V302-E-5-TS3-Z36-1-K-2-000	DMK 457 pressure transmitter
M04-1602-0-B8-0K0-300-1-2-2-1-000	Digitalmanometer
M00-1602-0-B5-0K0-400-1-1-2-1-000	Digital pressure gauges
470-D736-E-3-M10-M00-1-1-2-000	screw-in probe
LMK 351 471-0400-3-3-M10-M00-1-1-2-000	sensor
600-1602-E-3-G10-300-1-000 Type DMP 457	SENSOR TRANSMITTER SENSOR STRIPPING PUMP
250-6002-1-5-100-400-1-1-2-000 type DMK 331	Pressure Transmitter
250-1003-1-5-100-400-1-1-2-000 Type DMK 331	Pressure Transmitter
381-1001-1-2-1-1-5-1-020-000	level transmitter
LMK 382 Code: 565-2002-1-2-E-1-1-3-010-000	Edelstahl-Tauchsonde LMK 382, inkl. 10m PVC-Kabel
LMP 331, Code: 430-V152-1-1-3-1-100-5-000	Screw-in probe
DMP 331, Code: 110-M160-3-5-M00-300-1-000	Pressure Transmitter
DMP 331, Code: 110-V152-3-3-100-300-1-000	Pressure Transmitter
26.600 G-1002-R-3-5-100-300-1-000	OEM Pressure Transmitter 26.600G
LMK 351 Code: 470-D736-E-3-M10-M00-1-1-2-000	Screw-in Transmitter
26.600 G-4002-R-1-5-100-200-1-000	OEM Druckmessumformer 26.600 G
785-LS02-1-1-2-100-C62-1-0-2-200	Pressure Sensor

Product	Description
17.609 G-3002-R-1-5-M20-U00-2-000	OEM pressure transmitter 17.609G
140-1004-E-3-100-200-2-000	Druckmessumformer DMP 334
17.600G-1002-R-1-5-100-300-Q-000	Pressure Transmitter
110-1602-1-3-100-F00-1-000 (DMP 331)	Pressure Transmitter
DC8-4003-L5-2-207-300-1-000	Druckmessumformer DCT 531
LMP 307 code 450-2501-1-1-1-1-3-1-030-000	Probe
DS 4 (680-1002-1-0-Q00-Q00-5-000-000)	Elektronischer OEM-Druckschalter
380-4000-1-2-E-1-5-1-015-000	Tauchsonde LMK 307
110-1602-1-3-100-500-1-000 (DMP 331)	Industrial Pressure Transmitter
250-5002-1-5-100-500-1-1-2-000 (DMK 331)	Differential Pressure Transmitter
566-1600-1-2-1-1-2-3-005-000	Stainless steel probe
26.600 G-V302-R-1-5-100-300-1-000	pressure transmitter
110 1002E 3 100 C00 1 006	Pressure transmitter
110-4002-E-3-100-C00-1-006	Pressure transmitter
110-2502-E-3-100-C00-1-006	Pressure transmitter
111-1000-12-2-M00-200-1-115	Pressure Transmitter
LMK 331 (Code : 460-2501-1-5-M10-K00-3-B-2-000)	Screw-in
395-2500-R-C-1-1-3-4-010-000	Immersion probe
110-4000-E-5-850-400-1-000	Pressure transmitter
LMK 458 768-4001-K-1-2-1-1-4-2-000	Sensor
DMP 331 (Code: 110-2500-3-5-100-100-1-000)	Pressure transmitter
DMP457-600-6000-1-3-TR3-F00-1-003-000	Pressure transmitter
601-D290-E-3TR3-H00-1-000	Sensor
140-P15K-E-3-850-V00-2-000	industrial pressure transmitter
30.600G Code: 30.600G-4001-R-1-8-100-300-2-1-000	Pressure transmitter
782-4003-E-2-5-N01-N00-5-1-2-000, Type: DS 201	Pressure Switch
26.600 G , Code: 26.600 G-4001-R-1-5-100-300-1-000	Pressure transmitter
DS200 781-1602-1-2-3-N01-F00-1-000	
DS 200 781-2502-1-2-3-N01-F00-1-000	pressure switch DS 200
17.600 G-1603-R-1-5-100-400-2-000	OEM pressure transmitter 17.600G
730-D-6001-E-5-100-200-1-000	DMD 331 differential pressure transmitter
DMP 331 Code: 110-M400-3-3-M00-300-1-000	Pressure transmitter
100-M010-1-5-100-100-1-000, Type: DMP 343	Pressure transmitter
430-D172-1-1-1-1-M00-3-000	Screw-in probe
DMP 331 110-M100-3-5-M00-F00-1-000	Pressure transmitter
411-2500-R-1-1-1-1-5-010-000	Immersion probe
Type: LMP307, P/N: 450-1000-1-1-1-1-5-2-003-000	sensor
110-LS03-E-3-850-400-1-000	Pressure transmitter
26.600 G-2502-R-1-5-100-200-1-000	Pressure Transmitter
DMD 331 Code: 730-F-0400-E-8-100-800-1-000	differential pressure transmitter
451-1600-1-1-E-1-5-3-150-000	Immersion probe LMP 307
451-1600-1-1-E-1-5-3-070-000	Immersion probe LMP 307
DMP 331	sensor
DMP 331P (Code: 500-1601-1-3-100-Z00-1-1-1-000)	pressure transmitter
250-6001-1-5-M10-H00-1-B-2-000	Pressure Transmitter

Product	Description
DMP 343 Code: 100-0600-1-5-100-300-1-000	Pressure Transmitter
DMD 331 (Code: 730-E-2001-E-8-N1F-J00-7-000)	Differential Pressure Transmitter
DMP 304 220-6004-1-5-100-P00-041	Hydraulic Pressure Transducer
LMK 307-308-1001-1-2-1-1-5-1-010-000	LEVEL TRANSMITTER
LMK 307-308-1001-1-2-1-1-5-1-020-000	LEVEL TRANSMITTER
LMK 307-308-1001-1-2-1-1-5-1-045-000	LEVEL TRANSMITTER
DMK 331 / 250-2501-1-5-M10-100-1-1-2-000	Pressure Transmitter
LMP 307	Stainless Steel Probe
DMP331-110-1002-1-3-100-H00-1-000	Pressure transmitter
LMP 331	Pressure sensor
451-1000-1-1-1-1-5-2-003-000 - LMP 307	Pressure Sensor
Conductor for 451-1000-1-1-1-1-5-2-003-000	3-conductor
110-1000-1-5-100-200-3-000	Pressure Transmitter
470-1002-E-3-TR0-M00-1-1-2-000	Screw-in probe
111-2502-ES-3-TR1-200-1-037	Pressure Transmitters
131-6002-ES-3-TR1-200-1-037	Pressure Transmitters
131-2503-ES-3-TR1-200-1-037	pressure transmitter
110-P020-ES-3-TR1-200-1-037	pressure transmitter
131-4003-ES-3-TR1-200-1-037	Pressure Transmitters
26.600 G-2503-R-1-5-100-300-1-000	OEM Pressure Transmitter
100-0500-3-5-100-300-1-000	Pressure Transmitter
250-P5K8-E-5-M10-N40-1-1-2-000	Pressure Transmitter
787-4003-0-2-5-N01-Z00-1-5-1-000	Submersible Pressure Transmitter
780-1602-1-1-3-N01-F00-1-000	Electronic Pressure Switch
787-1003-0-2-5-N01-Z00-1-5-1-000	Electronic pressure switch
18.605G-2500-M-1-5-1-003-300-1-000	Submersible OEM Transmitter
18.605G-1000-M-3-5-1-003-300-1-000	Submersible OEM Transmitter
DMK 458 Code: 59B-D290-1-2-TR3-F23-1-8-2-000	Pressure Transmitters
LMK 458 Code: 768-D290-K-1-C-1-1-4-2-010-000	Submersible probe
DMP 331 110-6001-3-2-TR0-N40-1-000	Pressure Transmitter for Industrial Applications
CIT 750-1-U16-U16-UN5-1-4-100-000	Multi-channel process display
M0E-1002-0-B2-0K0-N40-1-1-1-1-000	Low-Pressure Transmitter
PVC-Kabel	.
785-4000-1-1-3-N01-Z00-1-1-1-000	Submersible Level Transmitter
18.601G-1600-R-1-8-100-200-1-000	Pressure Transmitter for Gas Applications
18.605-2500-B-1-5-1-006-300-1-000	High-Pressure Transmitter for Industrial Use
780-V163-1-2-2-N01-100-1-000	Electronic pressure switch DS 200
DS 200 780-V323-1-2-2-N01-100-1-000	pressure switch DS 200
780-V602-1-2-2-N01-100-1-000	pressure switch DS 200
DAkKS	calibration certificate
DMK 458 59B-D290-1-2-TR1-F23-1-8-2-010	Pressure Transmitter
LMK 307 (380-6000-1-2-1-1-5-1-020-000)	Submersible probe
DS 201 782-1002-0-1-5-100-N00-1-1-2-000	pressure switch
590-6001-1-5-G10-100-1-K-2-000	Pressure Transmitter
590-1002-1-5-G10-100-1-K-2-000	Compact Pressure Transmitter for Liquid Applications

Product	Description
380-1001-1-2-1-1-5-1-020-000	Plunge probe
DMP 331 110-6001-3-3-M10-300-1-000	Industrial Pressure Transmitter for Liquids and Gases
DMP 457 (600-1602-E-3-TR3-100-1-000)	Pressure Transmitters
110-M160-3-5-100-300-1-000	Pressure Transmitter DMP 331
140-1004-E-2-M10-D28-2-000	Transducer
LMP 307 (451-2500-1-1-1-1-5-1-005-000)	Stainless steel immersion probe
UPA2-600b/420/G1/2	High-Pressure Transmitter for Industrial Applications
LMK 307 381-1001-1-2-1-1-5-1-015-000	HYDROSTATIC LEVEL SENSOR
DS 201 (782-4003-E-2-5-N01-100-5-1-2-000)	Electronic pressure switch DS 201
680-6001-1-0-Q00-Q00-5-013-000	OEM electronic pushbutton switch DS 4
26.600 G-1003-R-3-5-100-200-1-000	Pressure Transmitters
110-S102-1-3-100-100-7-000	Sensor
DMK 331, Code: 250-V252-1-5-100-F00-1-1-2-000	Industrial Pressure transmitter
26.600 G-2502-R-1-5-100-300-1-000	Pressure Transmitter 26.600G
26.600G-6001-R-1-5-100-300-1-000 (INPUT 0-10 BAR)	General Purpose Pressure Transmitter
26.600G-6001-R-1-5-100-300-1-000 (INPUT 0-16 BAR)	General Purpose Pressure Transmitter (0-16 Bar)
26.600G-6001-R-1-5-100-300-1-000 (INPUT 0-40 BAR)	General Purpose Pressure Transmitter (0-40 Bar)
26.600G-6001-R-1-5-100-300-1-000 (INPUT 0-60 BAR)	General Purpose Pressure Transmitter (0-60 Bar)
26.600 GJS21-R-1-8-100-N40-1-000	OEM pressure transmitter 26.600 G
LMK 458	plunge probe
DMK 458	pressure transmitter
TPE-U-CABLE	TPE-U Extension Cable for BD Sensors Devices
LMK 351 471-6000-1-3-100-M00-1-1-2-000	Sensor
26.600 G-V502-R-1-5-M20-400-1-000	OEM pressure transmitter 26,600G
LMP 331, Code: 431-2500-1-1-3-1-100-3-000	Screw-in probe
DMK 331 250-1602-3-5-M00-H00-1-B-2-000	Industrial Pressure Transmitter
DMP 331-110-1002-1-3-100-100-1-000	Pressure transmitter
DMP 331 Code:110-1601-1-1-100-300-1-000	Pressure Sensor
DMP331 Code 110-1002-E-3-M00-100-5-000	Pressure Transmitter for Industrial Applications
18601G, Code 1601-R-1-5-100-300-3-000	General Purpose Pressure Transmitter
LMK 487 (366-1000-1-1-C-1-7-4-3-003-502)	stainless steel plunge probe
DM01-A21	display for digital pressure gauge DM 01
26.600 G-V252-R-1-5-100-300-1-000	Pressure transmitter (Normal)
500-6001-1S-3-M10-C62-1-0-2-000	pressure transmitter
380-6001-1-2-1-1-5-3-010-000	stainless steel plunge probe
110-6002-3-2-100-100-1-000	Pressure transmitter DMP 331
250-6002-3-5-100-100-1-1-2-000	Pressure transmitter DMK 331
18.601G-1001-A-3-5-100-100-1-000	OEM pressure transmitter
DMP 331 (110-6001-3-3-100-100-1-000)	pressure transmitter
26.600 G-6001-R-1-5-100-200-1-000	Pressure transmitter
18.601G-2501-R-1-5-100-200-1-000	Pressure transmitter
400-4000-1-1-1-1-5-1-020-000	Probe
DS200 780-4003-E-1-3-N01-100-1-000	pressure switch
DMP331-110-2001-1-2-100-100-1-000	Pressure transmitter
DMP331i-110-2001-1-1-100-100-1-111	Pressure transmitter

Product	Description
DMP331i-110-S100-1-1-100-100-1-111	Pressure transmitter
18.601G-2500-R-1-5-100-300-1-000	Pressure transmitter
LMP307-450-4000-1-1-1-1-5-1-030-000	Submersible probe
46.608-4002-2-TR0-000	Pressure transmitter
250-1002-3-5-M10-F00-1-1-2-000	pressure transmitter
780-1602-E-1-3-N11-100-1-070	pressure switch
780-1003-E-1-3-N11-100-1-070	pressure switch
780-4003-E-1-3-N11-100-1-070	pressure switch
500-V402-1S-3-M10-M76-1-0-2-000	pressure transmitter
600-1602-1-3-G10-100-1-000	pressure transmitter
LMK307 381-4000-1-2-1-1-5-1-010-000	Stainless steel immersion probe
110-2502-3-3-100-C00-1-006	pressure transmitter
110-6001-E-3-100-C00-1-006	pressure transmitter
DMP 333 130-1003-1-3-100-100-5-000	Compact Pressure Transmitter for Low Pressure Measurement
110-V402-1-3-M10-300-3-000	Industrial Pressure Transmitter with High Accuracy
26.600G-Z102-R-1-8-100-200-1-000	OEM pressure transmitter
17.600 G-1002-R-1-5-100-300-Q-070	OEM pressure transmitter
110-2500-1-5-100-100-1-000	pressure transmitter dmp 331
110-1000-1-5-100-100-1-000	pressure transmitter dmp 331
111-1002-3-3-M10-300-1-000	pressure transmitter
P/N: 110-2502-E-3-100-C00-1-006, Type: DMP 331	Transmitter
18.601G	OEM pressure transmitter
17.600 G-4003-R-3-5-100-300-P-000	OEM pressure transmitter
DMP 343 100-2500-E-3-100-200-1-000	Pressure transmitters
DMP 331 110-6001-3-3-M00-300-1-000	Pressure transmitter
LMK307-381-1001-1-2-1-1-5-3-065-000	Stainless steel immersion probe
DMP 331P Code: 501-1601-1-3-100-Z00-1-1-1-200	Pressure transmitter
LMK 307 381-1001-1-2-1-1-5-3-035-000	Submersible Level Transmitter for Water and Wastewater Applications
DMK 458 59A-2500-E-2-G10-200-1-8-2-000	Pressure transmitters
EPS200G14SP12	Pressure sensor
DMP 333 130-6003-1-2-100-500-1-000	Compact Pressure Transmitter for Medium Pressure Measurement
26.600G-V502-R-1-5-100-300-1-000	OEM-Pressure transmitter
DMP 331 110-1001-E-3-100-F00-1-000	pressure transmitter
26.600 G-1002-R-1-5-M20-300-1-000	OEM pressure transmitter
P/N: 110-LS03-E-3-100-N00-1-000, Type: DMP 331	Pressure transmitters
P/N: 110-1002-E-3-100-C00-1-006, Type: DMP 331	Pressure transmitters
P/N: 110-6001-E-3-100-C00-1-006, Type: DMP 331	Pressure transmitters
P/N: 602-6002-1-3-G10-100-1-000, Type: DMP 457	Pressure transmitters
P/N: 110-2500-1-5-100-100-1-000, Type: DMP 331	Pressure transmitters
17.600 G-6001-R-1-B5-100-N40-2-000	Pressure transmitters
P/N: 450-1001-1-1-1-1-3-1-010-000, Type: LMP 307	submersible probe
P/N: 566-6000-1-2-1-1-1-3-010-000, Type: LMK 382	submersible probe
P/N: 111-1002-1-3-100-100-1-000, Type: DMP 331	Pressure transmitters

Product	Description
Code: 381-4000-1-2-3-1-5-1-005-000	Submersible Level Transmitter for Water Applications
115-6002-3-1-100-300-1-000	Industrial Pressure Transmitter for High Accuracy Applications
DMP 331 110-1000-1-5-100-200-1-000	Pressure transmitters
P/N: 130-2503-1-3-100-100-1-000, Type: DMP 333	Pressure transmitters
M0K-1003-0-B1-100-1-000	Precision digital pressure gauges
DMP 457 Code: 600-1602-E-3-TR3-300-1-000	pressure transmitter
500-6001-1-3-100-Z00-1-1-2-000	pressure transmitter DMP 331P
111-1602-1-3-M10-N40-1-000	pressure transmitter DMP 331
111-6001-1S-3-M10-N40-1-000	pressure transmitter DMP 331
LMK 809	submersible probe
26.600G-2502-R-3-5-100-300-1-000	water/air pressure sensor
M00-1002-0-B5-0K0-200-1-1-2-1-000	digital pressure gauge
M0K-2502-0-B1-100-1-000	Pressure transmitter for digital pressure gauge DM 01
M0K-6000-0-B1-100-1-000	Pressure transmitter for digital pressure gauge DM 01
501-1002-1-3-100-C61-1-0-2-205 Type DMP 331P	pressure transmitter
DS200 781-1001-7J-1-3-N11-100-1-000	electronic pressure switch
LMP 307 // 307-451-1600-1-1-E-1-5-3-070-000	stainless steel immersion probe
DMP 321	Pressure transmitter
26.600 G-1002-R-1-8-100-300-1-000	OEM pressure transmitter
Code: 251-2001-1-5-M10-300-1-1-2-000 Type DMK 331	Pressure transmitter
815-0016-3Z-0-G-0-N-Y00-M-000	Differential pressure transducer
Type DMP 331i Code: 110-1002-1-1-M10-200-2-111	Pressure transducer
59A-1602-E-2-TR3-H00-1-8-2-000	Pressure transmitter
DS 210 78A-M250-7-1-3-N01-300-1-000	Electronic pressure switch DS 210
DMP 331 110-M200-1-5-100-300-1-000	Pressure transmitter
DMP331 / 110-V202-1-3-100-100-1-000	PRESSURE TRANSMITTER
DMP343 100-0500-3-5-100-300-1-000	Pressure transmitter
110-6000-E-1-100-F00-1-000	liquid level probe
AX14-DS 201 /782-4003-E-2-5-N01-N00-5-1-2-000	Pressure Transmitter for Hydraulic Applications
111-1002-E-3-850-N00-1-000	Pressure Transmitter for General Industrial Use
111-1002-E-3-880-N00-1-000	pressure transmitter
590-V602-E-5-TS3-Z36-1-K-2-000	Pressure transmitter
441-6000-1-1-1-1-1-5-020-000	stainless steel submersible probe
26.600G-1003-R-3-5-TM0-300-1-000 (OEM)	Pressure transmitter
LMP331 430-0600-1-1-1-1 100-8-000	pressure sensor
18.600G-M250-R-1-5-100-300-1-000	Pressure Transmitter
DMK33112	Industrial pressure transmitter
600-V502-1-3-G10-100-1-000	Pressure transmitter
600-6001-1-3-G10-100-1-000	Pressure transmitter
600-4001-1-3-G10-100-1-000	Pressure transmitter
600-4002-1-3-G10-100-1-000	Pressure transmitter
500-1002-1-2-100-C61-1-0-1-000	Pressure transmitter
450-4000-1-1-1-1-3-1-005-000	level probe
110-6001-1-3-M10-F00-1-000	Pressure transmitter
110-1602-1-3-100-F00-1-000	Pressure transmitter

Product	Description
110-1602-1-3-M10-F00-1-000	Pressure transmitter
110-6002-1-3-100-F00-1-000	Pressure transmitter
DMP 331 110-2502-E-1-850-100-1-000	Pressure sensor
18.601G-0500-R-3-8-100-300-1-000	Pressure probe
18.601G-0500-R-3-8-M20-400-1-000	Pressure probe
DMP331 110-2500-2-5-100-1-006 (U)	pressure sensor
DMP331 / 111-1001-3-3-100-100-1-000	Pressure transmitter
DMP321-115-4003-1 -2-100-N40-1-000	Pressure sensor
18.605G-2500-B-1-5-1-006-300-1-000	OEM submersible pressure transmitter
DMP331i 110-9999-3-1-100-300-1-111	Pressure sensor
DMK 457 590-1602-E-5-TS3-Z36-1-K-2-000	Pressure sensor
Code 500-5001-1-3-100-C62-1-0-2-000 Type DMP 331P	Pressure transmitter
DMP 331 / 110-1600-1-5-TAO-100-1-000	Sensor
Code 330-0600-1-8-M10-Q00-6-000 Type DMD 341	pressure transmitter
Code: 110-6000-E-1-100-F00-1-000 Type DX19-DMP 331	Pressure transmitter
591-2501-1-5-TT3-H00-1-1-2-000	Pressure transmitter
591-1601-1-5-TT3-H00-1-1-2-000	Pressure transmitter
18.605G / 18.605-6000-M-1-5-1-009-300-1-000	Pressure transmitter
590-2502-1-5-TT3-N00-1-1-2-000	High-Pressure Transmitter for Demanding Applications
DMP331 110-1602-1-3-100-F00-1-000	Pressure sensor
DMP331 110-1602-1-3-M10-F00-1-000	Pressure sensor
CIT 400 PH0-F-2-E-6-B-000	display
26.600G-1002-R-1-5-100-300-1-000 (G1/4")	Pressure transmitter
PH0-F-2-E-6-N-000	Process display
DMP 333 130 2503 1 5 100 200 1 000	Pressure Transmitter
DMP 331 110 4002 1 5 100 200 1 000	Pressure Transmitter
DMP 331 110 4001 1 5 100 200 1 000	Pressure Transmitter
DMP 331 110 1002 E 5 100 200 1000	Pressure Transmitter
DMP 333 / 130 4003 E 3 100 200 1 000	pressure transducer
DMP 333 130 7003 E 3 100 200 1 000	Pressure Transmitter
DMP 333 / 130 1003 E 3 100 200 1 000	pressure transducer
DMD 331 Code: 110-2502-E-3-100-C00-1-006	Pressure Transmitter for General Industrial Applications
DMP 331P 500-6001-1S-3-M10-C52	Pressure transmitter
250-4000-1-5-M10-H00-1-B-2-0	Pressure transmitter
250-4000-1-5-M10-H00-1-B-2-000	Pressure transmitter
30.600G-1002-R-1-8-100-N40-2-1-000	Submersible Pressure Sensor for Liquid Level Measurement
LMP331-431-2500-1-1-1-1-100-5-000	Pressure sensor
LPM 331 (431-2500-1-1-1-3-100-5-000)	Screw-in probe
26.600 G-6002-R-1-5-TM0-N40-1-000	Pressure Transmitter
26.600 G-2502-R-1-5-TM0-N40-1-000	pressure transmitter
LMP 307 451-2502-1-1-1-1-1 200-000	Low Pressure Transmitter for Environmental Monitoring
18-605G-6000-M-1-5-1-012-300-1-000	Pressure transmitter
17.600 G-6003-R-3-5-100-300-P-070	Submersible Pressure Sensor for High-Pressure Liquid Measurement

Product	Description
460-6001-1-5-M10-K00-3-1-2-000	Industrial Pressure Transmitter for Process Applications
460-1002-1-5-M10-K00-3-1-2-000	Pressure Transmitter for Low-Pressure Systems
DMP 320 -11C-1003-7-1-100-100-1-000	Pressure sensor
DX14-LMK 351 470-D736-E-3-M10-M00-1-1-2-000	Screw-in probe
30.600G-1003-R-1-8-100-300-2-1-000	Pressure transducer
30.600G-1603-R-1-8-100-300-2-1-000	Pressure transducer
26.600 G-1003-R-1-5-100-300-1-000	Submersible Pressure Sensor for Liquid Measurement
26.600 G-1603-R-1-5-100-300-1-000	Submersible Pressure Sensor for Liquid Monitoring
DMP343 100-d220-1-3-100-100-1-000	Industrial Pressure transmitter
LMK358-446-1001-1-2-H-1-2-1-015-000	Hydrostatic Pressure Sensor for Sewage and Sludge Applications
391-1601A-2-1-1-5-1-020-000	Submersible probe
30.600 G-2502-R-1-8-100-300-2-1-000	Industrial Pressure Transmitter
100-0400-1-5-100-100-1-000	pressure transducer
G-D025-R-1-5-100-H00-1-582	OEM pressure transmitter
18.605G-1001-M-1-5-1-006-300-1-000	OEM pressure transmitter
766-1601-1-3-2-1-1-4-2-003-000	Level probe
766-4000-1-3-2-1-1-4-2-015-000	Level probe
LMK 458 4000-1-3-2-1-1-4-2-015-000	Hydrostatic Pressure Sensor for High-Pressure Applications
LMK 458 766-1601-1-3-2-1-1-4-2-003-000	Submersible Pressure Sensor for Low-Level Monitoring
DX19-DMP 457 / 602-WS03-E-5-TR3-200-1-000	pressure transducer
DMP 333 / 130-2503-E-3-100-200-1-000	pressure transducer
DMP 331 / 110-4002-E-3-100-200-1-000	pressure transducer
DMP 331 / 110-4001-E-3-100-200-1-000	pressure transducer
DMP 331 / 110-1002-E-3-100-200-1-000	pressure transducer
DMP 334 / 140-7003-E-3-100-200-2-000	pressure transducer
250-1601-ES-5-M10-N40-1-1-2-000	DMK 331 pressure transmitter
430-D172-1-1-1-1-M10-3-000	Precision Pressure Transmitter
LMK351 / 470-4001-1-3-TA0-M00-1-B-2-000	screw-in probe
M00-1002-0-B5-0K0-200-1-1-2-N-000	digital pressure gauge
DMP 331 / 110-1002-1S-3-M10-100-1-000	Industrial Pressure Transmitter
17.600 G-1002-R-1-5-M20-400-2-000	17.600G OEM Pressure Transmitter
LMK 358H / 446-1501-1-2-H-1-2-1-040-000	LMK 358H stainless steel submersible probe
DS200 // 780-1603-1-1-3-N01-N00-1-000	Electronic Pressure Switch
LMK 358H (446-1501-1-2-H-1-0-1-000-000	Hydrostatic Level Sensor for Aggressive Media
DMP336-215-1603-1-5-M10-200-2-007	Industrial Pressure Transmitter
DMK 457-590-2503-1-5-TS3-100-1-K-2-000	Pressure Transmitter
TPE-U-Kabel	Thermoplastic Elastomer Cable for BD Sensors Devices
DMK 351P / Code: 295-V902-1-3-M10-C62-7-1-2-000	Sensor
DMP 343 code: 100-0400-1-100-100-000	Low Pressure Transmitter
dmp331 110-4001-1-5-100-500-1-000	sensors
17.600G	Industrial Pressure Transmitter
M00-1001-0-B5-0K0-200-1-1-2-1-000	BAROLI 05 digital pressure gauge
780-4003-E-2-3-N11-100-1-070	pressure switch
500-1602-E-3-100-Z00-1-1-1-000	Submersible Pressure Transmitter
130-4003-E-3-100-100-5-000	High-Pressure Transmitter

Product	Description
450-6000-1-1-1-1-3-1-010-000	Level probe
DMP 331 110-4001-1-3-100-100-3-000	Precision Pressure Transmitter
DMP 331 110-1000-E-5-100-200-2-000	Standard Pressure Transmitter
DMP 331 110-1002-E-3-100-100-1-000	Compact Pressure Transmitter
DMK 351 290-1000-E-3-100-100-1-1-2-007	Differential Pressure Transmitter
600-V502-E-3-G10-100-1-000	Pressure Transmitter
DC7-2501-L5-2-N11-N40-1-000	Submersible Level Transmitter
500-1002-1-2-100-Z00-1-1-1-000	Pressure sensor
DS 200 780-4003-1-1-3-100-200-1-070	electronic pressure switch
DMK 331 / 250-2501-1-5-100-H00-1-B-2-000	Pressure transmitter
LMP 331 / 430-JS49-1-1-E-1-E00-5-818	screw-in probe
DMP 331 P / 501-6001-1-3-100-C61-1-0-2-205	Pressure transmitter
DMP331-110-S102-1-3-100-200-1-000	sensor
26.600 G-X102-R-1-8-100-1-000	General Purpose Pressure Transmitter
780-4003-1-1-3-100-300-1-070	High-Performance Pressure Transmitter
130-1003-E-3-850-N40-5-000 / DMP 333	Pressure transmitter
Code: M0E-2500-0-B2-0K0-N00-1-1-1-1-000	manometer
100-6000-1-3-100-100-1-000	DMP 343 Pressure Transmitter
DMP 343 100-6000-1-3-100-200-1-000	Low Pressure Transmitter
110-1001-1-2-M10-F00-1-000	Pressure transmitter
DMP 343 100-0400-1-3-N00-1-000	Low Pressure Transmitter
590-1002-E-5-G10-100-1-K-2-000	Pressure transmitter
LMP 331/ 430-1000-1-1-1-1-100-1-000	screw-in probe
DMP331-111-2001-7-3-TA0-30 0-1-000	Industrial Pressure Transmitter
366-2500-1-1-C-1-1-4-3-003-000	LMK 487 stainless steel submersible probe
LMK 382/566-1600-1-2-1-1-2-3-005-000	Submersible Level Transmitter
100-D265-1-5-100-100-1-000	Compact Pressure Transmitter
DCT 533-DC2-4000-IO-5M17-200-2-000	Pressure Transmitter
LMK 358 / 446-1601-1-2-1-1-2-3-020-000	Separable stainless steel submersible probe
KL 2 / KL 2-ZB.601-201-000	terminal housing
DMK 331 250-4000-1-5-100-H00-1-B-2-000	Pressure transmitter
470-2500-1-3-M10-M00-1-B-2-000	Submersible Level Transmitter
DMK 331P / 505-6003-E-5-100-Z00-1-1-1-000	Pressure transmitter
110-D558-E-5-100-N00-1-000	Industrial Pressure Transmitter
110-S050-E-5-100-N00-1-000	Compact Industrial Pressure Transmitter
DS201-782-1002-0-1-5-100-H00-3-B-2-000	low pressure switch
566-1001-1-2-E-1-2-3-010-000	Level Sensor
768-D291-1-1-3-2-1-1-4-2-003-000	Submersible Level Transmitter
601-D049-1-3-TR3-F00-1-000	Differential Pressure Transmitter
601-D290-1-3-TR3-F00-1-000	Differential Pressure Transmitter
DMP 331 / 110-M400-1-1-100-300-1-000	Industrial Pressure Transmitter
DMP 331 / 110-4000-1-1-100-300-1-000	High-Pressure Industrial Transmitter
Measurement report 11 points/3 cycles	Measurement Report for Calibration
601-D049-E-3-TR3-H00-3-000	Pressure transmitter
DMP343 100-0100-1-5-100-N40-1-000	Industrial Pressure Transmitter

Product	Description
Type DMK 457 Code 592-6980-1-5-TR3-100-1-1-2-000	Pressure transmitter
Type DMK 457 Code 592-6450-1-5-TR3-100-1-1-2-000	Pressure transmitter
600-1602-E-3-G10-100-1-000	Pressure transmitter
Type DMK 457 Code 592-2501-1-5-TT33-100-1-1-2-000	Pressure transmitter
DMK387-285-2000-1-3-100-L00-1-B-C-000	Precision Differential Pressure Transmitter
LMK 351 Code: 470-0600-3-3-100-M00-3-B-C-000	Hydrostatic Level Transmitter
LMK 307 / 380-6000-1-2-1-1-5-1-015-000	stainless steel submersible probe
46.607-4002-2-TR0-000	Pressure transmitter
XMP i / 511-2002-A0-H-1-AK0-200-1-1-1-000	precision pressure transmitter
DMK 331 250-6002-3-5-100-100-1-1-2-000	Pressure transmitter
110-2502-E-3-100-F00-1-00	Transmitter
18 605G 6000 M 1 5 1 009 300 1 000	probe
DMK 331 / 250-4001-1-5-100-100-1-1-2-000	pressure sensor
LMP 307-451-4000-1-1-1-1-5-1 -003-00R	Submersible Pressure Transmitter for Liquid Level Measurement
381-6000-1-2-1-1-5-1-010-000	Hydrostatic level
600-3000-1-5-TR3-F00-1-000	sensor
YLMP307212TR	Customized Pressure Transmitter for Special Applications
340-2501-1-A0-H-17-AK0-N56-1-1-1-000	XMD differential pressure transmitter
381-4000-1-2-1-1-5-1-006-000	General Purpose Pressure Transmitter
600-4000-1-3-G10-100-1-000	Pressure Transmitter for Industrial Applications
100-0100-1-5-M10-300-1-000 // DMP343	pressure transmitter
DMD 331// 730-E-4001-1-8-100-200-1-000	differential pressure transmitter
DMP 331P (501-2501-3-3-TA0-Z00-1-7-1-200)	Pressure transmitter
DMD 331-730-F-1000-E-5-100-J00-1-000	
LMK351-471-2500-1-3-100-M00-1-1-2-000	Screw-in Transmitter
592-9740-1-5-TR3-100-1-K-2-000	PRESURE MEASUREMENT
59C-9740-1-2-TR3-H00-1-K-2-000	PRESURE MEASUREMENT
59C-6550-1-2-TR3-100-1-8-2-000	PRESURE MEASUREMENT
DMK 458-59C-9740-1-2-TR3-H00-1-K-2-000	
DMK 458-59C-6550-1-2-TR3-100-1-8-2-000	
26.600 G-1602-R-3-5-100-300-1-000	
DMK 331P / 505-1603-1-5-200-Z00-1-1-1-200	pressure transmitter
766-2001-1-1-2-E-1-4-2-025-000	
LMK 351 Code: 470-2501-1-3-TA0-M00-1-1-2-000	screw-in probe
LMP307 Code: 450-4000-1-1-1-1-5-1-006-000	Level probe
M01-1002-0-B5-0K0-N00-1-1-2-1-000	Pressure switch
30.600G-6002-R-1-8-100-300-2-1-000	
266182 / 26600 G 6002-R-1-5-100-400-1-000	
DMP 331 110 4002 E 3 100 C00 1 006	PRESSURE SENSOR
DMP 331 110 2502 E 3 100 C00 1 006	Pressure sensor
18.601G-S102-R-1-5-M20-300-1-000	OEM pressure transmitter
LMK 807 / 391-1601-RA-2-1-1-5-1-020-000	
LMK 807 391-1601-R-2-1-1-5-1-020-000	
DMP 331 110-M400-3-5-M00-F00-1-000	
110-M400-3-5-M10-F00-1-000	

Product	Description
DS200 780-1603-1-1-3-N01-100-1-000	Electronic pressure switch
110-M400-3-5-M10-300-1-000	
DMK 331P 505-1002-1-5-100-Z00-1-1-2-000	
DMP 321 - 115-1002-3-2-100-100-1-000	Pressure transmitter
505-L010-E-5-170-Z00-1-7-1-200	
850-E-0-100-4-1-000	
511-S102-A0-I-1-AK0-N00-1-1-1-000	XMPi Precision Pressure Transmitter
511-1002-A0-I-1-AK0-N00-1-1-1-000	XMPi Precision Pressure Transmitter
CIT 400 / PH0-H-2-S-5-N-000	Process display
685-2003-2-0-M13-300-1-000-000	DS 6 OEM electronic pressure switch
DMK457 / 592-6980-1-5-TR3-100-1-1-2-00	Pressure transmitter
DKM457 / 592-6450-1-5-TR3-100-1-1-2-00	Pressure transmitter
18.601G-6000-R-1-5-100-100-1-000	pressure transmitters
LMK 307 / 380-6000-1-2-1-1-5-1-010-000	
18.601G-1002-R-1-5-100-100-1-000	OEM pressure transmitter
DMP 320 11C-2503-7-1-100-300-1-000	precision pressure transmitter
26.600 G-1601-R-1-5-100-300-1-000	Pressure transmitter
26.600G-2503-R-3-5-100-300-1-000	PRESSURE TRANSMITTER FOR WATER MAKER
26.600G-1603-R-3-5-100-300-1-000	SENSOR
26.600 G-2503-R-6-5-TM0-300-1-000	
M0G-6001-0-B5-0K0-C62-0-1-1-2-000	Sensor
M0E-2500-0-B5-0K0-N00-1-1-1-1-000	
78H-4000-0-2-5-N01-N00-1-000	
17.600 G-2502-R-1-5-100-300-Q-000	
DMK457/590-V252-1-5-TR3-F-00-1-1-2-000	Pressure transmitter
LMK 307 / 381-4000-1-2-3-1-5-1-005-000	probe
DMP 457 600-V152-1-3-G10-300-1-000	Pressure sensor
DMP 457 600-1602-1-3-G10-300-1-000	pressure sensor
470-D736-E-3-M10-M00-1-1-C-000 / LMK 351	screw-in probe
DMP 320 11C-6003-7-1-M10-100-1-000	DMP 320 precision pressure transmitter
685-6003-1-0-M13-300-1-000-000	DS 6 OEM electronic pressure switch
110-2501-E-3-100-100-1-000	
110-6000-E-3-100-100-1-000	
17.600 G-2503-R-3-5-100-300-P-000	Pressure Sensors
460-6000-1-5-M13-K00-1-B-2-000	
LMP 307 / 451-3000-1-1-1-1-5-1-005-000	
LMK 307 (381-4000-1-2-1-1-5-2-033-503)	Stainless steel submersible probe
450-2500-1-1-1-1-5-1-0-10-000	
DMP331i 110-S400-1-1-A00-200-1-121	
DMK 457 / p/n 592-9740-1-5-TR3-100-1-K-2-000	
DMP331i 110-V103-1-1-A00-200-1-121	
LMP307-451-0600-1-1-1-1-5-1-002-000	
YDMP33112ABS GE	Sensor
M00-V403-0-B5-0K0-200-1-1-2-1-000	
DMP333 / P.N 130-1003-ES-2-100-300-1-000	

Product	Description
DMP 333 / G1/2" DIN 3852	
DMP343 100-JS9R-2-3-100-300-1-000	
DMP 331P/500-P300-1-3-M13-Z61-1-1-1-03P	Pressure transmitter
396-0600-R-C-3-1-2-3-001-000	
501-2001-ES-2-100-S12-1-0-1-000	
DMK 331 251-1002-3-5-100-100-1-1-2-000	
DMP321 / 115-1002-1-1-100-N00-1-000	Pressure sensor
DPS 200 / 811-0060-7-G-0-N-Y00-M-000	
UPA51-30.600-4003-R-1-8-100-300-2-1-000 (BD Sensors)	
110-4000-1-3-TR0-H00-1-000	
DMP331 110-4000-3-3-M00-300-1-000	
DS 233 335-1000-7-1-8-N01-Q00-6-000	
DS 210 78A-1000-7-1-5-N01-300-1-000	
DS 210 78A-2500-7-1-3-N01-300-1-000	
DS 210 78A-M100-7-1-5-N01-300-1-000	Electronic pressure switch DS 210
10544361 / 686-1001-2-0-M13-300-1-000-000	Sensor
DMP 331 / 110-1002-1-3-850-200-1-0	Gage
600-1602-E-3-TR3(2m)-100-1-000	
LMK351 470-1001-1-3-TA0-M00-1-1-2-000 / 0...1Bar	Screw-in probe
DMK331 250-2502-1-5-10-H-1-B-3-000 / 0...25Bar	Pressure transmitter
DMK331 0...6BAR / 250-6001-1-5-100-H 00-1-B-2-000	Pressure transmitter
DMD331-730-E-1602-1-5-100-200-1-000	
DMP 331P 501-2501-3-3-TAO-Z00-1-7-1-200	Pressure transducer
500-4000-1-3-M10-ZS0-1-1-1-000	
600-4001-1-3-G00-100-1-000	DMP 457 Pressure transducer (Hold CSW Disch Pressure Sensor)
DS 200 780-V253-1-2-2-N01-100-1-000	
DS 200 780-1600-1-2-5-N01-100-1-000	
TTR4	
DMK 331-251-1001-3-5-100-100-1-1-2-000	
500-6001-1-3-100-C61-1-0-2-205	Pressure transducer
DMK331 / Code: 250-S500-1S-5-100-100-1-1-2-000	
111-2501-1-1-M10-400-3-000	Pressure transmitter
566-1600-1-C-1-1-1-3-003-000	
DMP 331 110-1000-1-5-100-N40-1-000	Pressure transducer
78R-1002-7-1-G-N11-300-1-000	
17.600 G-1002-R-1-5-100-N40-2-000	Pressure transmitter
18.605G	pressure sensor
470-1601-1-3-100-M00-3-R-C-000	
780-4002-E-2-3-N11-100-1-070	
780-4001-E-2-3-N11-100-1-070	
250-4003-E-5-100-H00-1-1-2-000	
850-E-1-100-1-1-000	