



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. İhlamur Bul. Ağaoğlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA,PUE
www.enapart.com.mx
sales@enapart.com.mx



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREŞTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

BDC

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
<u>ALS10/4609AKS-B</u>	Speed sensor
<u>C8B/0045PVG</u>	BDC 4 WIRE CORNER CONNECTOR
<u>DCA12/5609KS</u>	INDUCTIVE SENSOR
<u>DCA 18/4309KS</u>	INDUCTIVE SENSOR
<u>DCA18/4B08KSH2-0.240</u>	INDUCTIVE SENSOR CABLE M.0,17
<u>DCA12/5629KS</u>	INDUCTIVE SENSOR
<u>DCA8/4609KS</u>	INDUCTIVE SENSOR
<u>DCA8/5909KS</u>	Inductive sensor
<u>DSE12/4309KS</u>	sensor
<u>DCA5/5B09KS</u>	Inductive sensor
<u>DCA12/4609KST-0.12</u>	INDUCTIVE TEMPERATURE SENSOR
<u>DSE6.5/4619LKS</u>	inductive sensor
<u>DSE8 / 4609KS</u>	Induktiver Sensor
<u>DC12/5600-3 optional</u>	
<u>DCA30/4609KS</u>	Sensore induttivo
<u>DCA12/4609KS</u>	Inductive proximity sensor
<u>DCA5/5919KS</u>	INDUCTIVE SENSOR
<u>DC12/5600</u>	INDUCTIVE SENSOR
<u>ALS10/4609AAKS23676/4 / new version ALS10/4609AKS-B</u>	Rotary sensor
<u>DCA8/4309KT</u>	INDUCTIVE SENSOR
<u>DCA12/5608NKS</u>	INDUCTIVE SENSOR
<u>DCE12/43C9KT</u>	INDUCTIVE SENSOR
<u>DCA5/4909KS</u>	INDUCTIVE SENSOR
<u>DCA8/5919KS</u>	SENSORE INDUTTIVO
<u>DCA 12/4309KS</u>	INDUCTIVE SENSOR
<u>DCA18/5609KSJ</u>	INDUCTIVE SENSOR
<u>DCA18/4609KT</u>	LIMIT SWITCH (INDUCTIVE SENSOR)
<u>DCAT/4729KS</u>	sensor
<u>DCA30/4629KS</u>	sensor
<u>DCA5/4609KS</u>	INDUCTIVE SENSOR
<u>DCA30/4619KT</u>	Inductive sensor
<u>DCA 12/4309KST</u>	Homing Sensor
<u>BRS12X/4609KJ</u>	Speed sensor
<u>ERB1109500R</u>	Encoder
<u>0736237369B</u>	Limit Switches
<u>0736237350A</u>	



Product	Description
<u>DCA18/4609KS</u>	Inductive sensor
<u>ERB119500R</u>	Encoder
<u>ERB1000200E</u>	Encoder
<u>DCAY/4609KS</u>	Inductive sensor
<u>DCZ/5600</u>	Inductive sensor
<u>C11/0045PVG</u>	Connector
<u>C8B/00410PRN</u>	BDC 4 WIRE CORNER CONNECTOR
<u>C8B/00410PVG</u>	BDC 4 WIRE CORNER CONNECTOR
<u>C8B/0045PRN</u>	BDC 4 WIRE CORNER CONNECTOR
<u>DCA18/4629KS</u>	INDUCTIVE SENSOR
<u>DC12/5600A</u>	INDUCTIVE SENSOR
<u>DCA8/4908KS</u>	Inductive Sensor
<u>DCA8/4918KS</u>	Inductive Sensor
<u>DSA8/4909KS</u>	Inductive sensor
<u>DCA18/4A09KSJMA</u>	INDUCTIVE ATEX SENSOR
<u>DCA18/4A09KSJMB</u>	INDUCTIVE ATEX SENSOR
<u>DCA12/5608KSC2-07</u>	INDUCTIVE SENSOR
<u>DCA5/5909KS</u>	INDUCTIVE SENSOR
<u>DCA12/5608KS</u>	sensor
<u>C12/0032PRN</u>	Sensor cable
<u>0736237351C</u>	SINGLE PROXIMITY LIMIT SWITCH
<u>DCA18/5609KS</u>	INDUCTIVE SENSOR
<u>DSA8/4609KS</u>	INDUCTIVE SENSOR
<u>DSA30/5308KS</u>	INDUCTIVE SENSOR
<u>DCA30/4629KT</u>	INDUCTIVE SENSOR
<u>AC18/4609S</u>	INDUCTIVE SENSOR
<u>DCA12/43C9KT</u>	INDUCTIVE SENSOR
<u>DCA8/4608KS</u>	INDUCTIVE SENSOR
<u>2736240995F</u>	SINGLE PROXIMITY LIMIT SWITCH
<u>DCX/4700</u>	INDUCTIVE SENSOR
<u>DCA 12/4609KSMB-10</u>	
<u>DCA12P/5609KSJ-10PR</u>	
<u>DCA8/4609KT</u>	INDUCTIVE SENSOR
<u>BMS12/4609KS</u>	
<u>PVC CABLE SUPPLEMENT</u>	
<u>BKS30S/4329KS</u>	
<u>DC12/5600 KS</u>	
<u>DCAE12/4309KS</u>	
<u>DCAE8/4609KS</u>	
<u>DCA30/5609KSTB3GD - 5</u>	
<u>SUPP.CAVO TEMP.</u>	
<u>DCA8/4309KS</u>	