



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Ağaoğlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Carel

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">SPKT0031C0</a>	Pressure transmitters Carel, 0/30 bar, 4-20 mA
<a href="#">BLCT2C00W2</a>	Carel disposable steam cylinder
<a href="#">BLCT4C00W2</a>	Cylinder
<a href="#">CONVONOFF0</a>	Conv.Pwm uscita rele'in scamb
<a href="#">BL0T1CW0H2 -OEM</a>	Steam Cylinder for Humidifiers
<a href="#">DPPT011000</a>	Temperature (-20t70 °C) (output carel ntc sensor only)
<a href="#">DPWT011000</a>	Temperature Sensor
<a href="#">E4V85AST00</a>	Electronic expansion valve e4v-85 28- 35 odf with sight glass
<a href="#">EVD0000E20</a>	TRV Driver
<a href="#">EVD0000E50</a>	Driver for TVs
<a href="#">FCS3404010</a>	controller
<a href="#">IR33F0EN00</a>	temperature Regator
<a href="#">IR33S0EA00</a>	temperature controller
<a href="#">IR33W7LR20</a>	IR33 Universal Controller
<a href="#">IR33W9MR20</a>	Electronic Controller
<a href="#">IR33Z7HR20</a>	temperature regulator
<a href="#">IR33Z9MR20</a>	Controller
<a href="#">KITVC00006</a>	Valve
<a href="#">MCH2000010</a>	Controller for a refrigeration machine
<a href="#">MCH2000020</a>	Expansion module for MC2
<a href="#">MCHSML0010</a>	Term.MCH small opz.lr+b
<a href="#">NTC030WH01</a>	Temperature sensor
<a href="#">NTC120WH01</a>	Temperature sensor
<a href="#">NTC002HPRR</a>	Sensor ntc hp 15cm red con.Jst pck.50Pcs
<a href="#">NTC015HP00</a>	Temperature Sensor
<a href="#">NTC015WH01</a>	Temperature sensor
<a href="#">NTC060HF01</a>	Sensor
<a href="#">NTC060WF0</a>	Temperature sensor
<a href="#">NTC120WP00</a>	temperature sensor
<a href="#">CRL-PCO3000AS0</a>	controller
<a href="#">PCO3CON0L0</a>	Terminal
<a href="#">RSF077D000</a>	Liquid phase control
<a href="#">P+500B0A000S0</a>	Controller
<a href="#">PCOE004850</a>	Expansion card
<a href="#">CRL-PJEZS0G000</a>	Temperature Controller
<a href="#">PJEZS0H000</a>	Refrigeration controller

Product	Description
<a href="#">PJEZS0P000</a>	PJEZ base model
<a href="#">SPKC002300</a>	cable
<a href="#">SPKC005310</a>	Cable
<a href="#">SPKT0021D0</a>	-0.5 To 7 barg (-8 to 100 psig)
<a href="#">TCONN6J000</a>	"T" connector for local network
<a href="#">URKTR10000</a>	Transformator
<a href="#">PGD1000FW0</a>	
<a href="#">CRL-UU01FD0000</a>	ULTRASONIC HUMIDIFIER FOR FAN COIL
<a href="#">CRL-DPWC110000</a>	Temperature Sensor
<a href="#">DPWC111000</a>	Temp. Sensor
<a href="#">EVBAT00100</a>	Carel Rechargeable battery module
<a href="#">EVD0000UC0</a>	Ultracap module for evdevo
<a href="#">3307740</a>	KÜHLMODUL 1500W 400/460V, 3~, eComfortcontr
<a href="#">EVD0000E30</a>	Driver For TPB
<a href="#">IR33W7HR20</a>	2xNTC/PTC/PT1000 Input 2 Relay Output 115-230Vac
<a href="#">EVD0000T50</a>	EVD Evolution Twin
<a href="#">E2V14BSF00</a>	Electronic expansion valve e2v-14b 12-12 odf
<a href="#">MX30M25HO0</a>	Electronic Control
<a href="#">IR00UGC300</a>	TERMINAL GREEN LED
<a href="#">IR33Z7LR20</a>	Thermo Regulator
<a href="#">P+50CON0S0</a>	Clemored
<a href="#">PCO1CON0M0</a>	Clemore
<a href="#">PGDT04000F020</a>	user terminal
<a href="#">PCO3CON0M0</a>	Terminal block
<a href="#">EVD0000400</a>	Driver for electronic expansion valve
<a href="#">EVD0000E00</a>	Universal controller
<a href="#">UE005YL001</a>	Immersed Electrode Steam Humidifier
<a href="#">MCH2000000 obsolete</a>	Controller For Refrigeration Machine
<a href="#">CRL-ASET030000</a>	TEMPERATURE PROBE
<a href="#">PGD0000W00</a>	Display
<a href="#">PCOS004850</a>	Communication board
<a href="#">PCO100CLK0</a>	Real time clock board
<a href="#">PC0B000B21</a>	fixed screw
<a href="#">PCO3000BL0</a>	controller
<a href="#">CRL-PCO3000AM0</a>	pCO <sup>3</sup> control board without display/panel
<a href="#">Control terminal</a>	User Interface for Carel Controllers
<a href="#">PCO1CON0X0</a>	Screw Terminal Version For pCOXS
<a href="#">FLOS000000</a>	Pinhole sensor
<a href="#">E2V30BSM00</a>	Electronic Expansion Valve
<a href="#">E2VCABS300</a>	Shielded cable and connector
<a href="#">PGD1000F00</a>	pCO Graphic Display Terminal
<a href="#">NTC008WH01</a>	temperature sensor
<a href="#">MCHSMLCAB2</a>	Kit 24cavi x mch-mpx l=2mt. Sez.1Mmq.
<a href="#">IR33 - IR33W7HR20</a>	Electronic Controller
<a href="#">MCH2001030</a>	Controller

Product	Description
<a href="#">MCH200TW00</a>	µC2 remote terminal for wall-mounting + power supply module
<a href="#">98C615P004SP</a>	Adapter
<a href="#">6021350010</a>	pCO3 Programmable Controller
<a href="#">UE015XL001</a>	humiSteam
<a href="#">UE025XL001</a>	humiSteam
<a href="#">MCHSMLCAB0</a>	Control cable
<a href="#">MCHSML4200</a>	Transducer
<a href="#">PCO3003AL0</a>	Controller
<a href="#">BL0S3F00H2SP</a>	Cylinder
<a href="#">BL0T1C00H2SP</a>	cylinder
<a href="#">DPDC110000</a>	CHANNEL SENSOR TEMPERATURE
<a href="#">Type: UE008YL001</a>	Humidifier HumiSteam 8 kg / h
<a href="#">Type: UCHUMM0000</a>	Mechanical Humidistat
<a href="#">NTC060WH01</a>	temperature sensor
<a href="#">DN33Z7HR20</a>	4 Relays version, 115 to 230 Vac
<a href="#">SPKT0011D0</a>	pressure transducer
<a href="#">IR33C7HR00</a>	temperature controller
<a href="#">KITVC10058SP</a>	Fill valve kit
<a href="#">MD 33D0EN00</a>	pCO Sistema Programmable Controller
<a href="#">PCO3CONOLO</a>	pCO3 I/O Board
<a href="#">S90 CONNOO2</a>	Connection Cable for pCO Controllers
<a href="#">BL0T5C00H0</a>	cylinder
<a href="#">PCO100KEY0</a>	Programming key
<a href="#">PCOS00AKC0</a>	Usb key adapter
<a href="#">TABASE7000</a>	main control board
<a href="#">1312367AXX</a>	steam hose
<a href="#">1312365AXX</a>	Hose for BL0T3C00H2
<a href="#">BLCT2D00W2SP</a>	cylinder humidifier
<a href="#">IR33V7LR20</a>	Contoller
<a href="#">PC03000EL0</a>	PLC
<a href="#">PCO3000EL0</a>	Controller
<a href="#">PZSTSOG001K</a>	Temperature and Humidity Sensor
<a href="#">CVSTDUTTLO</a>	converter
<a href="#">DPPC111000</a>	Temperature humidity sensor
<a href="#">SPKT00F3R0</a>	0 To 5 Vdc, 0 to 20.7 Barg (0 to 300 psig)
<a href="#">PCO3000BS0</a>	Controller
<a href="#">MCH2004850</a>	RS485 serial card for panel version
<a href="#">FCSER00000</a>	serial card
<a href="#">NTC008HP00</a>	IP67, 0.8 M cable, -50t105 °C (on air)
<a href="#">UEI0000000</a>	Input / Output Interface
<a href="#">KITBLCT3C0</a>	Electrode
<a href="#">PJEZS0G000</a>	Electronic Controller
<a href="#">3396282</a>	SK Display
<a href="#">PJEZC00000</a>	Electronic Controller
<a href="#">MD33D0EB00 / C1101189</a>	Programmable Controller for Refrigeration Applications

Product	Description
<a href="#">MD33D5EN00</a>	MasterCella PID Temperature Controller
<a href="#">PJEZC0H000</a>	refrigeration controller
<a href="#">BL0T3C00H2</a>	Cylinder
<a href="#">NTC030HT00</a>	Sensor
<a href="#">BL0T2C00H2</a>	Cylinder
<a href="#">NTC015HT41</a>	Thermo Sensor -IP55
<a href="#">BL0T1C00H1SP</a>	Cylinder
<a href="#">PCOS00AKY0</a>	Program Key
<a href="#">CHKDIST000</a>	Distributor Kit
<a href="#">CHKFV02001</a>	Fill Kit Drain Tempering Valve
<a href="#">CY0S1A0000</a>	Cylinder 1.5-2.5Kg/H 110V 1Ph Mod.A
<a href="#">CY0S1C0000</a>	Cylinder 1-5.4Kg/H 230V 1Ph Mod. C
<a href="#">S90CONN003</a>	Cable l= 6 m, telephone connectors
<a href="#">L201MA0000</a>	Steam Cylinder
<a href="#">SDPOEM0022</a>	nozzle
<a href="#">SHOSE00030</a>	Rubber Steam Hose, 30 MM
<a href="#">KITVCCN000</a>	Fill Tank With Conductivity Meter
<a href="#">1413107AXX</a>	Bottom Sump
<a href="#">9995643ACA</a>	Drain Valve
<a href="#">DPWC112000</a>	Wall Mount Temperature Sensor
<a href="#">E201MA0000</a>	Steam Cylinder
<a href="#">E401TA0000</a>	cylinder
<a href="#">F201MA0000</a>	cylinder
<a href="#">K400TA0000</a>	Cylinder
<a href="#">KITCN00000SP</a>	Conductivity Meter Kit
<a href="#">KITPS0SZ00</a>	Drain Pump
<a href="#">KITVC00100</a>	Fill Valve Kit
<a href="#">UEKTAM0000SP</a>	Universal current transformer (TAM)
<a href="#">URKCONT300</a>	Contacteur
<a href="#">1312113AXX</a>	Connector
<a href="#">ECKFSV0000</a>	Fill Valve Kit
<a href="#">UAKDS33000</a>	Drop Separator
<a href="#">UAKDS35000</a>	Drop Separator
<a href="#">UAKDS43000</a>	Drop Separator
<a href="#">UAKDS45000</a>	Drop Separator
<a href="#">UAKDS53000</a>	Drop Separator
<a href="#">UAKDS55000</a>	Drop Separator
<a href="#">UAKVGX1800</a>	Ultracapacitor Module for Energy Storage
<a href="#">UC10KDS000</a>	disk for humiDisk 10
<a href="#">UCKETV0000</a>	Solenoid Valve
<a href="#">0203007AXX</a>	Contacteur
<a href="#">10C615A235</a>	Harness Kit
<a href="#">BL0S1E00H1SP</a>	Steam Cylinder
<a href="#">BL0T1D00H1SP</a>	Cylinder
<a href="#">BL0T2A00H0</a>	Steam Cylinder

Product	Description
<a href="#">BL0T2B00H0</a>	Cylinder
<a href="#">BL0T3B00H0</a>	Steam Cylinder
<a href="#">BL0T4D00H0SP</a>	Steam Cylinder
<a href="#">BLCT2B00W0</a>	Cleanable Steam Cylinder
<a href="#">BLCT2C00W0</a>	Cylinder
<a href="#">BLCT2D00W0</a>	Cleanable Steam Cylinder
<a href="#">HCT1EXW000</a>	Display Terminal
<a href="#">KITVC00040</a>	Fill Valve Kit
<a href="#">KITVC00070</a>	Fill Valve Kit
<a href="#">PGD0PH0F00</a>	pGD0 120x32 pixel phc umid, panel mounting
<a href="#">UEKCOLL000SP</a>	Fill/drain manifold 25 to 130 kg/h
<a href="#">UEKDH00000SP</a>	Drain Pump Hose
<a href="#">HCT1EXF000SP</a>	Display Terminal
<a href="#">HCTREW0000SP</a>	Display
<a href="#">KITVC10070SP</a>	Fill Valve
<a href="#">KITVC10140SP</a>	Fill Valve
<a href="#">UEHxxv0000</a>	Control Module
<a href="#">UEKDC00000SP</a>	Drain Circuit
<a href="#">UEKDRAIN02</a>	Drain Pump kit
<a href="#">UEKT20000S</a>	Hydraulic Pipes Kit
<a href="#">UEX10M0010</a>	Controller
<a href="#">KITDTEXT06</a>	Text Display Kit for pCO Controllers
<a href="#">UGKFC00090</a>	Combuster Ventilator Kit
<a href="#">UGKGUAG090</a>	Gas Gasket Kit
<a href="#">URKFLAN000</a>	Front cover kit with gasket for UR rev. 1
<a href="#">URKFS00000</a>	Anti-Foaming Sensor
<a href="#">BLCS1F00W2</a>	Cleanable Steam Cylinder
<a href="#">KITPSR0000</a>	Drain pump kit for UR from 20 to 60 rev. 1
<a href="#">KITVC00012</a>	Valve
<a href="#">THP00A0000</a>	thermostat
<a href="#">URKBR00000</a>	Cylinder Cover Locking Clamp
<a href="#">URKF0000XL</a>	Boiler filter kit UR020 to UR060
<a href="#">URKFH20000</a>	Fuse Holder Kit
<a href="#">URKFLOAT00SP</a>	Level Sensor Kit
<a href="#">URKFUSE700</a>	Fuse Kit
<a href="#">URKFUSE800</a>	Fuse Kit
<a href="#">URKG100000</a>	Boiler Gasket Kit
<a href="#">URKH00A322</a>	Heater Kit
<a href="#">URKKL00000</a>	Thermostat
<a href="#">URKKL20000</a>	Thermoprotector Kit
<a href="#">URKNTC0000</a>	NTC Probe
<a href="#">URKPTCS020</a>	PTC Probe
<a href="#">URKTB00000</a>	Terminal Cable Kit
<a href="#">URKTR20000</a>	Transformer
<a href="#">UEY45M0200</a>	ELECTRONIC CONTROLLER



Product	Description
<a href="#">UUKAX00000</a>	Optional Card
<a href="#">UUKCY00000</a>	Conveyor
<a href="#">UUKDE00000</a>	Driver
<a href="#">UUKDI00000</a>	Display Terminal
<a href="#">UUKTP00000</a>	Transducer
<a href="#">1309589AXX</a>	Compression fitting for cap diam.= 6 Mm, 1/4" gas
<a href="#">ADPH003000</a>	Ambient Display Terminal
<a href="#">ASET030001</a>	active temperature probe
<a href="#">CVSTDUTLF0</a>	Converter - USB/RS485
<a href="#">DN33Z7LR20</a>	4 Relays version, 12 to 24 Vac (12 to 30 Vdc)
<a href="#">DPDC111000</a>	Humidity Sensor
<a href="#">DPDC112000</a>	Temperature (-10t60 °C) and humidity (10 to 90% rh)
<a href="#">DPDC114000</a>	Duct-Mounted Temperature and Humidity Sensor
<a href="#">DPDC210000</a>	Humidity Sensor
<a href="#">DPDC212000</a>	Temperature (-20t70 °C) and humidity (0 to 100% rh)
<a href="#">DPDC214000</a>	Temperature (-20t70 °C) and humidity (0 to 100% rh)
<a href="#">DPDT010000</a>	Temperature (-20t70 °C)
<a href="#">DPDT014000</a>	Temperature (-20t70 °C)
<a href="#">DPPC110000</a>	AMBIENT SENSOR TEMPERATURE FOR INDUSTRIAL ENVIRONMENTS
<a href="#">DPPC11100N</a>	Temperature Sensor
<a href="#">DPPC112000</a>	Temperature (-10t60 °C) and humidity (10 to 90% rh)
<a href="#">DPPC114000</a>	Temperature Sensor
<a href="#">DPPC212000</a>	Temperature (-20t70 °C) and humidity (0 to 100% rh)
<a href="#">DPPC214000</a>	Outdoor Temperature and Humidity Sensor
<a href="#">DPPT010000</a>	Temperature (-20t70 °C)
<a href="#">DPPT014000</a>	Temperature (-20t70 °C)
<a href="#">DPUC110000</a>	temperature and humidity sensor
<a href="#">DPUT011000</a>	temperature sensor
<a href="#">DPWC110000</a>	wall sensor
<a href="#">DPWC11100N</a>	temperature Sensor
<a href="#">DPWC114000</a>	Wall Mount Temperature Humidity Sensor
<a href="#">DPWC115000</a>	Temperature Sensor
<a href="#">E2V05BS000</a>	Electronic expansion valve e2v05-b 10-10 s.Stell
<a href="#">E2V05BSF00</a>	Electronic expansion valve e2v05-b 12-12 odf
<a href="#">E2V05BWB00</a>	Electronic expansion valve e2v05-b 3/8"-1/2" odf
<a href="#">E2V09BSF00</a>	Electronic expansion valve e2v09-b 12-12 odf
<a href="#">E2V11BSF00</a>	Electronic expansion valve e2v-11b 12-12 odf
<a href="#">E2V30SSM00</a>	E2V30 smart 16(5/8")-16(5/8") odf with sight glass
<a href="#">E2VCAB0300</a>	connector
<a href="#">E2VMAG0000</a>	Manual actuator for e2v valve
<a href="#">E3V65SWS10</a>	Electronic Expansion Valve
<a href="#">EVBAT00500</a>	Battery for modul battery ricaricabile evd
<a href="#">EVBATBOX10</a>	EVD battery din-rail box (ver.2)
<a href="#">EVD0000E40</a>	Electronic Expansion Valve Driver

Product	Description
<a href="#">EVD0000T20</a>	Universal twin for two valves
<a href="#">EVD0000T40</a>	Twin for two carel valves (plan)
<a href="#">EVD00N3E2K</a>	Kit exv, universal valve 0 to 10 bar without valve
<a href="#">EVDENV00E0</a>	converter
<a href="#">FCSM042300</a>	Fan for speed control
<a href="#">IR33C0HF20</a>	Electronic Controller
<a href="#">IR33C0LN00</a>	Electronic Controller
<a href="#">IR33S0LN00</a>	refrigeration controller
<a href="#">IR33V7HR20</a>	Electronic Controller
<a href="#">IREVC7HC0E</a>	Electronic Controller
<a href="#">IREVY7HN0E</a>	Electronic Controller
<a href="#">IROPZ48500</a>	Modbus Card
<a href="#">NTC015HT00</a>	cable
<a href="#">NTC015WF00</a>	IP67, fast reading, 1.5 M cable, -50t105 °C
<a href="#">NTC030HF01</a>	Sensor
<a href="#">NTC030HP00</a>	NTC Sensor
<a href="#">NTC030WF00</a>	Sensor
<a href="#">NTC060HF0Y</a>	sensor
<a href="#">NTC060HP00</a>	Sensor
<a href="#">NTC060HT00</a>	IP55, 6 m cable, 0t150 °C
<a href="#">NTC060HT0S</a>	High Temp Sensor
<a href="#">NTC060HT41</a>	SENSOR
<a href="#">NTC060PS00</a>	IP67, 6 m cable, -50t105 °C (on air)
<a href="#">NTC060WG00</a>	Glass temperature probe, ip67, cable l= 6 m, -50t105 °C
<a href="#">NTC060WP20</a>	IP68, 6 m cable, -50t105 °C, lenght cap= 200 mm
<a href="#">PCO100TLN0</a>	Tlan serial card
<a href="#">PCO10B1WB0</a>	Communication board
<a href="#">PCO3000EM0</a>	Programmable Controller for HVAC/R Applications
<a href="#">PCO3000ESO</a>	Controller
<a href="#">PGD0000T00</a>	pGD0 with pcot enclosure
<a href="#">PGD0000WZ0</a>	pGD0 wall display + buzzer
<a href="#">PJEZC00100</a>	Refrigeration controller
<a href="#">PJEZC0H100</a>	Electronic Controller for Refrigeration Units
<a href="#">PJEZC0M100</a>	OM100 Controller
<a href="#">PJEZS00500</a>	Refrigeration Control
<a href="#">PJEZS0E130</a>	Electronic Controller
<a href="#">PJEZS0G100</a>	Electronic Controller
<a href="#">PJEZS0P100 (FRS.2548</a>	Carel Controller
<a href="#">PJEZSNH100</a>	Electronic Controller
<a href="#">RTA200C024</a>	RTA 2mod. 5/35 24V
<a href="#">SPKT0031S0</a>	0 To 34.5 Barg (0 to 500 psig)
<a href="#">SPKT0041C0</a>	4 To 20 ma, 0 to 18.2 Barg (0 to 260 psig)
<a href="#">SPKT0043R0</a>	Pressure Transducer
<a href="#">TSOPZCV030</a>	3 M cable for pt1000 sensor
<a href="#">TSQ15MAB00</a>	IP65, 150 mm bulb ø 3 mm -50t350 °C



Product	Description
<a href="#">0907858AXX</a>	EVD eev wires toroid
<a href="#">Type: 1312365AXX</a>	Steam hose Ø30 mm 4m
<a href="#">13C453A085</a>	Non-stick Film (scale-collection bag)
<a href="#">18C431A004</a>	Conductivity Probe
<a href="#">57C453A349</a>	Heater
<a href="#">98C615P005SP</a>	Adapter
<a href="#">ASDH100000</a>	Humidity Sensor, Duct Mount
<a href="#">BL0S1E00H2</a>	Steam Cylinder
<a href="#">BL0T1B00H2</a>	Steam Cylinder
<a href="#">BL0T1D00H2</a>	Steam Cylinder
<a href="#">BL0T2A00H2</a>	Steam Cylinder
<a href="#">BL0T2B00H2</a>	Steam Cylinder
<a href="#">BL0T3D00H2SP</a>	Steam Cylinder
<a href="#">BL0T4B00H2</a>	Steam Cylinder
<a href="#">BL0TRB00H1 (BL0TRB00H1SP)</a>	Steam Cylinder
<a href="#">BL0TRD00H1SP</a>	Steam Cylinder
<a href="#">BL0TRL00H1</a>	Steam Cylinder
<a href="#">BLCT1A00W2</a>	Cleanable Steam Cylinder
<a href="#">BLCT2A00W2</a>	Cleanable Steam Cylinder
<a href="#">BLCT5C00W0</a>	Humidification tank
<a href="#">DP00003000</a>	Plastic Distributor Kit
<a href="#">DP000G3000</a>	Distributor Gasket Kit
<a href="#">DP045D30RU</a>	Stainless steel channel distributor l = 450 mm
<a href="#">DP060D30RU</a>	Duct Steam Distributor 30mm, 24"
<a href="#">DP085D40R0</a>	Stainless steel duct distributor
<a href="#">DP105D30R0</a>	Duct Steam Distributor 30mm, 48"
<a href="#">DP105D40R0</a>	channel Distributor
<a href="#">DP165D40R0</a>	Duct Steam Distributor 40mm, 72"
<a href="#">DP205D40R0</a>	Duct Steam Distributor 40mm, 84"
<a href="#">KITBLCT4C2</a>	Replacement Electrode Kit
<a href="#">KITPS00000 Fill</a>	Drain Pump Kit for SD
<a href="#">KITVC10011</a>	Fill Valve Kit
<a href="#">MCHRTF08C0</a>	Fan Speed controller
<a href="#">PC0S00AKY0</a>	programming Key
<a href="#">PCOUMI2000</a>	PCO Humidifier Interface
<a href="#">PT100000A1</a>	sensor
<a href="#">PT100000A2</a>	IP65, 6x100 mm bulb, 3 m cable, 0t400 °C
<a href="#">S90CONN000</a>	Cable l = 1.5 M, telephone connectors
<a href="#">S90CONN002</a>	Cable l = 0.8 M, telephone connectors
<a href="#">SPK2500000</a>	0 To 25 barg (0 to 360 psig)
<a href="#">SPK3000000</a>	1 To 30 barg (0 to 435 psig)
<a href="#">SPKT0033R0</a>	Pressure Transducer
<a href="#">THP00C0000</a>	Motor Protector
<a href="#">UEKVASC100</a>	Fill Tank Kit
<a href="#">UGKSL00002</a>	3-position level switch

Product	Description
<a href="#">BL0SRF00H2</a>	Steam Cylinder
<a href="#">CONV0/10A0</a>	Module
<a href="#">MAC2SER000/RS485</a>	Serial Card
<a href="#">PCO3000BM0</a>	Controller
<a href="#">UAKCD000U1</a>	Drain Valve
<a href="#">VSDTRA0000</a>	Blower Transformer
<a href="#">ATCM001CW0</a>	Digital Wall Mount Thermostat
<a href="#">KUE0300X01</a>	KIT UE OEM 09-10-15 KG/H IDR.
<a href="#">CPYTERM200</a>	Display
<a href="#">ATC4001AD0</a>	Electronic controller for air-conditioning
<a href="#">BL0T4C00H2</a>	Steam Cylinder
<a href="#">PSOPZKEY00</a>	Programming key
<a href="#">UE130XL001</a>	HumiSteam 130 kg/h
<a href="#">CRL-IR33Z9MR20</a>	Universal Electronic Controller
<a href="#">ASET030000</a>	Temperatur sensor
<a href="#">PCO3000AM0</a>	Controller
<a href="#">DPPC210000</a>	Temperature Sensor
<a href="#">P+P000UB00EF0</a>	Basic version
<a href="#">P+500SEA00EZ0</a>	Extralarge version
<a href="#">P+P0CON1B0</a>	Spring version for c.pCO mini basic panel version
<a href="#">P+50CON0Z0</a>	Screw version for pco5+ extralarge
<a href="#">PCOC000AM0</a>	Controller
<a href="#">TC0NN6J000</a>	T-Connector For pLAN Display
<a href="#">P+D000NH1DEF0</a>	Controller with display
<a href="#">P+D0CON0E0</a>	Terminal block
<a href="#">PGDT07000FR00</a>	Display
<a href="#">HumiSteam 25 kg/h, Type UE025XL001</a>	Humidifier
<a href="#">HUMISTEAM X TYPE 35KG/H 400/3 + FLSTDMHU20</a>	Humidifier
<a href="#">HumiSteam 45 kg/h, Type UE045XL001</a>	Humidifier
<a href="#">HumiSteam 65 kg/h, Type UE065XL001</a>	Humidifier
<a href="#">HumiSteam 90 kg/h, Type UE090XL001</a>	Humidifier
<a href="#">NTC120WF01</a>	Temperature sensor with 12 m. cable
<a href="#">PJEZ0G000</a>	Air conditioning module
<a href="#">PCO10000F0</a>	Lon ftt10 serial interface
<a href="#">E2V14CZ000</a>	valve
<a href="#">EVDIS00EN0</a>	DISPLAY FOR EVD EVOLUTION, ENGLISH
<a href="#">IROPZKEYA0</a>	Parameter programming key for ir33 platform
<a href="#">MXOPZKEYA0</a>	MPXPRO OPTION, PROGRAMMING KEY
<a href="#">CRL-PJEZC0M000</a>	Electronic Controller
<a href="#">PZD0C0P001</a>	Zweipunktregler Thermostat
<a href="#">CVSTDUMOR0</a>	Humidification
<a href="#">IR33S0EN00</a>	Temperature Controller
<a href="#">DP045D30R0</a>	Stainless steel distributor
<a href="#">1312368AXX</a>	Drainage hose
<a href="#">BL0T2C00H2</a>	Steam Cylinder

Product	Description
<a href="#">BL0S2F00H2</a>	Cylinder
<a href="#">PB00C0HN10</a>	Panel Mount On/Off Temperature Controller
<a href="#">UU05DD0000</a>	HUMISONIC DUCT( 4,8 l/h )
<a href="#">UQ05CD0000</a>	CONTROL PANEL FOR ULTRASONIC HUMIDIFIER
<a href="#">KITPSE0000SP</a>	
<a href="#">MCHRTF04C0</a>	fan speed controller-cut
<a href="#">Supply hose (1.5m / 3/4 ") + Drain Hose 1m + Accessories</a>	Hose Kit for HVAC Systems
<a href="#">UCQ065D100</a>	Electrical Control Panel For humiDisk
<a href="#">PCO10B0WB0- pCOWEB</a>	Ethernet™™ serial card, transparent black,8MB
<a href="#">PCO3CON0S0</a>	Terminal kit
<a href="#">NTC120WH01</a>	Temperature sensor
<a href="#">32113374</a>	Twin module driver
<a href="#">PJEZY00000</a>	PJ Easy Panel Mount On/Off Temperature Controller
<a href="#">DCPD010100</a>	Air differential
<a href="#">IROPZ400850</a>	communication board
<a href="#">IROPZ485S0</a>	RS485 Serial Communication Interface
<a href="#">ATA4011CW0</a>	TH TUNE NEUTRAL
<a href="#">EVD0000E10</a>	Electronic Expansion Valve Driver
<a href="#">SPKT0021C0</a>	pressure sensor
<a href="#">E2V30USM20</a>	Unipol electronic exp valve e2v30u 16-16 odf conne ip67
<a href="#">P+500BAA000S0</a>	Programmable Controller for HVAC/R Applications
<a href="#">EVD0000410</a>	EVD400 universal (plan)
<a href="#">DPWL447000</a>	gas leakage box
<a href="#">DPWLC47000</a>	gas leakage box
<a href="#">DPWLE27000</a>	R410a semiconductor version with remote head, 5 m cable
<a href="#">MX30M24HO0</a>	MPX-PRO THERMOSTAT
<a href="#">E2V18BSF00</a>	Electronic expansion valve e2v-18b
<a href="#">EVD0000T51</a>	Twin for two carel valves multiple package 10 pcs
<a href="#">DP060D40RU</a>	Distributor of stainless steel
<a href="#">MCH2000030</a>	Micro Chiller Controller
<a href="#">PGTA00CNV0</a>	cable adapter
<a href="#">1413306AXX</a>	Sensor Well
<a href="#">PDGT04000FS00</a>	display
<a href="#">IRELF0EN215</a>	electronic controller
<a href="#">P/N: UE065YL001</a>	HumiSteam 65 kg/h
<a href="#">PCO1000WD0</a>	Ethernet card for ip protocols
<a href="#">UE065XL001</a>	humiSteam X-plus Steam Humidifier
<a href="#">E6VB2ASV00</a>	Electronic Expansion Valve
<a href="#">UGKDP00050</a>	drain pump kit
<a href="#">BLOT2HCOO2</a>	Cylinder
<a href="#">PC03000AIO</a>	Card
<a href="#">MCH2001031 (pack x20)</a>	CONTROL DEVICE
<a href="#">RICMTA000078</a>	DEC REL. 3.3 DATA SHEET
<a href="#">P+500B0A00ELO</a>	Large version, pgd1 built-in

Product	Description
<a href="#">BL0SRF00H1SP</a>	cylinder
<a href="#">BL0T5D00H0</a>	CYLINDER 65 kg/h
<a href="#">IR33A7LR20</a>	Temperature Controller
<a href="#">PGD0000F00</a>	Display
<a href="#">BL0T2C00H2SP</a>	CYLINDER
<a href="#">P+500B0A00ES0</a>	controllers
<a href="#">SNU0000EM0</a>	Supernode for humidification + flstdmugws
<a href="#">P+D000NH1DLF0</a>	c.pCO Mini High-End Programmable Controller
<a href="#">PSD1024400</a>	frequency invertor
<a href="#">P+500B0A00EM0</a>	Medium version, pgd1 built-in
<a href="#">P+50CON0M0</a>	Screw version for pco5+ medium
<a href="#">BL0S2F00H0</a>	Steam Cylinder
<a href="#">PSOPZKEYA0</a>	programming key
<a href="#">P+500SEB00EM0</a>	Medium version
<a href="#">PJEZS00000</a>	Regulator
<a href="#">PCO3000AS0</a>	Programmable Controller for HVAC/R Systems
<a href="#">BL0S1F00H1SP</a>	cylinder
<a href="#">PLD00GFP00</a>	pLDPRO Display
<a href="#">P+500B0A000L0</a>	control without display
<a href="#">BL0T2C00H0</a>	Humidification cylinder
<a href="#">PCO1000CM0</a>	controler
<a href="#">PCO1000AX0</a>	microprocessor
<a href="#">SPKT0033P0</a>	Pressure sensor
<a href="#">SPKT00B6R0</a>	Pressure Transducer
<a href="#">E4V95FSSA1</a>	Electronic Expansion Valve
<a href="#">UPCARH1DM0</a>	Card
<a href="#">SHOSE00040</a>	Steam hose
<a href="#">BLOT4COOH2</a>	steam cylinder
<a href="#">BL0T4D00H2 , type D</a>	cylinder
<a href="#">E2V35SSM00</a>	Valve
<a href="#">IR32Z00000</a>	Date 27 jan-2004
<a href="#">MCH2CON001</a>	Connector Kit for µC ESP DIN EV Driver
<a href="#">MCH2000050</a>	Controller for refrigeration machine
<a href="#">P+500B0B00EM0</a>	Medium version, pgd1 built-in
<a href="#">PGDE020FZ0</a>	display
<a href="#">DPRC13A000</a>	Temperature and humidity sensor
<a href="#">P+100SE00D0M0</a>	Programmable Controller for HVAC/R Applications
<a href="#">P+100SE00D0S0</a>	Programmable Controller for HVAC/R Applications
<a href="#">E2VATT24Z1/E2V-S</a>	Electronic Expansion Valve
<a href="#">FCSM0823L0</a>	Fan Speed Controller-cut
<a href="#">E2V24BSF00</a>	Electronic expansion valve e2v-24b 12-12 odf
<a href="#">SPKC002310</a>	IP67, 2 m cable with co-moulded packard connector for spkt*
<a href="#">PGD0000I00</a>	Display
<a href="#">SPKT0011D0</a>	Internal thread pressure sensor
<a href="#">NTC050HP02</a>	Temperature sensor

Product	Description
<a href="#">SPKT0013R1</a>	Pressure meter
<a href="#">SPKT0033R1</a>	Pressure meter
<a href="#">SPKC005510</a>	SPKT Cable
<a href="#">P+500BAA000L0</a>	Large version, usb port
<a href="#">PGDE000F00</a>	Display Board
<a href="#">EVD0000E51</a>	electronic expansion valve driver
<a href="#">EVD0011N00</a>	115/230 V with display
<a href="#">EVD0000N00</a>	Ultracap module for evd mini
<a href="#">UCHBP00000100</a>	Uchiller, panel, nfc, bte
<a href="#">UCHBDE0001140</a>	Uchiller enhanced, din mounting
<a href="#">UCHBE00001140</a>	Uchiller enhanced io exp for second circuit
<a href="#">AX5000PD20A30</a>	Display for uchiller, nfc, bte
<a href="#">FCR3124020</a>	Up to 12 a
<a href="#">FCR3204020</a>	Up to 20 a
<a href="#">P+DSVN021K</a>	c.pCO Sistema Programmable Controller
<a href="#">E2V35SSM40</a>	Expansion Valve
<a href="#">E3V45SSR40</a>	electronic expansion valve
<a href="#">E3V55BWR50</a>	E3v55b unipolar 7/8"-7/8" odf cable 2m
<a href="#">E3V55SSR10</a>	18-22 Mm copper connections, integral screw, without sightglass
<a href="#">E3V65SSS10</a>	22-28 Mm copper connections, integral screw, without sightglass
<a href="#">E4V85BWT00</a>	electronic expansion valve
<a href="#">E4V95BWT00</a>	Electronic Expansion Valve
<a href="#">E5VA2AST00</a>	35-35 Mm copper connections, with sight glass, size 120
<a href="#">E6VA8ASV00</a>	42-42 Mm copper connections, size 180
<a href="#">E7VB4ASZ00</a>	54-54 Mm copper connections, size 240
<a href="#">E2VCABS600</a>	Shielded Cable and Connector
<a href="#">SPKT0013R0</a>	Pressure Transducer
<a href="#">PCOECON000</a>	Screw Terminals For Expansion PCOE
<a href="#">EVD0000E50/EVD</a>	EVD Evolution Electronic Expansion Valve Driver
<a href="#">EVD0000E21</a>	Universal multiple package 10 pcs
<a href="#">HCTLEYF020SP</a>	onscreen
<a href="#">UEY65L0200</a>	Control board for UE Basic
<a href="#">EEVMAG0000</a>	Manual Actuator Kit for Electronic Expansion Valves
<a href="#">EVD0000E01</a>	Universal (tlan) multiple package 10 pcs
<a href="#">MCH2000000</a>	MicroChiller2 SE
<a href="#">EVD0000401</a>	EVD400 Universal Electronic Expansion Valve Driver
<a href="#">SPKT0011C0</a>	Pressure Transducer
<a href="#">SPKC005300</a>	Packard Cable + Connector
<a href="#">PCO1000BX0</a>	Controller
<a href="#">SPKT00E3R0</a>	0 To 5 Vdc, -1 to 12.8 Barg (-15 to 185 psig)
<a href="#">UE045YL001</a>	Steam humidifier
<a href="#">PSD0022400</a>	Power Speed Drive
<a href="#">EVD0000T21</a>	Universal twin for two valves multiple package 10 pcs
<a href="#">3396667</a>	SK Display
<a href="#">SPKT00B1C0</a>	Pressure Transducer

Product	Description
<a href="#">FLOE000010</a>	Flood detector
<a href="#">SK 3396.282 / RITBUSR002</a>	SK Display
<a href="#">NTC030WH01</a>	NTC Sensor
<a href="#">NTC015WH01</a>	NTC Sensor Probe
<a href="#">IR33B9MR20</a>	IR33 Universal Electronic Controller
<a href="#">IR33B7LR20</a>	Thermostat
<a href="#">SPKT0043P0</a>	Pressure Transducer
<a href="#">UE090XL001</a>	Steam humidifier Humisteam 90 kg/h
<a href="#">MCH2001031</a>	Parametric controller
<a href="#">SPKT00B1D0</a>	Pressure Transducer
<a href="#">BL0T5C00H0SP</a>	Cylinder
<a href="#">P+E0000000000</a>	Expansion Module
<a href="#">UR006HD204</a>	HeaterSteam steam humidifier 6 kg/h
<a href="#">FRS.1334</a>	Controller PJEZS0H000 1R 2HP 2NTC PYEZ0E0009
<a href="#">297.9800-5</a>	
<a href="#">THB000AAF0</a>	Temperature flush mounting
<a href="#">THB000ACF0</a>	Temperature and humidity flush mounting
<a href="#">THB000AAW0</a>	Temperature wall mounting
<a href="#">THB000ACW0</a>	Temperature and humidity wall mounting
<a href="#">ATA4001AD0</a>	230 Vac, flush mounting
<a href="#">ATA4011AD0</a>	Th tune neutral 230 Vac, flush mounting
<a href="#">ATA4011CD0</a>	terminal
<a href="#">ATAM001AD0</a>	230 Vac, membrane keypad, flush mounting
<a href="#">ATAM001CD0</a>	th-tune
<a href="#">ATC4001CD0</a>	Control Terminal
<a href="#">ATCM001AD0</a>	24 Vac, membrane keypad, flush mounting
<a href="#">ATCM001CD0</a>	display
<a href="#">ATA4001AW0</a>	230 Vac, wall mounting
<a href="#">ATA4001CW0</a>	230 Vac, temperature and humidity, wall mounting
<a href="#">ATAM001AW0</a>	230 Vac, membrane keypad, wall mounting
<a href="#">ATAM001CW0</a>	display
<a href="#">ATC4001AW0</a>	room terminal
<a href="#">ATC4001CW0</a>	24 Vac, temperature and humidity, wall mounting
<a href="#">ATC4011CW0</a>	Th tune neutral 24 Vac, t+h, wall mounting
<a href="#">ATCM001AW0</a>	24 Vac, membrane keypad, wall mounting
<a href="#">P+E000000D000</a>	c.pCOe enhanced version, 16 i/o, exv
<a href="#">P+500SEA000Z0</a>	Extralarge version
<a href="#">P+500SEB000Z0</a>	Extralarge version
<a href="#">P+500SEB00EZ0</a>	Extralarge version
<a href="#">P+500SEA000L0</a>	Controller
<a href="#">P+500SEB000L0</a>	controller
<a href="#">P+500SFB000L0</a>	c.pCO large, fb no opto /bms opto, 2xeth, usb,BACnet™™ b-bc
<a href="#">P+500SNB000L0</a>	c.pCO large, fb no opto /bms opto, 2xeth, usb, usd, nfc
<a href="#">P+500SEA00EL0</a>	Large version
<a href="#">P+500SEB00EL0</a>	controller



Product	Description
<a href="#">P+500SFB00ELO</a>	controller
<a href="#">P+500SNB00ELO</a>	Controller
<a href="#">P+500SEA000M0</a>	Controller without display
<a href="#">P+500SEB000M0</a>	Medium version
<a href="#">P+500SFB000M0</a>	c.pCO medium, fb no opto /bms opto, 2xeth, usb,BACnet™ b-bc
<a href="#">P+500SNB000M0</a>	c.pCO medium, fb no opto /bms opto, 2xeth, usb, usd, nfc
<a href="#">P+500SEA020M0</a>	Controller
<a href="#">P+500SEB010M0</a>	Medium version, evd evo embedded for 1 carel exv
<a href="#">P+500SNB060M0</a>	Controller
<a href="#">P+500SEB06EM0</a>	Medium version, evd evo embedded for 2 universal exv
<a href="#">P+500SEA00EM0</a>	Medium version
<a href="#">P+500SFB00EM0</a>	controller
<a href="#">P+500SFB00ES0</a>	controller
<a href="#">P+500SNB00EM0</a>	Controller
<a href="#">P+D000UB00LF0</a>	controller
<a href="#">P+D000UBC0LF0</a>	c.pCO mini din basic, blind, usb, 2 ssr 24v
<a href="#">P+D000UE1DLF0</a>	c.pCO Mini Programmable Controller
<a href="#">P+D000FH1DLF0</a>	controller
<a href="#">P+D000NHDDL0</a>	controller
<a href="#">P+D000UB00EF0</a>	Basic version
<a href="#">P+D000BE1DEF0</a>	controller
<a href="#">P+D000UE1DEF0</a>	Controller
<a href="#">P+D000FH1DEF0</a>	controller
<a href="#">P+D000NHBDEF0</a>	controller
<a href="#">P+P000UE1DEF0</a>	c.pCO Mini Enhanced Programmable Controller
<a href="#">P+P000NH1DEF0</a>	c.pCO Mini High-End Programmable Controller
<a href="#">P+P000NHBDEF0</a>	c.pCO Mini High-End Programmable Controller
<a href="#">P+P000NHDDEF0</a>	c.pCO Mini High-End Programmable Controller
<a href="#">P+R000NH1DFF0</a>	c.pCO Mini High-End Programmable Controller
<a href="#">CSBAA00100</a>	BACnet™ b-aac profile license(server mstp/ip)
<a href="#">CSBAA005E0</a>	Humidity Sensor
<a href="#">CSBBC00100</a>	BACnet™ b-bc profile license (client/server mstp/ip)
<a href="#">CSBBC001E0</a>	BACnet™ client/server plugin with envelope
<a href="#">CSNMP00100</a>	Snmp protocol
<a href="#">P+500SEA000S0</a>	Small version
<a href="#">P+500SEB000S0</a>	Small version
<a href="#">P+500SFB000S0</a>	c.pCO small, fb no opto /bms opto, 2xeth, usb,BACnet™ b-bc
<a href="#">P+500SNB000S0</a>	c.pCO small, fb no opto /bms opto, 2xeth, usb, usd, nfc
<a href="#">P+5K0SEA000S0</a>	c.pCO small, fb/bms no opto, 2xeth, usb for kec
<a href="#">P+500SEA00ES0</a>	Small version
<a href="#">P+500SEB00ES0</a>	Small version
<a href="#">P+500SEC00ES0</a>	c.pCO small, fb opto /bms opto, 2xeth, usb, pgd1 built in
<a href="#">P+500SNB00ES0</a>	c.pCO Medium Programmable Controller
<a href="#">TCONN60000</a>	Connettore telef. T 6vie
<a href="#">CVSTD00000</a>	Standard Terminal for pCO Controllers

Product	Description
<a href="#">PC485KIT00</a>	Kit interf.Seriale 2 fili
<a href="#">PCOS00PLZ0</a>	Plan polarizer
<a href="#">PCOS00S010</a>	Fastening bracket for canbus serial card
<a href="#">PCOS00S020</a>	Fastening bracket support for serial card pco-web / net
<a href="#">PCOS00S030</a>	Fastening bracket for serial card rs485/lon/rs232
<a href="#">PCOS00SKX0</a>	Bms slot plastic cover for knx card ets config.
<a href="#">PCO1000BD0</a>	pCOnet se, rs485 card for BACnet™ ms/tp protocol
<a href="#">PCO10N0BD0</a>	pCO5+ Programmable Controller
<a href="#">PCO1NN0BD0</a>	pCO1 Medium Programmable Controller
<a href="#">PCO10N0WD0</a>	pCOWeb se, ethernet card for ip protocols neutral (no logo)
<a href="#">PCO1NN0WD0</a>	pCOWeb se, ethernet card for ip protocols naked (no cover)
<a href="#">18C711A016</a>	Portellino per opzione pco web
<a href="#">PCOS00HBB0</a>	Serial Card for pCO Controllers
<a href="#">PCOS00HBF0</a>	Canbus board for e-dronic at 125 kb
<a href="#">PCOS00HSB0</a>	Canbus board for e-dronic at 250 kb
<a href="#">PCOS00KXB0</a>	Konnex serial card
<a href="#">PCOS00KXF0</a>	Konnex serial card
<a href="#">PCOS00KXN0</a>	card
<a href="#">PCOS01KXB0</a>	Konnex serial card for large system
<a href="#">PCO10001F0</a>	Lon ftt10 serial interface, standard chiller profile
<a href="#">PCO100MDM0</a>	pCO1 serial card rs232 for modem
<a href="#">PCOS00FD20</a>	Field bus connection board for modem
<a href="#">PCO100MPB0</a>	Mp-bus® serial card
<a href="#">PCO100FD10</a>	serial card
<a href="#">MT100D2100</a>	Temperature Sensor
<a href="#">MT300W3200</a>	Three-Phase Energy Meter
<a href="#">MTOPZA1000</a>	Split core transformer 100 a, cable /bus-bar
<a href="#">MTOPZA2000</a>	Split core transformer 200 a, cable /bus-bar
<a href="#">MTOPZA4000</a>	Split core transformer 400 a, cable /bus-bar
<a href="#">MTOPZD0000</a>	User interface for energy meter emeter3
<a href="#">MTOPZS1000</a>	Current Transformer for Energy Meters
<a href="#">MTOPZT1000</a>	Transformer 100 a, cable /bus-bar
<a href="#">MTOPZT2000</a>	Transformer 200 a, cable /bus-bar
<a href="#">E2V03BS000</a>	Electronic expansion valve e2v03-b 10-10 s. Stell
<a href="#">E2V03BS100</a>	Electronic expansion valve e2v03-b 13-13 s.Stell
<a href="#">E2V03BSF00</a>	Electronic expansion valve e2v03-b 12-12 odf
<a href="#">E2V03BWA00</a>	Electronic expansion valve e2v03-b 3/8" - 3/8" odf
<a href="#">E2V03BWA01</a>	Electronic expansion valve e2v03-b 3/8" - 3/8" odf 10 pcs
<a href="#">E2V03CS000</a>	Electronic Expansion Valve
<a href="#">E2V03CS100</a>	Electronic Expansion Valve
<a href="#">E2V03CS1C0</a>	Electronic Expansion Valve
<a href="#">E2V03CSFC1</a>	Electronic Expansion Valve
<a href="#">E2V03CZ000</a>	Electronic Expansion Valve
<a href="#">E2V03UWA00</a>	Unipolar electronic expansion valve e2v03-u 3/8"-3/8" odf
<a href="#">E2V05BS100</a>	Electronic expansion valve e2v05-b 13-13 s.Stell

Product	Description
<a href="#">E2V05BWA00</a>	Electronic expansion valve e2v05-b 3/8" - 3/8" odf
<a href="#">E2V05BWA01</a>	Electronic expansion valve e2v05-b 3/8" - 3/8" odf 10 pcs
<a href="#">E2V05CS000</a>	Electronic Expansion Valve
<a href="#">E2V05CS001</a>	Electronic Expansion Valve
<a href="#">E2V05CS100</a>	Electronic Expansion Valve
<a href="#">E2V05CS1C0</a>	Electronic Expansion Valve
<a href="#">E2V05CSFC1</a>	Electronic Expansion Valve
<a href="#">E2V05CZ000</a>	Electronic Expansion Valve
<a href="#">E2V05UWA00</a>	Unipolar electronic expansion valve e2v05-u 3/8"-3/8" odf
<a href="#">E2V09BRB00</a>	Electronic expansion valve e2v09-b 3/8-1/2 sae
<a href="#">E2V09BS000</a>	Electronic expansion valve e2v09-b 10-10 s.Steel
<a href="#">E2V09BS100</a>	Electronic expansion valve e2v09-b 13-13 s.Steel
<a href="#">E2V09BSF01</a>	Electronic expansion valve e2v-09b 12-12 odf imb.10Pcs
<a href="#">E2V09BWA00</a>	Electronic expansion valve e2v09-b 3/8" - 3/8" odf
<a href="#">E2V09BWA01</a>	Electronic expansion valve e2v09-b 3/8" - 3/8" odf 10 pcs
<a href="#">E2V09BWB00</a>	Electronic expansion valve e2v09-b 3/8"-1/2" odf
<a href="#">E2V09CS000</a>	Electronic Expansion Valve
<a href="#">E2V09CS001</a>	Electronic Expansion Valve
<a href="#">E2V09CS100</a>	Electronic Expansion Valve
<a href="#">E2V09CS1C0</a>	Electronic Expansion Valve
<a href="#">E2V09CSFC1</a>	Electronic Expansion Valve
<a href="#">E2V09CZ000</a>	Electronic Expansion Valve
<a href="#">E2V09USF00</a>	Unipolar electronic expansion valve e2v09-u 12-12 odf
<a href="#">E2V09USF10</a>	Unipolar electronic exp valve e2v09u 12-12 odf cable 2m
<a href="#">E2V09USF20</a>	Unipol electronic exp valve e2v09u 12-12 odf conne ip67
<a href="#">E2V09UWA00</a>	Unipolar electronic expansion valve e2v09-u 3/8"-3/8" odf
<a href="#">E2V11BRB00</a>	Electronic expansion valve e2v-11b 3/8 - 1/2 sae
<a href="#">E2V11BRB01</a>	Electronic expansion valve e2v-11b 3/8 - 1/2 sae imb.10Pcs
<a href="#">E2V11BS000</a>	Electronic expansion valve e2v-11b 10-10 s.Steel
<a href="#">E2V11BS100</a>	Electronic expansion valve e2v11-b 13-13 s.Steel
<a href="#">E2V11BSF01</a>	Electronic expansion valve e2v-11b 12-12 odf imb.10Pcs
<a href="#">E2V11BWA00</a>	Electronic expansion valve e2v11-b 3/8" - 3/8" odf
<a href="#">E2V11BWA01</a>	Electronic expansion valve e2v11-b 3/8" - 3/8" odf 10 pcs
<a href="#">E2V11BWB00</a>	Electronic expansion valve e2v11-b 3/8"-1/2" odf
<a href="#">E2V11CS000</a>	Electronic Expansion Valve
<a href="#">E2V11CS001</a>	Electronic Expansion Valve
<a href="#">E2V11CS100</a>	Electronic Expansion Valve
<a href="#">E2V11CS1C0</a>	Electronic Expansion Valve
<a href="#">E2V11CSFC1</a>	Electronic Expansion Valve
<a href="#">E2V11CZ000</a>	Electronic expansion valve
<a href="#">E2V11USF00</a>	Unipolar electronic expansion valve e2v11-u 12-12 odf
<a href="#">E2V11USF10</a>	Unipolar electronic exp valve e2v11u 12-12 odf cable 2m
<a href="#">E2V11USF20</a>	Unipol electronic exp valve e2v11u 12-12 odf conne ip67
<a href="#">E2V11UWA00</a>	Unipolar electronic expansion valve e2v11-u 3/8"-3/8" odf
<a href="#">E2V14BRB00</a>	Electronic expansion valve e2v-14b 3/8-1/2 sae

Product	Description
<a href="#">E2V14BRB01</a>	Electronic expansion valve e2v-14b 3/8-1/2 sae imb.10Pcs
<a href="#">E2V14BS000</a>	Electronic expansion valve e2v-14b 10-10 s.Steel
<a href="#">E2V14BS100</a>	Electronic expansion valve
<a href="#">E2V14BSF01</a>	Electronic expansion valve e2v-14b 12-12 odf imb.10Pcs
<a href="#">E2V14BWA00</a>	Electronic expansion valve e2v14-b 3/8" - 3/8" odf
<a href="#">E2V14BWA01</a>	Electronic expansion valve e2v14-b 3/8" - 3/8" odf 10 pcs
<a href="#">E2V14BWB00</a>	Electronic expansion valve e2v14-b 3/8"-1/2" odf
<a href="#">E2V14CS000</a>	Electronic expansion valve
<a href="#">E2V14CS001</a>	Electronic expansion valve
<a href="#">E2V14CS100</a>	Electronic expansion valve
<a href="#">E2V14CS1C0</a>	Electronic expansion valve
<a href="#">E2V14CSFC1</a>	Electronic expansion valve
<a href="#">E2V14USF00</a>	Unipolar electronic expansion valve e2v14-u 12-12 odf
<a href="#">E2V14USF10</a>	Unipolar electronic exp valve e2v14u 12-12 odf cable 2m
<a href="#">E2V14USF20</a>	Unipol electronic exp valve e2v14u 12-12 odf conne ip67
<a href="#">E2V14UWA00</a>	Unipolar electronic expansion valve e2v14-u 3/8"-3/8" odf
<a href="#">E2V18BRB00</a>	Electronic expansion valve e2v-18b 3/8-1/2 sae
<a href="#">E2V18BRB01</a>	Electronic expansion valve e2v-18b 3/8-1/2 sae imb.10Pcs
<a href="#">E2V18BS000</a>	Electronic expansion valve e2v-18b 10-10 s.Steel
<a href="#">E2V18BS100</a>	Electronic expansion valve e2v18-b 13-13 s.Steel
<a href="#">E2V18BSF01</a>	Electronic expansion valve e2v-18b imb.10Pcs
<a href="#">E2V18BWA00</a>	Electronic expansion valve e2v18-b 3/8" - 3/8" odf
<a href="#">E2V18BWA01</a>	Electronic expansion valve e2v18-b 3/8" - 3/8" odf 10 pcs
<a href="#">E2V18BWB00</a>	Electronic expansion valve e2v18-b 3/8"-1/2" odf
<a href="#">E2V18CS000</a>	Electronic expansion valve
<a href="#">E2V18CS001</a>	Electronic expansion valve
<a href="#">E2V18CS100</a>	Electronic expansion valve
<a href="#">E2V18CS1C0</a>	Electronic expansion valve
<a href="#">E2V18CSFC1</a>	Electronic expansion valve
<a href="#">E2V18CZ000</a>	Electronic expansion valve
<a href="#">E2V18USF00</a>	Unipolar electronic expansion valve e2v18-u 12-12 odf
<a href="#">E2V18USF10</a>	Unipolar electronic exp valve e2v18u 12-12 odf cable 2m
<a href="#">E2V18USF20</a>	Unipol electronic exp valve e2v18u 12-12 odf conne ip67
<a href="#">E2V18UWA00</a>	Unipolar electronic expansion valve e2v18-u 3/8"-3/8" odf
<a href="#">E2V24BRB00</a>	Electronic expansion valve e2v-24b 3/8-1/2 sae
<a href="#">E2V24BRB01</a>	Electronic expansion valve e2v-24b 3/8-1/2 sae imb.10Pcs
<a href="#">E2V24BS000</a>	Electronic expansion valve e2v-24b 10-10 s.Steel
<a href="#">E2V24BS100</a>	Electronic expansion valve e2v24-b 13-13 s.Steel
<a href="#">E2V24BSF01</a>	Electronic expansion valve e2v-24b 12-12 odf imb.10Pcs
<a href="#">E2V24BSM00</a>	Electronic expansion valve e2v-24b 16(5/8")-16(5/8") odf
<a href="#">E2V24BSM01</a>	Electronic expansion valve e2v-24b 16-16 odf imb.10Pcs
<a href="#">E2V24BWA00</a>	Electronic expansion valve e2v24-b 3/8"- 3/8" odf
<a href="#">E2V24BWA01</a>	Electronic expansion valve e2v24-b 3/8" - 3/8" odf10 pcs
<a href="#">E2V24BWB00</a>	Electronic expansion valve e2v24-b 3/8"-1/2" odf
<a href="#">E2V24CS000</a>	Electronic expansion valve

Product	Description
<a href="#">E2V24CS100</a>	Electronic expansion valve
<a href="#">E2V24CS1C0</a>	Electronic expansion valve
<a href="#">E2V24CZ000</a>	Electronic expansion valve
<a href="#">E2V24USF00</a>	Unipolar electronic expansion valve e2v24-u 12-12 odf
<a href="#">E2V24USF10</a>	Valve
<a href="#">E2V24USF20</a>	Unipol electronic exp valve e2v24u 12-12 odf conn ip67
<a href="#">E2V24USM00</a>	Electronic Expansion Valve
<a href="#">E2V24USM10</a>	Unipolar electronic exp valve e2v24u 16-16 odf cable 2m
<a href="#">E2V24USM20</a>	Unipol electronic exp valve e2v24u 16-16 odf conn ip67
<a href="#">E2V24UWA00</a>	Unipolar electronic expansion valve e2v24-u 3/8"-3/8" odf
<a href="#">E2V30BRB00</a>	Electronic expansion valve e2v-30b 3/8-1/2 sae
<a href="#">E2V30BRB01</a>	Electronic expansion valve e2v-30b 3/8-1/2 sae imb.10Pcs
<a href="#">E2V30BS000</a>	Electronic expansion valve e2v-30b 10-10 s.Steel
<a href="#">E2V30BS100</a>	Electronic expansion valve e2v30-b 13-13 s.Steel
<a href="#">E2V30BSM01</a>	Electronic expansion valve e2v30-b 16-16 odf 10 pcs
<a href="#">E2V30USM00</a>	Unipolar electronic expansion valve e2v30-u 16-16 odf
<a href="#">E2V30USM10</a>	Unipolar electronic exp valve e2v30u 16-16 odf cable 2m
<a href="#">E2V35BRB00</a>	Electronic expansion valve e2v-35b 3/8-1/2 sae
<a href="#">E2V35BRB01</a>	Electronic expansion valve e2v-35b 3/8-1/2 sae imb.10Pcs
<a href="#">E2V35BS000</a>	Electronic expansion valve e2v-35b 10-10 s.Steel
<a href="#">E2V35BS100</a>	Electronic expansion valve e2v35-b 13-13 s.Steel
<a href="#">E2V35BSM00</a>	Valve
<a href="#">E2V35BSM01</a>	Electronic Expansion Valve
<a href="#">E2V03ZSF03</a>	Electronic Expansion Valve
<a href="#">E2V03ZSF13</a>	Electronic Expansion Valve
<a href="#">E2V03ZSF63</a>	Electronic Expansion Valve
<a href="#">E2V03ZSF73</a>	Electronic Expansion Valve
<a href="#">E2V03ZSFA0</a>	Electronic Expansion Valve
<a href="#">E2V03ZSFB0</a>	Electronic Expansion Valve
<a href="#">E2V03ZWF03</a>	Electronic Expansion Valve
<a href="#">E2V03ZWF13</a>	Electronic Expansion Valve
<a href="#">E2V03ZWF63</a>	Electronic Expansion Valve
<a href="#">E2V03ZWF73</a>	Electronic Expansion Valve
<a href="#">E2V03ZWFA0</a>	Electronic Expansion Valve
<a href="#">E2V03ZWFB0</a>	Electronic Expansion Valve
<a href="#">E2V05SSF00</a>	E2V05 smart 12-12 odf with sight glass
<a href="#">E2V05SSF01</a>	E2V05 smart 12-12 odf with sight glass 10 pcs
<a href="#">E2V05SSF10</a>	E2V05 smart 12-12 odf w/o sight glass
<a href="#">E2V05SSF11</a>	E2V05 smart 12-12 odf w/o sight glass 10 pcs
<a href="#">E2V05SSF20</a>	E2V05 smart 12-12 odf with sight glass unip. Cab 1m
<a href="#">E2V05SSF30</a>	E2V05 smart 12-12 odf w/o sight glass unip. Cab 1m
<a href="#">E2V05SSF40</a>	E2V05 smart 12-12 odf with sight glass unip. Cab 2m
<a href="#">E2V05SSF50</a>	E2V05 smart 12-12 odf w/o sight glass unip. Cab 2m
<a href="#">E2V05SSF60</a>	Electronic Expansion Valve
<a href="#">E2V05SSF70</a>	Electronic Expansion Valve



Product	Description
<a href="#">E2V05SWF00</a>	E2V05 smart 1/2"-1/2" odf with sight glass
<a href="#">E2V05SWF10</a>	E2V05 smart 1/2"-1/2" odf w/o sight glass
<a href="#">E2V05SWF11</a>	E2V05 smart 1/2"-1/2" odf w/o sight glass 10 pcs
<a href="#">E2V05SWF20</a>	Electronic Expansion Valve
<a href="#">E2V05SWF21</a>	Electronic Expansion Valve
<a href="#">E2V05SWF30</a>	Electronic Expansion Valve
<a href="#">E2V05SWF31</a>	Electronic Expansion Valve
<a href="#">E2V05SWF40</a>	Electronic Expansion Valve
<a href="#">E2V05SWF41</a>	Electronic Expansion Valve
<a href="#">E2V05SWF50</a>	Electronic Expansion Valve
<a href="#">E2V05SWF51</a>	Electronic Expansion Valve
<a href="#">E2V05SWF60</a>	Electronic Expansion Valve
<a href="#">E2V05SWF61</a>	Electronic Expansion Valve
<a href="#">E2V05SWF70</a>	Electronic Expansion Valve
<a href="#">E2V05SWF71</a>	Electronic Expansion Valve
<a href="#">E2V05ZSF03</a>	Electronic Expansion Valve
<a href="#">E2V05ZSF13</a>	Electronic Expansion Valve
<a href="#">E2V05ZSF63</a>	Electronic Expansion Valve
<a href="#">E2V05ZSF73</a>	Electronic Expansion Valve
<a href="#">E2V05ZSFA0</a>	Electronic Expansion Valve
<a href="#">E2V05ZSFB0</a>	Electronic Expansion Valve
<a href="#">E2V05ZWF03</a>	Electronic Expansion Valve
<a href="#">E2V05ZWF13</a>	Electronic Expansion Valve
<a href="#">E2V05ZWF63</a>	Electronic Expansion Valve
<a href="#">E2V05ZWF73</a>	Electronic Expansion Valve
<a href="#">E2V05ZWFA0</a>	Electronic Expansion Valve
<a href="#">E2V05ZWFB0</a>	Electronic Expansion Valve
<a href="#">E2V09SSF00</a>	E2V09 smart 12-12 odf with sight glass
<a href="#">E2V09SSF01</a>	E2V09 smart 12-12 odf with sight glass 10 pcs
<a href="#">E2V09SSF10</a>	E2V09 smart 12-12 odf w/o sight glass
<a href="#">E2V09SSF11</a>	E2V09 smart 12-12 odf w/o sight glass 10 pcs
<a href="#">E2V09SSF20</a>	E2Vo9 smart 12-12 odf with sight glass unip. Cab 1m
<a href="#">E2V09SSF30</a>	E2Vo9 smart 12-12 odf w/o sight glass unip. Cab 1m
<a href="#">E2V09SSF40</a>	E2V09 smart 12-12 odf with sight glass unip. Cab 2m
<a href="#">E2V09SSF50</a>	E2Vo9 smart 12-12 odf w/o sight glass unip. Cab 2m
<a href="#">E2V09SSF60</a>	Electronic Expansion Valve
<a href="#">E2V09SSF70</a>	Electronic Expansion Valve
<a href="#">E2V09SWF00</a>	E2V09 smart 1/2"-1/2" odf with sight glass
<a href="#">E2V09SWF10</a>	E2V09 smart 1/2"-1/2" odf w/o sight glass
<a href="#">E2V09SWF11</a>	E2V09 smart 1/2"-1/2" odf w/o sight glass 10 pcs
<a href="#">E2V09SWF20</a>	Electronic Expansion Valve
<a href="#">E2V09SWF21</a>	Electronic Expansion Valve
<a href="#">E2V09SWF30</a>	Electronic Expansion Valve
<a href="#">E2V09SWF31</a>	Electronic Expansion Valve
<a href="#">E2V09SWF40</a>	Electronic Expansion Valve



Product	Description
<a href="#">E2V09SWF41</a>	Electronic Expansion Valve
<a href="#">E2V09SWF50</a>	Electronic Expansion Valve
<a href="#">E2V09SWF51</a>	Electronic Expansion Valve
<a href="#">E2V09SWF60</a>	Electronic Expansion Valve
<a href="#">E2V09SWF61</a>	Electronic Expansion Valve
<a href="#">E2V09SWF70</a>	Electronic Expansion Valve
<a href="#">E2V09SWF71</a>	Electronic Expansion Valve
<a href="#">E2V09ZSF03</a>	Electronic Expansion Valve
<a href="#">E2V09ZSF13</a>	Electronic Expansion Valve
<a href="#">E2V09ZSF63</a>	Electronic Expansion Valve
<a href="#">E2V09ZSF73</a>	Electronic Expansion Valve
<a href="#">E2V09ZSFA0</a>	Electronic Expansion Valve
<a href="#">E2V09ZSFB0</a>	Electronic Expansion Valve
<a href="#">E2V09ZWF03</a>	Electronic Expansion Valve
<a href="#">E2V09ZWF13</a>	Electronic Expansion Valve
<a href="#">E2V09ZWF63</a>	Electronic Expansion Valve
<a href="#">E2V09ZWF73</a>	Electronic Expansion Valve
<a href="#">E2V09ZWFA0</a>	Electronic Expansion Valve
<a href="#">E2V09ZWFB0</a>	Electronic Expansion Valve
<a href="#">E2V11HSF10</a>	E2V11 smart 12-12 odf w/o sight glass for hot gas
<a href="#">E2V11HWF10</a>	Electronic Expansion Valve
<a href="#">E2V11HWFC0</a>	E2V11 smart hot-gas 1/2"-1/2" odf - w/o stator
<a href="#">E2V11SSF00</a>	E2V11 smart 12-12 odf with sight glass
<a href="#">E2V11SSF01</a>	E2V11 smart 12-12 odf with sight glass 10 pcs
<a href="#">E2V11SSF10</a>	E2V11 smart 12-12 odf w/o sight glass
<a href="#">E2V11SSF11</a>	E2V11 smart 12-12 odf w/o sight glass 10 pcs
<a href="#">E2V11SSF20</a>	E2V11 smart 12-12 odf with sight glass unip. Cab 1m
<a href="#">E2V11SSF30</a>	E2V11 smart 12-12 odf w/o sight glass unip. Cab 1m
<a href="#">E2V11SSF40</a>	E2V11 smart 12-12 odf with sight glass unip. Cab 2m
<a href="#">E2V11SSF50</a>	E2V11 smart 12-12 odf w/o sight glass unip. Cab 2m
<a href="#">E2V11SSF60</a>	Electronic Expansion Valve
<a href="#">E2V11SSF70</a>	Electronic Expansion Valve
<a href="#">E2V11SWF00</a>	E2V11 smart 1/2"-1/2" odf with sight glass
<a href="#">E2V11SWF10</a>	E2V11 smart 1/2"-1/2" odf w/o sight glass
<a href="#">E2V11SWF11</a>	E2V11 smart 1/2"-1/2" odf w/o sight glass
<a href="#">E2V11SWF20</a>	Electronic Expansion Valve
<a href="#">E2V11SWF21</a>	Electronic Expansion Valve
<a href="#">E2V11SWF30</a>	Electronic Expansion Valve
<a href="#">E2V11SWF31</a>	Electronic Expansion Valve
<a href="#">E2V11SWF40</a>	Electronic Expansion Valve
<a href="#">E2V11SWF41</a>	Electronic Expansion Valve
<a href="#">E2V11SWF50</a>	Electronic Expansion Valve
<a href="#">E2V11SWF51</a>	Electronic Expansion Valve
<a href="#">E2V11SWF60</a>	Electronic Expansion Valve
<a href="#">E2V11SWF61</a>	Electronic Expansion Valve

Product	Description
<a href="#">E2V11SWF70</a>	Electronic Expansion Valve
<a href="#">E2V11SWF71</a>	Electronic Expansion Valve
<a href="#">E2V11ZSF03</a>	Electronic Expansion Valve
<a href="#">E2V11ZSF13</a>	Electronic Expansion Valve
<a href="#">E2V11ZSF63</a>	Electronic Expansion Valve
<a href="#">E2V11ZSF73</a>	Electronic Expansion Valve
<a href="#">E2V11ZSFA0</a>	Electronic Expansion Valve
<a href="#">E2V11ZSFB0</a>	Electronic Expansion Valve
<a href="#">E2V11ZWF03</a>	Electronic Expansion Valve
<a href="#">E2V11ZWF13</a>	Electronic Expansion Valve
<a href="#">E2V11ZWF63</a>	Electronic Expansion Valve
<a href="#">E2V11ZWF73</a>	Electronic Expansion Valve
<a href="#">E2V11ZWFA0</a>	Electronic Expansion Valve
<a href="#">E2V11ZWFB0</a>	Electronic Expansion Valve
<a href="#">E2V14HSF10</a>	E2V14 smart 12-12 odf w/o sight glass for hot gas
<a href="#">E2V14HWF10</a>	Electronic Expansion Valve
<a href="#">E2V14HWFC0</a>	E2V14 smart hot-gas 1/2"-1/2" odf - w/o stator
<a href="#">E2V14SSF00</a>	E2V14 smart 12-12 odf with sight glass
<a href="#">E2V14SSF01</a>	E2V14 smart 12-12 odf with sight glass 10 pcs
<a href="#">E2V14SSF10</a>	E2V14 smart 12-12 odf w/o sight glass
<a href="#">E2V14SSF11</a>	E2V14 smart 12-12 odf w/o sight glass 10 pcs
<a href="#">E2V14SSF20</a>	E2V14 smart 12-12 odf with sight glass unip. Cab 1m
<a href="#">E2V14SSF30</a>	E2V14 smart 12-12 odf w/o sight glass unip. Cab 1m
<a href="#">E2V14SSF40</a>	E2V14 smart 12-12 odf with sight glass unip. Cab 2m
<a href="#">E2V14SSF50</a>	E2V14 smart 12-12 odf w/o sight glass unip. Cab 2m
<a href="#">E2V14SSF60</a>	Electronic Expansion Valve
<a href="#">E2V14SSF70</a>	Electronic Expansion Valve
<a href="#">E2V14SWF00</a>	E2V14 smart 1/2"-1/2" odf with sight glass
<a href="#">E2V14SWF10</a>	E2V14 smart 1/2"-1/2" odf w/o sight glass
<a href="#">E2V14SWF11</a>	E2V14 smart 1/2"-1/2" odf w/o sight glass 10 pcs
<a href="#">E2V14SWF20</a>	Electronic Expansion Valve
<a href="#">E2V14SWF21</a>	Electronic Expansion Valve
<a href="#">E2V14SWF30</a>	Electronic Expansion Valve
<a href="#">E2V14SWF31</a>	Electronic Expansion Valve
<a href="#">E2V14SWF40</a>	Electronic Expansion Valve
<a href="#">E2V14SWF41</a>	Electronic Expansion Valve
<a href="#">E2V14SWF50</a>	Electronic Expansion Valve
<a href="#">E2V14SWF51</a>	Electronic Expansion Valve
<a href="#">E2V14SWF60</a>	Electronic Expansion Valve
<a href="#">E2V14SWF61</a>	Electronic Expansion Valve
<a href="#">E2V14SWF70</a>	Electronic Expansion Valve
<a href="#">E2V14SWF71</a>	Electronic Expansion Valve
<a href="#">E2V14ZSF03</a>	Electronic Expansion Valve
<a href="#">E2V14ZSF13</a>	Electronic Expansion Valve
<a href="#">E2V14ZSF63</a>	Electronic Expansion Valve

Product	Description
<a href="#">E2V14ZSF73</a>	Electronic Expansion Valve
<a href="#">E2V14ZSFA0</a>	Electronic Expansion Valve
<a href="#">E2V14ZSFB0</a>	Electronic Expansion Valve
<a href="#">E2V14ZWF03</a>	Electronic Expansion Valve
<a href="#">E2V14ZWF13</a>	Electronic Expansion Valve
<a href="#">E2V14ZWF63</a>	Electronic Expansion Valve
<a href="#">E2V14ZWF73</a>	Electronic Expansion Valve
<a href="#">E2V14ZWFA0</a>	Electronic Expansion Valve
<a href="#">E2V14ZWFB0</a>	Electronic Expansion Valve
<a href="#">E2V18HSF10</a>	E2V18 smart 12-12 odf w/o sight glass for hot gas
<a href="#">E2V18HWF10</a>	Electronic Expansion Valve
<a href="#">E2V18HWFC0</a>	E2V18 smart hot-gas 1/2"-1/2" odf - w/o stator
<a href="#">E2V18SSF00</a>	E2V18 smart 12-12 odf with sight glass
<a href="#">E2V18SSF01</a>	E2V18 smart 12-12 odf with sight glass 10 pcs
<a href="#">E2V18SSF10</a>	E2V18 smart 12-12 odf w/o sight glass
<a href="#">E2V18SSF11</a>	E2V18 smart 12-12 odf w/o sight glass 10 pcs
<a href="#">E2V18SSF20</a>	E2V18 smart 12-12 odf with sight glass unip. Cab 1m
<a href="#">E2V18SSF30</a>	E2V18 smart 12-12 odf w/o sight glass unip. Cab 1m
<a href="#">E2V18SSF40</a>	E2V18 smart 12-12 odf with sight glass unip. Cab 2m
<a href="#">E2V18SSF50</a>	E2V18 smart 12-12 odf w/o sight glass unip. Cab 2m
<a href="#">E2V18SSF60</a>	Electronic Expansion Valve
<a href="#">E2V18SSF70</a>	Electronic Expansion Valve
<a href="#">E2V18SWF00</a>	E2V18 smart 1/2"-1/2" odf with sight glass
<a href="#">E2V18SWF10</a>	E2V18 smart 1/2"-1/2" odf w/o sight glass
<a href="#">E2V18SWF11</a>	E2V18smart 1/2"-1/2" odf w/o sight glass 10 pcs
<a href="#">E2V18SWF20</a>	Electronic Expansion Valve
<a href="#">E2V18SWF21</a>	Electronic Expansion Valve
<a href="#">E2V18SWF30</a>	Electronic Expansion Valve
<a href="#">E2V18SWF31</a>	Electronic Expansion Valve
<a href="#">E2V18SWF40</a>	Electronic Expansion Valve
<a href="#">E2V18SWF41</a>	Electronic Expansion Valve
<a href="#">E2V18SWF50</a>	Electronic Expansion Valve
<a href="#">E2V18SWF51</a>	Electronic Expansion Valve
<a href="#">E2V18SWF60</a>	Electronic Expansion Valve
<a href="#">E2V18SWF61</a>	Electronic Expansion Valve
<a href="#">E2V18SWF70</a>	Electronic Expansion Valve
<a href="#">E2V18SWF71</a>	Electronic Expansion Valve
<a href="#">E2V18ZSF03</a>	Electronic Expansion Valve
<a href="#">E2V18ZSF13</a>	Electronic Expansion Valve
<a href="#">E2V18ZSF63</a>	Electronic Expansion Valve
<a href="#">E2V18ZSF73</a>	Electronic Expansion Valve
<a href="#">E2V18ZSFA0</a>	Electronic Expansion Valve
<a href="#">E2V18ZSFB0</a>	Electronic Expansion Valve
<a href="#">E2V18ZWF03</a>	Electronic Expansion Valve
<a href="#">E2V18ZWF13</a>	Electronic Expansion Valve

Product	Description
<a href="#">E2V18ZWf63</a>	Electronic Expansion Valve
<a href="#">E2V18ZWf73</a>	Electronic Expansion Valve
<a href="#">E2V18ZWfA0</a>	Electronic Expansion Valve
<a href="#">E2V18ZWfB0</a>	Electronic Expansion Valve
<a href="#">E2V24HSF10</a>	E2V24 smart 12-12 odf w/o sight glass for hot gas
<a href="#">E2V24HSM10</a>	Electronic Expansion Valve
<a href="#">E2V24HSMC0</a>	E2V24 smart hot-gas ø16mm (5/8") odf - w/o stator
<a href="#">E2V24SSF00</a>	E2V24 smart 12-12 odf with sight glass
<a href="#">E2V24SSF01</a>	E2V24 smart 12-12 odf with sight glass 10 pcs
<a href="#">E2V24SSF10</a>	E2V24 smart 12-12 odf w/o sight glass
<a href="#">E2V24SSF11</a>	E2V24 smart 12-12 odf w/o sight glass 10 pcs
<a href="#">E2V24SSF20</a>	E2V24 smart 12-12 odf with sight glass unip. Cab 1m
<a href="#">E2V24SSF30</a>	E2V24 smart 12-12 odf w/o sight glass unip. Cab 1m
<a href="#">E2V24SSF40</a>	E2V24 smart 12-12 odf with sight glass unip. Cab 2m
<a href="#">E2V24SSF50</a>	E2V24 smart 12-12 odf w/o sight glass unip. Cab 2m
<a href="#">E2V24SSF60</a>	Electronic Expansion Valve
<a href="#">E2V24SSF70</a>	Electronic Expansion Valve
<a href="#">E2V24SSM00</a>	E2V24 smart 16(5/8")-16(5/8") odf with sight glass
<a href="#">E2V24SSM01</a>	Electronic Expansion Valve
<a href="#">E2V24SSM10</a>	E2V24 smart 16(5/8")-16(5/8") odf w/o sight glass
<a href="#">E2V24SSM11</a>	Electronic Expansion Valve
<a href="#">E2V24SSM20</a>	Valve
<a href="#">E2V24SSM30</a>	Electronic Expansion Valve
<a href="#">E2V24SSM40</a>	Electronic Expansion Valve
<a href="#">E2V24SSM50</a>	Electronic Expansion Valve
<a href="#">E2V24SSM60</a>	Electronic Expansion Valve
<a href="#">E2V24SSM70</a>	Electronic Expansion Valve
<a href="#">E2V24ZSF03</a>	Electronic Expansion Valve
<a href="#">E2V24ZSF13</a>	Electronic Expansion Valve
<a href="#">E2V24ZSF63</a>	Electronic Expansion Valve
<a href="#">E2V24ZSF73</a>	Electronic Expansion Valve
<a href="#">E2V24ZSFA0</a>	Electronic Expansion Valve
<a href="#">E2V24ZSFB0</a>	Electronic Expansion Valve
<a href="#">E2V24ZSM03</a>	Electronic Expansion Valve
<a href="#">E2V24ZSM13</a>	Electronic Expansion Valve
<a href="#">E2V24ZSM63</a>	Electronic Expansion Valve
<a href="#">E2V24ZSM73</a>	Electronic Expansion Valve
<a href="#">E2V24ZSMA0</a>	Electronic Expansion Valve
<a href="#">E2V24ZSMB0</a>	Electronic Expansion Valve
<a href="#">E2V24ZWf03</a>	Electronic Expansion Valve
<a href="#">E2V24ZWf13</a>	Electronic Expansion Valve
<a href="#">E2V24ZWf63</a>	Electronic Expansion Valve
<a href="#">E2V24ZWf73</a>	Electronic Expansion Valve
<a href="#">E2V30HSM10</a>	Electronic Expansion Valve
<a href="#">E2V30HSMC0</a>	E2V30 smart hot-gas ø16mm (5/8") odf - w/o stator

Product	Description
<a href="#">E2V30SSM01</a>	Electronic Expansion Valve
<a href="#">E2V30SSM10</a>	E2V30 smart 16(5/8")-16(5/8") odf w/o sight glass
<a href="#">E2V30SSM11</a>	Electronic Expansion Valve
<a href="#">E2V30SSM20</a>	Electronic Expansion Valve
<a href="#">E2V30SSM30</a>	Electronic Expansion Valve
<a href="#">E2V30SSM40</a>	Electronic Expansion Valve
<a href="#">E2V30SSM50</a>	Electronic Expansion Valve
<a href="#">E2V30SSM60</a>	Electronic Expansion Valve
<a href="#">E2V30SSM70</a>	Electronic Expansion Valve
<a href="#">E2V30ZSM03</a>	Electronic Expansion Valve
<a href="#">E2V30ZSM13</a>	Electronic Expansion Valve
<a href="#">E2V30ZSM63</a>	Electronic Expansion Valve
<a href="#">E2V30ZSM73</a>	Electronic Expansion Valve
<a href="#">E2V30ZSMA0</a>	Electronic Expansion Valve
<a href="#">E2V30ZSMB0</a>	Electronic Expansion Valve
<a href="#">E2V35HSM10</a>	Electronic Expansion Valve
<a href="#">E2V35HSMC0</a>	E2V35 smart hot-gas ø16mm (5/8") odf - w/o stator
<a href="#">E2V35SSM01</a>	Electronic Expansion Valve
<a href="#">E2V35SSM10</a>	E2V35 smart 16(5/8")-16(5/8") odf w/o sight glass
<a href="#">E2V35SSM11</a>	Electronic Expansion Valve
<a href="#">E2V35SSM20</a>	Electronic Expansion Valve
<a href="#">E2V35SSM30</a>	Electronic Expansion Valve
<a href="#">E2V35SSM50</a>	Electronic Expansion Valve
<a href="#">E2V35SSM60</a>	Electronic Expansion Valve
<a href="#">E2V35SSM70</a>	Electronic Expansion Valve
<a href="#">E2V35ZSM03</a>	Electronic Expansion Valve
<a href="#">E2V35ZSM13</a>	Electronic Expansion Valve
<a href="#">E2V35ZSMA0</a>	Electronic Expansion Valve
<a href="#">E2V35ZSMB0</a>	Electronic Expansion Valve
<a href="#">E2V03FSAC1</a>	Electronic expansion valve e2v03-f 08-08 (5/16"-5/16")
<a href="#">E2V03FSBC1</a>	Electronic Expansion Valve
<a href="#">E2V03FSFC1</a>	Electronic Expansion Valve
<a href="#">E2V03FWAC1</a>	Electronic Expansion Valve
<a href="#">E2V05FSAC1</a>	Electronic Expansion Valve
<a href="#">E2V05FSBC1</a>	Electronic Expansion Valve
<a href="#">E2V05FSFC1</a>	Electronic Expansion Valve
<a href="#">E2V05FWAC1</a>	Electronic Expansion Valve
<a href="#">E2V05FWFC1</a>	Electronic Expansion Valve
<a href="#">E2V09FSAC1</a>	Electronic expansion valve
<a href="#">E2V09FSBC1</a>	Electronic expansion valve
<a href="#">E2V09FSFC1</a>	Electronic expansion valve
<a href="#">E2V09FWAC1</a>	Electronic expansion valve
<a href="#">E2V09FWFC1</a>	Electronic expansion valve
<a href="#">E2V11FSAC1</a>	Electronic expansion valve
<a href="#">E2V11FSBC1</a>	Electronic expansion valve

Product	Description
<a href="#">E2V11FSFC1</a>	Electronic expansion valve
<a href="#">E2V11FWAC1</a>	Electronic expansion valve
<a href="#">E2V11FWFC1</a>	Electronic expansion valve
<a href="#">E2V14FSAC1</a>	Electronic expansion valve
<a href="#">E2V14FSBC1</a>	Electronic expansion valve
<a href="#">E2V14FSFC1</a>	Electronic expansion valve
<a href="#">E2V14FWAC1</a>	Electronic expansion valve
<a href="#">E2V14FWFC1</a>	Electronic expansion valve
<a href="#">E2V18FSAC1</a>	Electronic expansion valve
<a href="#">E2V18FSBC1</a>	Electronic expansion valve
<a href="#">E2V18FSFC1</a>	Electronic expansion valve
<a href="#">E2V18FSMC1</a>	Electronic expansion valve
<a href="#">E2V18FWAC1</a>	Electronic expansion valve
<a href="#">E2V18FWFC1</a>	Electronic expansion valve
<a href="#">E2V24FSAC1</a>	Electronic expansion valve
<a href="#">E2V24FSBC1</a>	Electronic expansion valve
<a href="#">E2V24FSFC1</a>	Electronic expansion valve
<a href="#">E2V24FSMC1</a>	Electronic expansion valve
<a href="#">E2V24FWFC1</a>	Electronic expansion valve
<a href="#">E2V30FSAC1</a>	Electronic expansion valve
<a href="#">E2V30FSBC1</a>	Electronic expansion valve
<a href="#">E2V30FSFC1</a>	Electronic expansion valve
<a href="#">E2V30FSMC1</a>	Electronic expansion valve
<a href="#">E2V35FSAC1</a>	Electronic expansion valve
<a href="#">E2V35FSBC1</a>	Electronic expansion valve
<a href="#">E2V35FSFC1</a>	Electronic expansion valve
<a href="#">E2V35FSMC1</a>	Electronic expansion valve
<a href="#">E3V35HWRC0</a>	Odf copper connections, without stator
<a href="#">E3V45BSR10</a>	22-22 Odf copper connections
<a href="#">E3V45BSRC1</a>	Odf copper connections, without stator
<a href="#">E3V45BWR10</a>	7/8"-7/8" Odf copper connections
<a href="#">E3V45BWRC1</a>	Odf copper connections, without stator
<a href="#">E3V45HWRC0</a>	Odf copper connections, without stator
<a href="#">E3V65HWS70</a>	1+1/8"-1+1/8" Odf copper connections, ip67, without sight glass
<a href="#">E3VORI0500</a>	E3v**s spare parts o-rings (20 pcs kit)
<a href="#">E3VORI0600</a>	E3v**s spare parts o-rings (kit for 1 valve)
<a href="#">E3VSTA0200</a>	BIPOLAR ELECTRICAL COIL
<a href="#">E3V35HSR50</a>	copper connections
<a href="#">E3V35SSR40</a>	copper connections
<a href="#">E3V35SSR50</a>	Valve
<a href="#">E3V45HSR10</a>	copper connections
<a href="#">E3V45HSR30</a>	copper connections
<a href="#">E3V45HSR50</a>	copper connections
<a href="#">E3V45HSR70</a>	copper connections
<a href="#">E3V45HWR00</a>	copper connections



Product	Description
<a href="#">E3V45HWR10</a>	copper connections
<a href="#">E3V45HWR30</a>	copper connections
<a href="#">E3V45HWR50</a>	copper connections
<a href="#">E3V45HWR70</a>	copper connections
<a href="#">E3V45SSR00</a>	18-22 Mm copper connections, integral screw, with sight glass
<a href="#">E3V45SSR10</a>	Electronic Expansion Valve
<a href="#">E3V45SSR20</a>	copper connections
<a href="#">E3V45SSR30</a>	copper connections
<a href="#">E3V45SSR50</a>	copper connections
<a href="#">E3V45SSR60</a>	copper connections
<a href="#">E3V45SSR70</a>	copper connections
<a href="#">E3V45SWR00</a>	copper connections
<a href="#">E3V45SWR10</a>	copper connections
<a href="#">E3V45SWR20</a>	copper connections
<a href="#">E3V45SWR30</a>	copper connections
<a href="#">E3V45SWR40</a>	copper connections
<a href="#">E3V45SWR50</a>	Valve
<a href="#">E3V45SWR60</a>	copper connections
<a href="#">E3V45SWR70</a>	copper connections
<a href="#">E3V55HSR10</a>	copper connections
<a href="#">E3V55HSS10</a>	copper connections
<a href="#">E3V55HWR10</a>	copper connections
<a href="#">E3V55SSR00</a>	18-22 Mm copper connections, integral screw, with sight glass
<a href="#">E3V55SSS00</a>	22-28 Mm copper connections, integral screw, with sight glass
<a href="#">E3V55SSS10</a>	22-28 Mm copper connections, integral screw, without sight glass
<a href="#">E3V55SWR00</a>	copper connections
<a href="#">E3V55SWR10</a>	copper connections
<a href="#">E3V65HSS10</a>	Electronic Expansion Valve
<a href="#">E3V65HWS00</a>	copper connections
<a href="#">E3V65HWS10</a>	copper connections
<a href="#">E3V65SSS00</a>	22-28 Mm copper connections, integral screw, with sight glass
<a href="#">E3V65SWS00</a>	copper connections
<a href="#">E3V35BSMC1</a>	Electronic Expansion Valve
<a href="#">E3V45BSM10</a>	16-16 (5/8"-5/8") Odf copper connections
<a href="#">E3V45BSMC1</a>	Electronic Expansion Valve
<a href="#">E3V55BSM10</a>	16-16 (5/8"-5/8") Odf copper connections
<a href="#">E3V55BSMC1</a>	E3v55b 16-16 (5/8"-5/8") odf w/o electrical coil 10 pcs
<a href="#">E3V55BSR10</a>	22-22 Odf copper connections
<a href="#">E3V55BSRC1</a>	E3v55b 22-22 odf w/o electrical coil 10 pcs
<a href="#">E3V55BWR10</a>	7/8"-7/8" Odf copper connections
<a href="#">E3V55BWRC1</a>	E3v55b 7/8"-7/8" odf w/o electrical coil 10 pcs
<a href="#">E3V65BSR10</a>	22-22 Odf copper connections
<a href="#">E3V65BSRC1</a>	E3v65b 22-22 odf w/o electrical coil 10 pcs
<a href="#">E3V65BWR10</a>	7/8"-7/8" Odf copper connections
<a href="#">E3V65BWRC1</a>	E3v65b 7/8"-7/8" odf w/o electrical coil 10 pcs

Product	Description
<a href="#">E3V30CWM00</a>	Electronic exp valve
<a href="#">E3V35CWM00</a>	Electronic exp valve
<a href="#">E3V45CWM00</a>	Electronic exp valve
<a href="#">E3V55CWR00</a>	Electronic exp valve
<a href="#">E3V65CWR00</a>	Electronic exp valve
<a href="#">E4V85BST00</a>	Valve
<a href="#">E4V95BST00</a>	copper connections
<a href="#">E6VA8AWV00</a>	1" 5/8 - 1" 5/8 Odf copper connections, size 180
<a href="#">E7VB4AWV00</a>	1" 5/8 - 1" 5/8 Odf copper connections, size 240
<a href="#">E7VC1ASZ00</a>	54-54 Mm copper connections, size 310
<a href="#">E2VCAB0600</a>	E2V spare parts connector&cable
<a href="#">E2VCAB0900</a>	Cavo e connettore sovrastampato per eev, ip67, lunghezza 9 m
<a href="#">E2VCABS310</a>	Shielded extension cable for unipolar
<a href="#">E2VCABS3U0</a>	Extension wire for unipolar valve 3m with ip67 connector shield
<a href="#">E2VCABS610</a>	cable
<a href="#">E2VCABS6U0</a>	Shielded extension cable for unipolar
<a href="#">E2VCABS900</a>	Shielded cable and connector for exv, ip67, l= 9 m
<a href="#">E2VCABS910</a>	Shielded extension cable for unipolar
<a href="#">E2VCABS9U0</a>	Shielded extension cable for unipolar
<a href="#">E2VCABSA50</a>	E2V spare parts con.&Cable shielded over.Assembly 15m ip67
<a href="#">E2VJUNC000</a>	sae-flare brass connector
<a href="#">E4V85HST10</a>	E4v-85b 28-35 mm copper connections, for hot gas
<a href="#">E4V85HWT10</a>	odf copper connections
<a href="#">E4V95HST10</a>	E4v-95b 28-35 mm copper connections, for hot gas
<a href="#">E4V95HWT10</a>	1/8-1" 3/8 odf copper connections, for hot gas
<a href="#">E2BR00SF00</a>	El.Exp.Valve e2vz 12-12 odf - body only - with sight-glass
<a href="#">E2BR00SF01</a>	Valve
<a href="#">E2BR00SF10</a>	El.Exp.Valve e2vz 12-12 odf - body only - w/o sight-glass
<a href="#">E2BR00SF11</a>	Valve
<a href="#">E2BR00SM00</a>	Valve
<a href="#">E2BR00SM01</a>	Valve
<a href="#">E2BR00SM10</a>	Valve
<a href="#">E2BR00SM11</a>	Valve
<a href="#">E2BR00WF00</a>	Valve
<a href="#">E2BR00WF01</a>	Valve
<a href="#">E2BR00WF10</a>	Valve
<a href="#">E2BR00WF11</a>	Valve
<a href="#">E2VATT03Z0</a>	E2V-s spare parts actuator with orifice integrated e2v03z
<a href="#">E2VATT03Z1</a>	E2V-s spare parts actuator
<a href="#">E2VATT05S0</a>	E2V-s spare parts actuator for e2v05s*
<a href="#">E2VATT05Z0</a>	E2V-s spare parts actuator with orifice integrated e2v05z
<a href="#">E2VATT05Z1</a>	E2V-s spare parts actuator
<a href="#">E2VATT09S0</a>	Expansion Valve Body
<a href="#">E2VATT09Z0</a>	E2V-s spare parts actuator with orifice integrated e2v09z
<a href="#">E2VATT09Z1</a>	E2V-s spare parts actuator

Product	Description
<a href="#">E2VATT11S0</a>	Expansion Valve Body
<a href="#">E2VATT11Z0</a>	E2V-s spare parts actuator with orifice integrated e2v11z
<a href="#">E2VATT11Z1</a>	E2V-s spare parts actuator
<a href="#">E2VATT14S0</a>	Expansion Valve Body
<a href="#">E2VATT14Z0</a>	E2V-s spare parts actuator with orifice integrated e2v14z
<a href="#">E2VATT14Z1</a>	E2V-s spare parts actuator
<a href="#">E2VATT18S0</a>	Expansion Valve Body
<a href="#">E2VATT18Z0</a>	E2V-s spare parts actuator with orifice integrated e2v18z
<a href="#">E2VATT18Z1</a>	E2V-s spare parts actuator
<a href="#">E2VATT24S0</a>	Expansion Valve Body
<a href="#">E2VATT24Z0</a>	E2V-s spare parts actuator with orifice integrated e2v24z
<a href="#">E2VATT24Z1</a>	E2V-s spare parts actuator
<a href="#">E2VATT30S0</a>	Expansion Valve Body
<a href="#">E2VATT30Z0</a>	E2V-s spare parts actuator with orifice integrated e2v30z
<a href="#">E2VATT30Z1</a>	E2V-s spare parts actuator
<a href="#">E2VATT35S0</a>	Expansion Valve Body
<a href="#">E2VATT35Z0</a>	E2V-s spare parts actuator with orifice integrated e2v35z
<a href="#">E2VATT35Z1</a>	E2V-s spare parts actuator
<a href="#">E2VFIL0000</a>	Filter for e2v**brb, bz0, 500um, multiple package (10 pcs)
<a href="#">E2VFIL0100</a>	Filter
<a href="#">E2VFIL0200</a>	Filter
<a href="#">E2VFIL0300</a>	kit filter for valve
<a href="#">E2VFIL0400</a>	Filter Kit for E2V Valves
<a href="#">E2VFIL0500</a>	Filter Kit for E2V Valves
<a href="#">E2VNUT0200</a>	fastening nut
<a href="#">E2VNUT0300</a>	fastening nut
<a href="#">E2VORI0000</a>	gasket kit
<a href="#">E2VORI0100</a>	Teflon gaskets and o-rings
<a href="#">E2VSGH0000</a>	Sight glass
<a href="#">E2VSTA0200</a>	coil
<a href="#">E2VSTA0201</a>	Stator bipolar for e2v%b 10pz
<a href="#">E2VSTA0310</a>	Stator unipolar da 1m for e2v%u
<a href="#">E2VSTA0311</a>	Stator unipolar da 1m for e2v%u 10pz
<a href="#">E2VSTA0320</a>	Stator unipolar da 2m for e2v%u
<a href="#">E2VSTA0321</a>	Electrical Coil for E2V Valves
<a href="#">E2VSTA0330</a>	cable
<a href="#">E2VSTA0331</a>	cable
<a href="#">E2VSTA0370</a>	Stator unipolar oem cable 0,7m per e2v%u+e2v%f 1 pz
<a href="#">E2VSTA0371</a>	Stator unipolar oem cable 0,7m per e2v%u+e2v%f 10 pz
<a href="#">E2VSTAS220</a>	connector
<a href="#">E2VSTAS221</a>	connector
<a href="#">E2VSTAS230</a>	Bipolar stator hermetic
<a href="#">E2VSTAS231</a>	connector
<a href="#">E3VATT30C0</a>	actuator
<a href="#">E3VATT35C0</a>	E3v actuator for e3v35c*

Product	Description
<a href="#">E3VATT35S0</a>	E3v-s spare parts actuator for e3v35s*
<a href="#">E3VATT4500</a>	E3v actuator for e3v45a*
<a href="#">E3VATT45C0</a>	E3v actuator for e3v45c*
<a href="#">E3VATT45S0</a>	E3v-s spare parts actuator for e3v45s*
<a href="#">E3VATT5500</a>	E3v actuator for e3v55a*
<a href="#">E3VATT55C0</a>	E3v actuator for e3v55c*
<a href="#">E3VATT55S0</a>	E3v-s spare parts actuator for e3v55s*
<a href="#">E3VATT6500</a>	E3v actuator for e3v65a*
<a href="#">E3VATT65C0</a>	E3v actuator for e3v65c*
<a href="#">E3VATT65S0</a>	E3v-s spare parts actuator for e3v65s*
<a href="#">E3VFIL0000</a>	Filter for e3v**s, 150 um, 10 pcs kit
<a href="#">E3VFIL0100</a>	Filter for e3v**c, 10 pcs kit
<a href="#">E3VORI0000</a>	E3v spare parts o-rings (20 pcs kit)
<a href="#">E3VORI0100</a>	E3v spare parts o-rings (kit for 1 valve)
<a href="#">E3VORI0300</a>	E3v**c spare parts o-rings (kit for 1 valve)
<a href="#">E3VSTA0000</a>	E3v spare parts stator (coil) for e3v**a*
<a href="#">E3VSTA0201</a>	coil
<a href="#">E3VSTA0311</a>	Unip electrical coil 1m e3v-b, e3v-c, e3v-s, e3v-h 10pcs
<a href="#">E3VSTA0321</a>	Unip electrical coil 2m e3v-b, e3v-c, e3v-s, e3v-h 10pcs
<a href="#">E3VSTA0331</a>	Unip electrical coil 0,3m e3v-b, e3v-c, e3v-s, e3v-h 10pcs
<a href="#">E4VATT8500</a>	E4v actuator for e4v85a* and e4v85b*
<a href="#">E4VATT9500</a>	Valve drive
<a href="#">E4VNUT0000</a>	fastening nut
<a href="#">E4VORI0000</a>	E4v spare parts o-rings (20 pcs kit)
<a href="#">E4VSGH0000</a>	Sight glass for e4v, e5v, e6v, e7v
<a href="#">E4VSGH0010</a>	Sight glass with moisture indicator for e4v, e5v, e6v, e7v
<a href="#">E4VSTA0000</a>	E4v spare parts stator (coil) for e4v*
<a href="#">E5VATT0000</a>	E5v actuator for e5va*
<a href="#">E5VATTA200</a>	E5v actuator for e5va2*
<a href="#">E5VORI0000</a>	E5v spare parts o-rings (20 pcs kit)
<a href="#">E5VORI0100</a>	E5v spare parts o-rings (kit for 1 valve)
<a href="#">E5VSTA0000</a>	E5v spare parts stator (coil) for e5v**a*
<a href="#">E6VATTA800</a>	E6v actuator for e6va8a* rev. 1.1
<a href="#">E6VATTB200</a>	E6v actuator for e6vb2a*
<a href="#">E6VATTB210</a>	E6v actuator for e6vb2a* rev. 1.1
<a href="#">E6VORI0100</a>	o-rings - set
<a href="#">E6VSTA0000</a>	coil
<a href="#">E6VSTA0001</a>	E6v**a* coil - multiple pack. No.10 Pcs
<a href="#">E7BR00TW00</a>	Body brased double e7vtwin 3" x 3" odf - only body
<a href="#">E7VATTB400</a>	E7v actuator for e7vb4a*
<a href="#">E7VATTC100</a>	E7v actuator for e7vc1a*
<a href="#">E7VATTC101</a>	E7vc1a* actuator - multiple pack. No.5 Pcs
<a href="#">E7VORI0000</a>	o-rings
<a href="#">E7VSTA0000</a>	E7v spare parts: stator (coil) for e7v**a*
<a href="#">E7VSTA0001</a>	E7v**a* coil - multiple pack. No.10 Pcs

Product	Description
<a href="#">EVBAT00200</a>	EVD battery step-up module (ver.2)
<a href="#">EVBATBOX00</a>	EVD battery din-rail box (ver.1)
<a href="#">EVD0000401</a>	EVD400 universal (tlan) packagemultiple 10pz.
<a href="#">EVD0000411</a>	EVD400 universal (plan) packagemultiple 10pz.
<a href="#">EVD0000420</a>	EVD400 universal (rs485)
<a href="#">EVD0000421</a>	EVD400 universal (rs485) packagemultiple 10pz.
<a href="#">EVD0000430</a>	EVD400 for valves carel (tlan)
<a href="#">EVD0000431</a>	EVD400 for valves carel (tlan) imb.Multiple 10pz.
<a href="#">EVD0000440</a>	EVD400 for valves carel (plan)
<a href="#">EVD0000441</a>	EVD400 for valves carel (plan) imb. Mult.10Pz.
<a href="#">EVD0000450</a>	EVD400 for valves carel (rs485)
<a href="#">EVD0000451</a>	EVD400 for valves carel (rs485) imb. Mult.10 Pz.
<a href="#">EVD0001400</a>	EVD400 universal (tlan) with faston
<a href="#">EVD0001401</a>	EVD400 universal (tlan) packagemultiple 10 pz with faston
<a href="#">EVD0001410</a>	EVD400 universal (plan) with faston
<a href="#">EVD0001411</a>	EVD400 universal (plan) packagemultiple 10 pz with faston
<a href="#">EVD0001420</a>	EVD400 universal (rs485) with faston
<a href="#">EVD0001421</a>	EVD400 universal (rs485) packagemultiple 10 pz with faston
<a href="#">EVD0001430</a>	EVD400 per eev carel (tlan) with faston
<a href="#">EVD0001431</a>	EVD Evolution Driver for Electronic Expansion Valves
<a href="#">EVD0001440</a>	EVD Evolution Driver for Electronic Expansion Valves
<a href="#">EVD0001441</a>	EVD400 per eev carel (plan) packagemultiple 10 pz with faston
<a href="#">EVD0001450</a>	EVD400 per eev carel (rs485) with faston
<a href="#">EVD0001451</a>	EVD Evolution Driver for Electronic Expansion Valves
<a href="#">EVD0001460</a>	EVD400 universal (modbus) with faston
<a href="#">59C545A003</a>	Kit cables per conn.Batt.Per evbat200
<a href="#">EVBAT00300</a>	EVD battery step-up module + pack (ver.2)
<a href="#">EVDCA00500</a>	Kit 14 cavi evd400 l=5m sez.1Mmq
<a href="#">EVDCON0001</a>	EVD400 connector kit - multiple package 10pz
<a href="#">EVDCON0011</a>	connector
<a href="#">EVDKEY0000</a>	Chiave di programmazione per evd400
<a href="#">EVD0000E11</a>	Universal (plan) multiple package 10 pcs
<a href="#">EVD0000E31</a>	Driver For TPB
<a href="#">EVD0000E41</a>	For carel valve (plan) multiple package 10 pcs
<a href="#">EVD0002E10</a>	Universal (plan), optoinsulated
<a href="#">EVD0002E20</a>	Universal, optoinsulated
<a href="#">EVD00W0E50</a>	EVD evo single carel exv with ultracap, rs 485
<a href="#">EVDCON0021</a>	Connectors kit (10 pcs)
<a href="#">EVDIS00CN0</a>	In chinese
<a href="#">EVDIS00CZ0</a>	In czech
<a href="#">EVDIS00ES0</a>	In spanish
<a href="#">EVDIS00FR0</a>	In french
<a href="#">EVDIS00PL0</a>	Display per evd evolution, polacco
<a href="#">EVDIS00RU0</a>	In russian
<a href="#">EVDIS00SE0</a>	In swedish

Product	Description
<a href="#">EVD0000T00</a>	Universal twin, for two valves (tlan)
<a href="#">EVD0000T01</a>	twin for two valves
<a href="#">EVD0000T10</a>	Universal twin for two valves (plan)
<a href="#">EVD0000T11</a>	twin for two valves
<a href="#">EVD0000T30</a>	Twin for two carel valves (tlan)
<a href="#">EVD0000T31</a>	Twin for two carel valves
<a href="#">EVD0000T41</a>	Twin for two carel valves (plan) multiple package 10 pcs
<a href="#">EVD00N3E5K</a>	Kit exv, for carel valve 0 to 10 bar without valve
<a href="#">EVDM001N00</a>	EVD Mini Driver
<a href="#">EVDM001N01</a>	24 V with display, multiple package 20 pcs
<a href="#">EVDM011N01</a>	EVD Mini Driver for Unipolar Electronic Expansion Valves
<a href="#">EVDMU00N01</a>	Ultracap module for evd mini
<a href="#">EDVPN01001</a>	With evd0000e30 tlan
<a href="#">EDVPN01002</a>	With evd0000e30 tlan, ultracap
<a href="#">EDVPN01003</a>	With evd0000e50 rs485/modbus®
<a href="#">EDVPN01004</a>	With evd0000e50 rs485/modbus®, with ultracap
<a href="#">EDVPN01007</a>	With evd0000e50 rs485/modbus®, with terminal blocks
<a href="#">EDVPN01008</a>	With evd0000e50 rs485/modbus®, with ultracap, with terminal blocks
<a href="#">EDVPN02005</a>	With evd0000t50 twin rs485/modbus
<a href="#">EDVPN02006</a>	With evd0000t50 twin rs485/modbus with ultracap
<a href="#">FCPM00A01K</a>	Ultracap Emergency Power Supply Module
<a href="#">FCPM00A02K</a>	Ultracap Emergency Power Supply Module
<a href="#">FCPM00C01K</a>	Ultracap Emergency Power Supply Module
<a href="#">FCPM0420A0</a>	Fan speed controller
<a href="#">FCPM082010</a>	Fan speed controller
<a href="#">FCPM082A10</a>	Fan speed controller
<a href="#">FCR3064020</a>	FCR3 Three-Phase Speed Controller with Modbus RS485 Serial Connection
<a href="#">FCR3094040</a>	Up to 9 a
<a href="#">FCR3404020</a>	Up to 40 a
<a href="#">FCSM0423L0</a>	Single-Phase Fan Speed Controller
<a href="#">FCSM082300</a>	Speed controller
<a href="#">FCSM122300</a>	ventilator
<a href="#">FCSM1223L0</a>	Speed controller
<a href="#">FCS3094010</a>	Up to 9 a
<a href="#">FCS3124010</a>	Three-Phase Fan Speed Controller
<a href="#">FCS3204010</a>	fan speed controller
<a href="#">FCS3122300</a>	Reg.V.Taglio trif.230V 12a
<a href="#">MCHRTF08E0</a>	Single-Phase Fan Speed Controller
<a href="#">MCHRTF10C0</a>	Up to 10 a
<a href="#">MCHRTF10C1</a>	Up to 10 a multiple package (10 pcs)
<a href="#">MCHRTF12C0</a>	Up to 12 a
<a href="#">MCHRTF12E0</a>	12A/230 Vac, compliance with indust. Stds
<a href="#">DN33V7HB20</a>	1 Relay version, 115 to 230 Vac, rtc



Product	Description
<a href="#">DN33V7HR20</a>	1 Relay version, 115 to 230 Vac
<a href="#">DN33V7LR20</a>	Relay
<a href="#">DN33V9HB20</a>	1 Relay version, 115 to 230 Vac, rtc
<a href="#">DN33V9HR20</a>	1 Relay version, 115 to 230 Vac
<a href="#">DN33V9MR20</a>	1 Relay version, 24 Vac/Vdc
<a href="#">DN33W7HB20</a>	2 Relays version, 115 to 230 Vac, rtc
<a href="#">DN33W7HR20</a>	2 Relays version, 115 to 230 Vac
<a href="#">DN33W7LR20</a>	Relay
<a href="#">DN33W9HB20</a>	2 Relays version, 115 to 230 Vac, rtc
<a href="#">DN33W9HR20</a>	2 Relays version, 115 to 230 Vac
<a href="#">DN33W9MR20</a>	2 Relays version, 24 Vac/Vdc
<a href="#">DN33Z7HB20</a>	IR33 Universal Controller
<a href="#">DN33Z9HB20</a>	4 Relays version, 115 to 230 Vac, rtc
<a href="#">DN33Z9HR20</a>	4 Relays version, 115 to 230 Vac
<a href="#">DN33Z9MR20</a>	4 Relays version, 24 Vac/Vdc
<a href="#">DN33B7HB20</a>	1 Relay + 1 output
<a href="#">DN33B7HR20</a>	1 Relay + 1 output 0 to 10 v version, 115 to 230 Vac
<a href="#">DN33B9HB20</a>	1 Relay + 1 output
<a href="#">DN33B9HR20</a>	1 Relay + 1 output 0 to 10 v version, 115 to 230 Vac
<a href="#">DN33B9MR20</a>	Relay
<a href="#">DN33E7HB20</a>	2 Relays + 2 output
<a href="#">DN33E7HR20</a>	2 Relays + 2 output 0 to 10 v version, 115 to 230 Vac
<a href="#">DN33E7LR20</a>	2 Relays + 2 output
<a href="#">DN33E9HB20</a>	2 Relays + 2 output
<a href="#">DN33E9HR20</a>	2 Relays + 2 output 0 to 10 v version, 115 to 230 Vac
<a href="#">DN33E9MR20</a>	2 Relays + 2 output
<a href="#">DN33A7LR20</a>	DIN Rail Mounted Temperature Controller
<a href="#">DN33A9HB20</a>	4 Ssr version, 115 to 230 Vac, rtc
<a href="#">DN33A9HR20</a>	4 Ssr version, 115 to 230 Vac
<a href="#">DN33A9MR20</a>	4 Ssr version, 24 Vac/Vdc
<a href="#">IR33V7HB20</a>	1 Relay version, 115 to 230 Vac, rtc
<a href="#">IR33V9HB20</a>	1 Relay version, 115 to 230 Vac, rtc
<a href="#">IR33V9HR20</a>	Panel-Mounted Temperature Controller
<a href="#">IR33V9MR20</a>	Universal Panel-Mounted Temperature Controller
<a href="#">IR33W7HB20</a>	2 Relays version, 115 to 230 Vac, rtc
<a href="#">IR33W9HB20</a>	2 Relays version, 115 to 230 Vac, rtc
<a href="#">IR33W9HR20</a>	Universal Panel-Mounted Temperature Controller with Dual Relays
<a href="#">IR33Z7HB20</a>	4 Relays version, 115 to 230 Vac, rtc
<a href="#">IR33Z9HB20</a>	4 Relays version, 115 to 230 Vac, rtc
<a href="#">IR33Z9HR20</a>	Temperature regulator
<a href="#">IR33B7HB20</a>	1 Relay + 1 output
<a href="#">IR33B7HR20</a>	1 Relay + 1 output 0 to 10 v version, 115 to 230 Vac
<a href="#">IR33B9HB20</a>	1 Relay + 1 output

Product	Description
<a href="#">IR33B9HR20</a>	Universal Panel-Mounted Temperature Controller with Relay and Analog Output
<a href="#">IR33E7HB20</a>	2 Relays + 2 output
<a href="#">IR33E7HR20</a>	Universal Panel-Mounted Temperature Controller with Dual Relays and Analog Outputs
<a href="#">IR33E7LR20</a>	2 Relays + 2 output
<a href="#">IR33E9HB20</a>	2 Relays + 2 output
<a href="#">IR33E9HR20</a>	Universal Panel-Mounted Temperature Controller with Dual Relays and Analog Outputs
<a href="#">IR33E9MR20</a>	Universal Panel-Mounted Temperature Controller with Dual Relays and Analog Outputs
<a href="#">IRTRUE000</a>	Remote control for ir33 universal
<a href="#">IR33A7HB20</a>	4 Ssr version, 115 to 230 Vac, rtc
<a href="#">IR33A7HR20</a>	4 Ssr version, 115 to 230 Vac
<a href="#">IR33A9HB20</a>	4 Ssr version, 115 to 230 Vac, rtc
<a href="#">IR33A9HR20</a>	4 Ssr version, 115 to 230 Vac
<a href="#">IR33A9MR20</a>	4 Ssr version, 24 Vac/Vdc
<a href="#">BMESTPWA00</a>	Boss-mini power plug kit (multi countries)
<a href="#">BMHSTDNA0K</a>	Boss din rail mounting kit (2 brackets + screws)
<a href="#">BMHSTMDA00</a>	Modem umts usb for boss
<a href="#">BMHSTMNA00</a>	Monitor touch 17" for boss
<a href="#">BMHSTPWA00</a>	Accessory box for boss (bmh*)
<a href="#">BMHSC00XE0</a>	monitoring system
<a href="#">BMHSC00XS0</a>	monitoring system
<a href="#">BMHST00XE0</a>	Extended box (300 devices)
<a href="#">BMHST00XS0</a>	Standard box (100 devices)
<a href="#">BMHST03XE0</a>	monitoring system
<a href="#">BMHST03XS0</a>	monitoring system
<a href="#">BMHST09XE0</a>	monitoring system
<a href="#">BMHST09XS0</a>	monitoring system
<a href="#">BMHST01P00</a>	Credit for activation of 1 boss plug-in
<a href="#">BMHST03P00</a>	Credit for activation of 3 boss plug-in
<a href="#">BMHST05P00</a>	Credit for activation of 5 boss plug-in
<a href="#">PLO550L30UB00</a>	Large version, pgd1 built-in, rs485 built in, connectors kit
<a href="#">PLO550X30U000</a>	connectors kit
<a href="#">GTW0000BT0</a>	Gatewa serial rs485/ttl to bluetooth,transparent mode
<a href="#">GTW0000WT0</a>	Gateway serial rs485/ttl to wifi transparent mode
<a href="#">IOM0002400</a>	24 Vac i/o module
<a href="#">IOM0011500</a>	115 Vac i/o module
<a href="#">IOM0023000</a>	230 Vac i/o module
<a href="#">PCH550L31UB00</a>	connectors kit
<a href="#">PCH550S31UB00</a>	connectors kit
<a href="#">BMEST00RE0</a>	Boss-mini supervisor headless box- extended (50 devices)
<a href="#">BMEST00RS0</a>	boss-mini Standard Supervisor
<a href="#">BMEST03RE0</a>	boss-mini Extended Supervisor

Product	Description
<a href="#">BMEST03RS0</a>	boss-mini Standard Supervisor
<a href="#">BMEST01P00</a>	Credit of 1 plug-in for boss-mini
<a href="#">BMEST03P00</a>	Credit of 3 plug-in for boss-mini
<a href="#">BMEST00LE0</a>	Boss-mini supervisor wi-fi/hdmi box- extended (50 devices)
<a href="#">BMEST03LE0</a>	boss-mini Supervisor with Wi-Fi and HDMI
<a href="#">UCHCOND010</a>	Conn. And cable kit uchiller din molex/free 100cm
<a href="#">UCHCONP010</a>	Cables
<a href="#">UCHBD00001130</a>	Uchiller, din mounting
<a href="#">UCHBD00N01131</a>	Uchiller, din neutral, multiple package (10 pcs)
<a href="#">UCHBDE0N01141</a>	Uchiller enhanced, din neutral, multiple package (10 pcs)
<a href="#">UCHBE00001130</a>	Uchiller io exp for second circuit
<a href="#">UCHBE00N01131</a>	Uchiller
<a href="#">UCHBE00N01141</a>	Uchiller
<a href="#">MCH2000040</a>	Controller
<a href="#">MCH200TP00</a>	µC2 remote terminal for panel, flush-mount installation + power supply module
<a href="#">MCH3000001</a>	MCH3 firmware roca without plastic multi package 18 pcs.
<a href="#">MCH3010001</a>	MCH3 without plastic multi package 18pcs.
<a href="#">MCH3010020</a>	MCH3 with full cover plastic single package
<a href="#">MCH300CAB0</a>	MCH3 cable kit 2m single package (only for one mch3)
<a href="#">MCH3CON000</a>	MCH3 connector kit single package
<a href="#">MCH3CON001</a>	MCH3 connector kit multi package 18 pcs.
<a href="#">MCH300KYA0</a>	MCH3 programming key
<a href="#">MCHSMLKEY0</a>	Chiave hard.Microch.Compact
<a href="#">MCHSMLSER0</a>	Conv.Ser.Rs485+rem.MCH.Comp
<a href="#">MCHSMLC100</a>	Kit 24cavi l=1m. +Coppia conn.12V-14v
<a href="#">MCHSMLC200</a>	Kit 24cavi l=2mt. +Coppia conn.12V-14v
<a href="#">MCHSMLC300</a>	Kit 24cavi l=3mt. +Coppia conn.12V-14v
<a href="#">MCHSMLCAB3</a>	Kit 24cavi x mch-mpx l=3mt. Sez.1Mmq.
<a href="#">MCHSMLCONM</a>	Kit sup.Conn.Fem.No ter. lmb.Multipli=20pz.
<a href="#">AX5000PD20A31</a>	Display
<a href="#">AX5100PD20A31</a>	Display for uchiller
<a href="#">AX5000PD20A20</a>	Display for uchiller, nfc
<a href="#">AX5000PD20A21</a>	Display for uchiller, nfc, multiple package (20 pcs)
<a href="#">AX5100PD20A21</a>	Display for uchiller neutral, nfc, multiple package (20 pcs)
<a href="#">UCHBP00000090</a>	Uchiller, panel, nfc
<a href="#">UCHBP00N00091</a>	Uchiller, panel neutral, nfc, multiple package (20 pcs)
<a href="#">UCHBP00N00101</a>	Uchiller, panel neutral, nfc, bte, multiple package (20 pcs)
<a href="#">CONV0/1L00</a>	Power supply module
<a href="#">RTA200A230</a>	RTA 2mod.-35/-5 230V
<a href="#">RTA200B230</a>	Thermostat
<a href="#">RTA200C230</a>	refrigerator thermostat
<a href="#">RTA200D230</a>	RTA 2mod. 35/65 230V
<a href="#">RTA200G230</a>	RTA 2mod.+5/15 230Vac diff. 1/20G.C.
<a href="#">RTA200B024</a>	RTA 2mod. -10/20 24V

Product	Description
<a href="#">RTA202E024</a>	RTA 2mod.Reset manual-20/10 24Vac
<a href="#">RTA202E230</a>	RTA 2mod.Reset manual-20/10 230Vac
<a href="#">RTA202F230</a>	RTA 2mod.Reset manual.65/95 230Vac
<a href="#">RTA202H230</a>	RTA 2mod. Manual reset fixed set 43c 230Vac
<a href="#">PSC550M000</a>	Seasoning control medium - usb
<a href="#">PSC550S000</a>	Seasoning control small - usb
<a href="#">P+D0CON0B0</a>	Terminal block
<a href="#">P+P0CON1E0</a>	Removable Spring Connectors Kit for c.pCO Mini
<a href="#">S90CONN001</a>	Cable l= 3 m, telephone connectors
<a href="#">S90CONN0S0</a>	Telephone cable
<a href="#">PCOX000AA0</a>	pCO compact 7 relays, 2 aout
<a href="#">PCOX000AB0</a>	pCO compact 6 relays, 4 aout
<a href="#">PCOX000CB0</a>	pCO compact 6 relays, 4 aout, usb
<a href="#">PCOX002AA0</a>	pCO compact 5 relays, 2 ssr, 2 aout
<a href="#">PCOX002AB0</a>	pCO compact 4 relays, 2 ssr, 4 aout
<a href="#">PCOX0N0AA0</a>	pCO compact 7 relays, 2 aout, neutral
<a href="#">PCOXCON0A0</a>	Removable screw connectors kit
<a href="#">PCOXCON0B0</a>	Removable screw connectors kit
<a href="#">PCOXCON1A0</a>	Removable spring connectors kit for pco compact type a
<a href="#">PCOX000BA0</a>	pCO compact 7 relays, 2 aout, pgd1 built-in display
<a href="#">PCOX000BB0</a>	pCO compact 6 relays, 4 aout, pgd1 built-in display
<a href="#">PCOX000DB0</a>	pCO compact 6 relays, 4 aout, pgd1 built-in display, usb
<a href="#">PCOX002BA0</a>	pCO compact 5 relays, 2 ssr, 2 aout, pgd1 built-in display
<a href="#">PCOX002BB0</a>	pCO compact 4 relays, 2 ssr, 4 aout, pgd1 built in
<a href="#">PCO1000CX0</a>	pCO1 xs (2m or 1m + 1m for historical data)
<a href="#">PCO1002AX0</a>	pCO1 8 mod.DIN, 2ssr
<a href="#">PCO1002CX0</a>	pCOxs 2mb 2 ssr
<a href="#">PCO10N0AX0</a>	pCOxs 1mb with neutral plate
<a href="#">PCO10N0CX0</a>	pCOxs 1+1 mb with neutral plate
<a href="#">PCO1002BX0</a>	pCO1 8 mod.DIN, 2ssr lcd built-in
<a href="#">PCO1002DX0</a>	pCOxs 2mb built-in terminal, 2 ssr
<a href="#">PCO10N0BX0</a>	pCOxs 1mb con placchetta neutra
<a href="#">PCO10N0DX0</a>	pCO1 1+1 mb con placchetta neutra
<a href="#">P+500B0A000Z0</a>	Extralarge version
<a href="#">P+500B0A200Z0</a>	Extralarge version, 2 ssr 24 v
<a href="#">P+500B0A400Z0</a>	pCO5+ extralarge, fb/bms no opto, no usb, 4 ssr 24v
<a href="#">P+500B0AB00Z0</a>	Extralarge version, 2 ssr 230 v
<a href="#">P+500B0B000Z0</a>	Extralarge version
<a href="#">P+500B0C000Z0</a>	Extralarge version
<a href="#">P+500BAA000Z0</a>	Extralarge version, usb port
<a href="#">P+500BAA200Z0</a>	Extralarge version, 2 ssr 24 v, usb port
<a href="#">P+500BAAB00Z0</a>	Extralarge version, 2 ssr 230 v, usb port
<a href="#">P+500BAB000Z0</a>	Extralarge version, usb port
<a href="#">P+500BAC000Z0</a>	Extralarge version, usb port
<a href="#">P+500B0A00EZ0</a>	Extralarge version, pgd1 built-in

Product	Description
<a href="#">P+500B0B00EZ0</a>	Extralarge version, pgd1 built-in
<a href="#">P+500B0C00EZ0</a>	Extralarge version, pgd1 built-in
<a href="#">P+500BAA00EZ0</a>	Extralarge version, usb port, pgd1 built-in
<a href="#">P+500BAB00EZ0</a>	Extralarge version, usb port, pgd1 built-in
<a href="#">P+500BAC00EZ0</a>	Extralarge version, usb port, pgd1 built-in
<a href="#">P+500B0A300L0</a>	Large version, 3 ssr 24 v
<a href="#">P+500B0A400L0</a>	Large version, 4 ssr 24 v, no usb port
<a href="#">P+500B0AC00L0</a>	Large version, 3 ssr 230 v
<a href="#">P+500B0B000L0</a>	Large version
<a href="#">P+500B0B300L0</a>	Large version, 3 ssr 24 v
<a href="#">P+500B0C000L0</a>	Large version
<a href="#">P+500BAA300L0</a>	Large version, 3 ssr 24 v, usb port
<a href="#">P+500BAAC00L0</a>	Large version, 3 ssr 230 v, usb port
<a href="#">P+500BAB000L0</a>	Large version, usb port
<a href="#">P+500BAC000L0</a>	Large version, usb port
<a href="#">P+50NB0A000L0</a>	pCO5+ large, fb/bms no opto, neutral
<a href="#">P+50NBAA000L0</a>	pCO5+ large, fb/bms no opto, usb, neutral
<a href="#">P+500B0B00EL0</a>	Large version, pgd1 built-in
<a href="#">P+500B0C00EL0</a>	Large version, pgd1 built-in
<a href="#">P+500BAA00EL0</a>	Large version, usb port, pgd1 built-in
<a href="#">P+500BAB00EL0</a>	controller
<a href="#">P+500BAC00EL0</a>	Large version, usb port, pgd1 built-in
<a href="#">P+50NB0A00EL0</a>	pCO5+ large, fb/bms no opto, pgd1 built in, neutral
<a href="#">P+500B0A000M0</a>	Control board
<a href="#">P+500B0A200M0</a>	Controller
<a href="#">P+500B0AB00M0</a>	Medium version, 2 ssr 230 v, usb port
<a href="#">P+500B0B000M0</a>	Medium version
<a href="#">P+500B0B200M0</a>	Medium version, 2 ssr 24 v
<a href="#">P+500B0C000M0</a>	Medium version
<a href="#">P+500BAA000M0</a>	c.pCO Medium Controller
<a href="#">P+500BAA200M0</a>	Medium version, 2 ssr 24 v, usb port
<a href="#">P+500BAAB00M0</a>	Medium version, 2 ssr 230 v, usb port
<a href="#">P+500BAAB50M0</a>	c.pCO Medium Controller with Embedded EVD EVO Driver
<a href="#">P+500BAB000M0</a>	Medium version, usb port
<a href="#">P+500BAB200M0</a>	Medium version, 2 ssr 24 v, usb port
<a href="#">P+500BAC000M0</a>	Medium version, usb port
<a href="#">P+50NB0A000M0</a>	pCO5+ medium, fb/bms no opto, neutral
<a href="#">P+50NBAA000M0</a>	pCO5+ medium, fb/bms no opto, usb, neutral
<a href="#">P+500B0A010M0</a>	PCO5plus Programmable Controller
<a href="#">P+500B0A020M0</a>	Medium version, evd evo embedded for 2 carel exv
<a href="#">P+500B0A050M0</a>	Medium version, evd evo embedded for 1 universal exv
<a href="#">P+500B0A060M0</a>	Medium version, evd evo embedded for 2 universal exv
<a href="#">P+500B0A210M0</a>	Medium version, evd evo embedded for 1 carel exv, 2 ssr 24 v
<a href="#">P+500B0A220M0</a>	Medium version, evd evo embedded for 2 carel exv, 2 ssr 24 v
<a href="#">P+500B0A250M0</a>	c.pCO Medium Controller with Enhanced Connectivity

Product	Description
<a href="#">P+500B0A260M0</a>	c.pCO Medium Controller with Integrated EVD EVO Driver
<a href="#">P+500B0AB10M0</a>	Medium version, evd evo embedded for 1 carel exv, 2 ssr 230 v
<a href="#">P+500B0AB20M0</a>	Medium version, evd evo embedded for 2 carel exv, 2 ssr 230 v
<a href="#">P+500B0AB50M0</a>	c.pCO Medium Controller with Embedded EVD EVO Driver
<a href="#">P+500B0AB60M0</a>	c.pCO Medium Controller with Embedded EVD EVO Driver for 2 EXVs
<a href="#">P+500B0B010M0</a>	Medium version, evd evo embedded for 1 carel exv
<a href="#">P+500B0B020M0</a>	Medium version, evd evo embedded for 2 carel exv
<a href="#">P+500B0B050M0</a>	Medium version, evd evo embedded for 1 universal exv
<a href="#">P+500B0B060M0</a>	Medium version, evd evo embedded for 2 universal exv
<a href="#">P+500B0C010M0</a>	Medium version, evd evo embedded for 1 carel exv
<a href="#">P+500B0C020M0</a>	Medium version, evd evo embedded for 2 carel exv
<a href="#">P+500B0C050M0</a>	Medium version, evd evo embedded for 1 universal exv
<a href="#">P+500B0C060M0</a>	Medium version, evd evo embedded for 2 universal exv
<a href="#">P+500BAA010M0</a>	Medium version, evd evo embedded for 1 carel exv, usb port
<a href="#">P+500BAA020M0</a>	Medium version, evd evo embedded for 2 carel exv, usb port
<a href="#">P+500BAA050M0</a>	Medium version, evd evo embedded for 1 universal exv, usb port
<a href="#">P+500BAA060M0</a>	Medium version, evd evo embedded for 2 universal exv, usb port
<a href="#">P+500BAA210M0</a>	c.pCO Medium Controller with Enhanced Connectivity
<a href="#">P+500BAA220M0</a>	c.pCO Medium Controller with Embedded EVD EVO Driver for 2 EXVs
<a href="#">P+500BAA250M0</a>	c.pCO Medium Controller with Enhanced Connectivity
<a href="#">P+500BAA260M0</a>	c.pCO Medium Controller with Integrated EVD EVO Driver for 2 EXVs
<a href="#">P+500BAAB10M0</a>	c.pCO Medium Controller with Embedded EVD EVO Driver for 1 Carel EXV
<a href="#">P+500BAAB20M0</a>	c.pCO Medium Controller with Embedded EVD EVO Driver for 2 Carel EXVs
<a href="#">P+500BAAB60M0</a>	c.pCO Medium Controller with Embedded EVD EVO Driver for 2 Universal EXVs
<a href="#">P+500BAB010M0</a>	Medium version, evd evo embedded for 1 carel exv, usb
<a href="#">P+500BAB020M0</a>	Medium version, evd evo embedded for 2 carel exv, usb
<a href="#">P+500BAB050M0</a>	Medium version, evd evo embedded for 1 universal exv, usb
<a href="#">P+500BAB060M0</a>	Medium version, evd evo embedded for 2 universal exv, usb
<a href="#">P+500BAC010M0</a>	Medium version, evd evo embedded for 1 carel exv, usb
<a href="#">P+500BAC020M0</a>	Medium version, evd evo embedded for 2 carel exv, usb
<a href="#">P+500BAC050M0</a>	Medium version, evd evo embedded for universal exv, usb
<a href="#">P+500BAC060M0</a>	Medium version, evd evo embedded for universal exv, usb
<a href="#">P+50NB0A020M0</a>	c.pCO Medium Controller
<a href="#">P+500B0A01EM0</a>	c.pCO Medium Controller with Enhanced Connectivity
<a href="#">P+500B0A02EM0</a>	c.pCO Medium Controller with Integrated Display
<a href="#">P+500B0A05EM0</a>	c.pCO Medium Controller with Embedded EVD EVO Driver for 1 Universal EXV
<a href="#">P+500B0A06EM0</a>	c.pCO Medium Controller with Embedded EVD EVO Driver for 2 Universal EXVs
<a href="#">P+500B0B01EM0</a>	c.pCO Medium Controller with Enhanced Connectivity



Product	Description
<a href="#">P+500B0B02EM0</a>	c.pCO Medium Controller with Embedded EVD EVO Driver for 1 Universal EXV
<a href="#">P+500B0B05EM0</a>	c.pCO Medium Controller with Embedded EVD EVO Driver for 1 Universal EXV and Built-in pgD1 Display
<a href="#">P+500B0B06EM0</a>	c.pCO Medium Controller with Embedded EVD EVO Driver for 2 Universal EXVs and Built-in pgD1 Display
<a href="#">P+500B0C01EM0</a>	Programmable Controller
<a href="#">P+500B0C02EM0</a>	evd evo embedded for 2 carel exv
<a href="#">P+500B0C05EM0</a>	Programmable Controller
<a href="#">P+500B0C06EM0</a>	Programmable Controller
<a href="#">P+500BAA01EM0</a>	Programmable Controller
<a href="#">P+500BAA02EM0</a>	Programmable Controller
<a href="#">P+500BAA05EM0</a>	Programmable Controller
<a href="#">P+500BAA06EM0</a>	Programmable Controller
<a href="#">P+500BAB01EM0</a>	Programmable Controller
<a href="#">P+500BAB02EM0</a>	Programmable Controller
<a href="#">P+500BAB05EM0</a>	Programmable Controller
<a href="#">P+500BAB06EM0</a>	Programmable Controller
<a href="#">P+500BAC01EM0</a>	Programmable Controller
<a href="#">P+500BAC02EM0</a>	Programmable Controller
<a href="#">P+500BAC05EM0</a>	Programmable Controller
<a href="#">P+500BAC06EM0</a>	Programmable Controller
<a href="#">P+500B0C00EM0</a>	Medium version, pgd1 built-in
<a href="#">P+500BAA00EM0</a>	Medium version, usb port, pgd1 built-in
<a href="#">P+500BAB00EM0</a>	Medium version, usb port, pgd1 built-in
<a href="#">P+500BAC00EM0</a>	Medium version, pgd1 built-in, usb port
<a href="#">P+50NB0A00EM0</a>	pCO5+ medium, fb/bms no opto,pgd1 built in, neutral
<a href="#">P+50CON020</a>	Screw version for pco5+ medium with evo embedded
<a href="#">P+50CON120</a>	Screw version for c.pCO medium with evo embedded
<a href="#">P+50CON1L0</a>	Screw version for c.pCO large
<a href="#">P+50CON1M0</a>	Screw version for c.pCO medium
<a href="#">P+50CON1S0</a>	Screw version for c.pCO small
<a href="#">P+50CON1Z0</a>	Screw version for c.pCO extralarge
<a href="#">P+500B0A100S0</a>	Small version, 1 ssr 24 v
<a href="#">P+500B0A10ES0</a>	Small version, 1 ssr 24 v, pgd1 built-in
<a href="#">P+500B0AA00S0</a>	Small version, 1 ssr 230 v
<a href="#">P+500B0B000S0</a>	Small version
<a href="#">P+500B0C000S0</a>	Small version
<a href="#">P+500BAA100S0</a>	Small version, 1 ssr 24 v, usb port
<a href="#">P+500BAAA00S0</a>	Small version, 1 ssr 230 v, usb port
<a href="#">P+500BAB000S0</a>	Small version, usb port
<a href="#">P+500BAC000S0</a>	Small version, usb port
<a href="#">P+50NBAA000S0</a>	pCO5+ small, fb/bms no opto, usb, neutral
<a href="#">P+500B0B00ES0</a>	Small version, pgd1 built-in
<a href="#">P+500B0C00ES0</a>	Small version, pgd1 built-in

Product	Description
<a href="#">P+500BAB00ES0</a>	Small version, usb port, pgd1 built-in
<a href="#">P+500BAC00ES0</a>	Small version, usb port, pgd1 built-in
<a href="#">PGE100EV20</a>	Mastercase2 option - evd upgrade
<a href="#">PGE100EV21</a>	Mastercase2 option
<a href="#">PLD00LF400</a>	Pld large panel mounting
<a href="#">PLD00SF400</a>	Pld small panel mounting
<a href="#">PLDH0SF400</a>	Pld small per heos
<a href="#">PLD01GFP00</a>	LCD Unit Terminal
<a href="#">PCOSCFAKY0</a>	16Mb programming key
<a href="#">SNSCON00M0</a>	Removable screw connectors kit for supernode medium
<a href="#">SNM0000EM0</a>	Supernode for microchiller 2 se + flstdmsnue
<a href="#">SNS0000AM0</a>	Supernode medium board
<a href="#">SNS0000EM0</a>	Supernode medium board + pgd1 built-in
<a href="#">SNS0001EM0</a>	Supernode medium board + pgd1 built-in + usb
<a href="#">PGD000FR11</a>	Face plate
<a href="#">PGD000FRM1</a>	Face plate pgd0, light grey ext, grey int, neutral 20pcs
<a href="#">PGD100FR11</a>	Face plate
<a href="#">PGD100FRM1</a>	Face Plate
<a href="#">PGN1000F00</a>	Pgn1 132x64 pixel, panel mounting
<a href="#">PGD0002F0K</a>	Kit pgd0 per configurazione indirizzo plan
<a href="#">PGDT04000FS00</a>	4.3", Flush mounting, 1 rs485 port, 1 usb port
<a href="#">PGDT04010F020</a>	pGD touch 4,3 neutral model, flush mounting 1 rs485 opto, 1 usb, 2 ethernet
<a href="#">PGDT04010FS00</a>	4.3" Touchscreen User Terminal
<a href="#">PGDT07000F120</a>	7" Advanced Touchscreen User Terminal
<a href="#">PGDT07010F120</a>	pGD touch 7 neutral model
<a href="#">PGDT07010FR00</a>	pGD touch 7 neutral model, flush mounting 2 rs485
<a href="#">PGDT07010C120</a>	7" Touchscreen User Terminal with Enhanced Connectivity
<a href="#">PGDT07010W120</a>	7" Touchscreen User Terminal with Wi-Fi Connectivity
<a href="#">PGDT10000FR10</a>	10" Touchscreen User Terminal
<a href="#">PGDT13000FR10</a>	13" Touchscreen User Terminal
<a href="#">PGTA00BX10</a>	Flush mounting box for pgd touch 7" panel version
<a href="#">PGTA00RM40</a>	Flush mounting case for pgdx 4,3
<a href="#">PGTA00SM40</a>	Surface mounting case for pgdx 4,3
<a href="#">PGTA00TRF0</a>	power supply
<a href="#">PGTA00TRX0</a>	power supply
<a href="#">PGD1000NW0</a>	pGD1 white led without external frame and keyboard
<a href="#">PGN0000I00</a>	pGN Graphic Display with pCOI Enclosure
<a href="#">PGD0000F01</a>	display
<a href="#">PGD0000FZ0</a>	pGD0 mounting display + buzzer
<a href="#">PGD0010F00</a>	pGD0 neutral frames flush mounting
<a href="#">PGD0CF0F00</a>	pGD0 panel mounting for refrigeration rack control
<a href="#">PGD1000FX0</a>	pGD1 Panel-Mounted Graphic Display with White Backlighting and Buzzer

Product	Description
<a href="#">PGD1000WX0</a>	pGD1 Wall-Mounted Graphic Display with White Backlighting and Buzzer
<a href="#">PGD1010FW0</a>	pGD1 white backlight neutral frames flush mounting
<a href="#">PGD1010WW0</a>	Display
<a href="#">PGN0000F00</a>	pGDn0 120 x 32 panel mounting display
<a href="#">PGN0000FZ0</a>	Pgn0 mounting display + buzzer
<a href="#">PGN1010W00</a>	Pgn1 neutral frames wall mounting
<a href="#">PGD0010W00</a>	Wall-Mounted Graphic Display
<a href="#">PGD1000WW0</a>	Wall-Mounted Graphic Display with White Backlighting
<a href="#">PGD1010WX0</a>	Wall-Mounted Graphic Display with White Backlighting and Buzzer
<a href="#">PGN0000W00</a>	Pgn0 120 x 32 wall mounting display
<a href="#">PGN0000WZ0</a>	Pgn0 120x32, mounting wall, with buzzer
<a href="#">PGN0010F00</a>	Pgn0 neutral frames flush mounting
<a href="#">PGN1000I00</a>	Pgn1 132x64 pixel, pcoi enclosure
<a href="#">PGN1010F00</a>	Flush-Mount Graphic Display with White LED Backlighting
<a href="#">PGN1010WZ0</a>	Wall-Mounted Graphic Display with White LED Backlighting and Buzzer
<a href="#">PGD1000F01</a>	Panel-Mounted Graphic Display with Green LED Backlighting
<a href="#">PGD1000FX1</a>	Panel-Mounted Graphic Display with White LED Backlighting and Buzzer
<a href="#">PGD1000FZ0</a>	Panel Mount Display
<a href="#">PGD1000FZ1</a>	Panel-Mounted Graphic Display with Green LED Backlighting and Buzzer
<a href="#">PGD1M30FX0</a>	Panel-Mounted Graphic Display with White LED Backlighting and Buzzer
<a href="#">PGD1PH0F00</a>	pGD1 132x64 pixel phc umid, panel mounting
<a href="#">PGD1RK0FX0</a>	Prack user terminal, pgd1 white display
<a href="#">PGDE000FZ0</a>	pGDevolution 132x64 pixel, flush mounting, buzzer
<a href="#">PGDE000W00</a>	pGDevolution 132x64 pixel, wall mounting
<a href="#">PGDE000WZ0</a>	pGDevolution 132x64 pixel, wall mounting, buzzer
<a href="#">PGDE020F00</a>	pGDevolution 132x64 pixels, flush mounting, black frame
<a href="#">PGDEH00FZ0</a>	pGDe per heos
<a href="#">PGDEH31FX0</a>	Hecu user terminal, pgdevolution
<a href="#">PGDEPS0FZ0</a>	Panel-Mounted Graphic Display with Green LED Backlighting and Buzzer
<a href="#">PGDERK0FX0</a>	Prack user terminal, pgdevolution
<a href="#">PGDERK1FX0</a>	Prack pr300t CO2 user terminal, pgdevolution
<a href="#">PGDEWB0FZ0</a>	Ultracella service terminal for commissioning
<a href="#">PGDEWB0FZK</a>	3m cable and telephone connector
<a href="#">PGN0000T00</a>	Pgn0 with pcot enclosure
<a href="#">PGN1000FZ0</a>	Pgn1 mounting display + buzzer
<a href="#">PGN1000FZ1</a>	Flush-Mount Graphic Display with Green LED Backlighting and Buzzer
<a href="#">PGN1000N00</a>	Pgn1 132x64 pixel, without frame, without keyboard
<a href="#">PGNE000F00</a>	Pgne 132x64, mounting panel

Product	Description
<a href="#">PGNE000FZ0</a>	Pgne 132x64, mounting panel, with buzzer
<a href="#">PGNE000W00</a>	Pgne 132x64, mounting wall
<a href="#">PGNE000WZ0</a>	Pgne 132x64, mounting wall, with buzzer
<a href="#">PGD1000W00</a>	Wall-Mounted Graphic Display with Green LED Backlighting
<a href="#">PGD1000WZ0</a>	pGD1 lcd, 132x64 pixels + buzzer
<a href="#">PGD1010YW0</a>	PGD1 White LED Frames
<a href="#">PGN1000W00</a>	Pgn1 132x64 pixel, wall mounting
<a href="#">PGD3000F00</a>	pGD3 320x240 pixel 256 color, touch-s panel mount.
<a href="#">PGB04000DERB0</a>	pGDx 4,3 browser panel rear
<a href="#">PGB04000TERB0</a>	pGDx 4,3 browser panel front no frame-ip65
<a href="#">PGB04000WECB0</a>	pGDx 4,3 browser wall no frame-t/h
<a href="#">PGB04000WERB0</a>	pGDx 4,3 browser wall no frame
<a href="#">PGR04000DABA0</a>	pGDx 4,3 panel rear -out temp -serial rj12 -buzz
<a href="#">PGR04000DBDA0</a>	pGDx 4,3 panel rear out temp-screw-buzz
<a href="#">PGR04000DCDA0</a>	pGDx 4,3 panel rear out temp-screw-eth-buzz
<a href="#">PGR04000FA000</a>	Touchscreen
<a href="#">PGR04000FA001</a>	4.3" Touchscreen User Terminal without Frame
<a href="#">PGR04000RA000</a>	pGDx 4,3 panel rear in temp-serial rj12 -no rtc
<a href="#">PGR04000TABA0</a>	Digital Display
<a href="#">PGR04000TBDA0</a>	4.3" Touchscreen User Terminal with Enhanced Connectivity
<a href="#">PGR04000TCDA0</a>	Controller
<a href="#">PGR04000WBA00</a>	pGDx 4,3 wall in temp no frame-screw-t/h -buzz
<a href="#">PGR04000WBD00</a>	pGDx 4,3 wall in temp no frame-screw-buzz
<a href="#">PGR04000WCA00</a>	pGDx 4,3 wall in temp no frame-screw-eth-t/h -buzz
<a href="#">PGR04000WCD00</a>	pGDx 4,3 wall in temp no frame-screw-eth-buzz
<a href="#">PGR04000WEA00</a>	pGDx 4,3 wall in temp no frame -eth-t/h -buzz
<a href="#">PGR04000WED00</a>	pGDx 4,3 wall in temp no frame-eth-buzz
<a href="#">PGTA00FB00</a>	Standard carel black frame for pgdx 4,3"
<a href="#">PGTA00FB10</a>	Neutral black frame for pgdx 4,3"
<a href="#">PGTA00FH00</a>	Standard black transparent frame with t/h holes for pgdx 4,3"
<a href="#">PGTA00FH10</a>	Neutral black transparent frame with t/h holes for pgdx 4,3"
<a href="#">PGTA00FT00</a>	Standard carel white transparent frame
<a href="#">PGTA00FT10</a>	Neutral white transparent frame with t/h holes for pgdx 4,3"
<a href="#">PGTA00FW00</a>	Standard carel white frame for pgdx 4,3"
<a href="#">PGTA00FW10</a>	Neutral white frame for pgdx 4,3"
<a href="#">DCFL000100</a>	Air flow switch
<a href="#">DCPD000100</a>	Air differential pressure 0.5 To 5 mbar
<a href="#">DCPD000101</a>	Air diff.Press.Transd. 0,5...5 Mbar - pck 50 pcs
<a href="#">DCPD001100</a>	Air differential pressure 0.2 To 2 mbar
<a href="#">DCPD001101</a>	Air diff.Press.Transd. 0,2...2 Mbar - pck 50 pcs
<a href="#">DCPD011100</a>	Air differential pressure 0.2 To 2 mbar with mounting kit
<a href="#">DPDQ306000</a>	Voc 0 to 10 Vdc or 4 to 20 ma output
<a href="#">DPDQ402000</a>	Co2 air quality sensor 0 to 10 Vdc output
<a href="#">DPDQ502000</a>	Voc and CO2 0 to 10 Vdc output
<a href="#">DPWQ306000</a>	Voc 0 to 10 Vdc or 4 to 20 ma output

Product	Description
<a href="#">DPWQ402000</a>	Co2 air quality sensor 0 to 10 Vdc output
<a href="#">DPWQ502000</a>	Voc and CO2, 0 to 10 Vdc output
<a href="#">DCTF000320</a>	Antifreeze thermostat
<a href="#">DPWAE08000</a>	Combined sensor light and presence detector
<a href="#">DPWAI08000</a>	Combined sensor light and presence detector
<a href="#">SFFF000000</a>	24 Vdc power supply
<a href="#">SFFS000000</a>	12 To 24 Vdc power supply
<a href="#">A1220140717 /FLOR000000</a>	Flooding sensor detector ribbon
<a href="#">DPWL107000</a>	Gas leakage detector r32 semiconductor version ip41
<a href="#">DPWL127000</a>	Gas leakage detector
<a href="#">DPWL207000</a>	Gas leakage detector r600 semiconductor version ip41
<a href="#">DPWL227000</a>	Gas leakage detector
<a href="#">DPWL307000</a>	Gas leakage detector r600a semiconductor version ip41
<a href="#">DPWL327000</a>	Gas leakage detector
<a href="#">DPWL417000</a>	Co2 infrared version
<a href="#">DPWL427000</a>	Co2 infrared version with remote head, 5 m cable
<a href="#">DPWLA07000</a>	R22 semiconductor version
<a href="#">DPWLA27000</a>	R22 semiconductor version with remote head, 5 m cable
<a href="#">DPWLB07000</a>	R134a semiconductor version
<a href="#">DPWLB27000</a>	R134a semiconductor version with remote head, 5 m cable
<a href="#">DPWLB37000</a>	Gas leakage detector
<a href="#">DPWLC07000</a>	R404a semiconductor version
<a href="#">DPWLC27000</a>	R404a semiconductor version with remote head, 5 m cable
<a href="#">DPWLD07000</a>	R407c semiconductor version
<a href="#">DPWLD27000</a>	R407c semiconductor version with remote head, 5 m cable
<a href="#">DPWLE2700N</a>	Gas leakage detector
<a href="#">DPWLE37000</a>	Gas leakage detector
<a href="#">DPWLG07000</a>	Nh3 semiconductor version
<a href="#">DPWLH07000</a>	Gas leakage detector r448a semiconductor version ip41
<a href="#">DPWLH27000</a>	Gas leakage detector
<a href="#">DPWLP07000</a>	R290 semiconductor version
<a href="#">DPWLP27000</a>	Gas leakage detector
<a href="#">DPWLQ07000</a>	Etylene semiconductor version
<a href="#">DPWLR07000</a>	R407a semiconductor version
<a href="#">DPWLR27000</a>	Gas leakage detector
<a href="#">DPWLS07000</a>	R407f semiconductor version
<a href="#">DPWLS27000</a>	Gas leakage detector
<a href="#">DPWLT07000</a>	R507a semiconductor version
<a href="#">DPWLT27000</a>	R507a semiconductor version with remote head, 5 m cable
<a href="#">DPWLU07000</a>	Gas leakage detector r449a semiconductor version ip41
<a href="#">DPWLU27000</a>	Gas leakage detector
<a href="#">DPWLW07000</a>	Gas leakage detector r450a semiconductor version ip41
<a href="#">DPWLW27000</a>	Gas leakage detector
<a href="#">DPWLW07000</a>	Gas leakage detector r452a semiconductor version ip41
<a href="#">DPWLW27000</a>	Gas leakage detector

Product	Description
<a href="#">DPWLX07000</a>	Gas leakage detector r513a semiconductor version ip41
<a href="#">DPWLX27000</a>	Gas leakage detector
<a href="#">DPWLY07000</a>	Gas leakage detector r1234yf semiconductor version ip41
<a href="#">DPWLY27000</a>	Gas leakage detector
<a href="#">DPWLZ07000</a>	Gas leakage detector r1234ze semiconductor version ip41
<a href="#">DPWLZ27000</a>	Gas leakage detector
<a href="#">6133015AXX</a>	Sensing element
<a href="#">6133016AXX</a>	Infrared sensing element
<a href="#">6133017AXX</a>	Sensing element
<a href="#">6133018AXX</a>	Infrared sensing element
<a href="#">6133019AXX</a>	Sensing element for nh3 gas semiconductor
<a href="#">DPWLKIT000</a>	Adapter
<a href="#">DPWLKIT010</a>	Adapter 4 hoses for calibration
<a href="#">DPWLKIT100</a>	Splashguard protection
<a href="#">DPWLKIT200</a>	Red sounder beacons
<a href="#">TSM1500B30</a>	M14 fitting, 2 m cable, -40t90 °C
<a href="#">TSOPZCM000</a>	M12 electrical connector for tsn and tst sensors
<a href="#">TSOPZCW030</a>	M12 electrical connector, 3 m cable for tsn and tst sensors
<a href="#">TSOPZRS000</a>	Welding m14 fitting adapter for tsc and tsm sensors
<a href="#">TSOPZRT000</a>	Welding
<a href="#">LSOPGGF000</a>	Guarnizione per sensore livello flangiato
<a href="#">LSOPGGT000</a>	Guarnizione per sensore livello filettato 2"
<a href="#">LSOPTA1000</a>	Tubo di calma per lsr0013000 con spia - connessione filettata 2"
<a href="#">LSOPUA1000</a>	Level bridle
<a href="#">NTC008HP0W</a>	0.8 M white cable
<a href="#">NTC015HP05</a>	1.5 M yellow cable
<a href="#">NTC015HP06</a>	1.5 M green cable
<a href="#">NTC015HP0W</a>	1.5 M white cable
<a href="#">NTC015WH04</a>	Sensor ntc wh ip68 -50t105 red cable 1,5m pck 10 pcs
<a href="#">NTC030HP05</a>	3 M yellow cable
<a href="#">NTC030HP06</a>	3 M green cable
<a href="#">NTC030WH04</a>	NTC Temperature Sensor with 3m Cable
<a href="#">NTC060HP0W</a>	cable
<a href="#">NTC060WS0Y</a>	cable
<a href="#">NTC008HF01</a>	cable
<a href="#">NTC015HF01</a>	cable
<a href="#">NTC030HF03</a>	IP67, 3 m cable, -50t90 °C strap-on, package for wholesalers
<a href="#">NTC030HF0R</a>	cable
<a href="#">NTC060HF03</a>	IP67, 6 m cable, -50t90 °C strap-on, package for wholesalers
<a href="#">DLOGNTC015</a>	Sensor ntc ip67 cable 1,5m 1gr.C. -35/+30G.C.
<a href="#">NTC015HP0I</a>	cable
<a href="#">NTC016HP0R</a>	NTC hp l= 1.6 M, multiple package (50 pcs)
<a href="#">NTC025HP00</a>	IP67, 2.5 M cable, -50t105 °C (on air)
<a href="#">NTC030HP0I</a>	cable
<a href="#">NTC030HPC1</a>	cable



Product	Description
<a href="#">NTC035HP00</a>	IP67, 3.5 M cable, -50t105 °C (on air)
<a href="#">NTC035HP01</a>	cable
<a href="#">NTC060HPC1</a>	Sensor ntc ip67 6m with metal tips pck. 10 Pcs
<a href="#">NTC120HP01</a>	cable
<a href="#">NTC004HP02</a>	NTC hp l= 40 cm, single package
<a href="#">NTC004HP0R</a>	NTC hp l= 40 cm, multiple package (50 pcs)
<a href="#">NTC006HP0R</a>	NTC Temperature Sensor with 6m Cable
<a href="#">NTC006HPYR</a>	Sensor ntc hp 60cm yellow jst pck.50Pcs
<a href="#">NTC010HP02</a>	NTC hp l= 1 m, single package
<a href="#">NTC010HP0R</a>	NTC hp l= 1 m, multiple package (50 pcs)
<a href="#">NTC016HP02</a>	NTC hp l= 1.6 M, single package
<a href="#">NTC030HP02</a>	NTC hp l= 3 m, single package
<a href="#">NTC030HP0R</a>	NTC hp l= 3 m, multiple package (50 pcs)
<a href="#">NTC050HP0R</a>	NTC hp l= 5 m, multiple package (50 pcs)
<a href="#">NTC060HP0R</a>	NTC hp l= 6 m, multiple package (50 pcs)
<a href="#">NTC100HP5R</a>	NTC hp l= 10 m, multiple package (50 pcs)
<a href="#">NTC015HP03</a>	cable
<a href="#">NTC030HP03</a>	cable
<a href="#">NTC060HP03</a>	cable
<a href="#">NTC030HPW1</a>	cable
<a href="#">NTC008HT00</a>	IP55, 0.8 M cable, 0t150 °C
<a href="#">NTC008HT41</a>	IP55, 0.8 M cable, 0t150 °C, multiple package (10 pcs)
<a href="#">NTC030HT02</a>	IP55, 3 m cable, 0t150 °C, multiple package (10 pcs)
<a href="#">NTC030HT03</a>	IP55, 3 m cable, 0t150 °C, package for wholesalers
<a href="#">NTC030HT41</a>	IP55, 3 m cable, 0t150 °C, multiple package (10 pcs)
<a href="#">NTC060HT03</a>	IP55, 5 m cable, 0t150 °C, package for wholesalers
<a href="#">NTC120HT00</a>	IP55, 12 m cable, 0t150 °C
<a href="#">NTC120HT41</a>	IP55, 12 m cable, 0t150 °C, multiple package (10 pcs)
<a href="#">TSC1500030</a>	M14 fitting, 2 m cable, -40t90 °C
<a href="#">TSN1300000</a>	1/8 Gas fitting, m12 electrical connection, -40t120 °C
<a href="#">NTC000LT00</a>	IP67, -80t105 °C, low temperature
<a href="#">NTC015WH03</a>	cable
<a href="#">NTC030WH03</a>	cable
<a href="#">NTC060WH03</a>	NTC Sensor
<a href="#">UEKNTC0015</a>	NTC sensor for climate ip68 -50t105 cable 1,5m
<a href="#">UEKNTC0060</a>	NTC sensor for climate ip68 -50t105 cable 6m
<a href="#">UEKNTC0120</a>	NTC sensor for climate ip68 -50t105 cable 12m
<a href="#">NTC015WF11</a>	cable
<a href="#">NTC030WF02</a>	cable
<a href="#">NTC030WP10</a>	IP68, 3 m cable, -50t105 °C; lenght cap= 100 mm
<a href="#">NTC060WP30</a>	IP68, 6 m cable, -50t105 °C, lenght cap= 300 mm
<a href="#">NTC120WP20</a>	IP68, 12 m cable, -50t105 °C; lenght cap= 200 mm
<a href="#">NTC015WS01</a>	cable
<a href="#">NTC030WS01</a>	Temperature sensor
<a href="#">NTC060WS01</a>	cable

Product	Description
<a href="#">NTCINF0150</a>	NTC sensor pass through, silicon cable 1,5 m -50t90 °C, ip67
<a href="#">NTCINF0340</a>	NTC sensor
<a href="#">NTCINF0600</a>	NTC sensor pass through, silicon cable 6 m -50t90 °C, ip67
<a href="#">NTCINF0610</a>	NTC sensor
<a href="#">NTCINF0640</a>	NTC sensor
<a href="#">PT1INF0340</a>	PT1000 sensor
<a href="#">PT1030HF01</a>	PT1000 Temperature Sensor with 3m Cable
<a href="#">PT1060HF01</a>	PT1000 Suction Temperature Probe for Superheat
<a href="#">PT1060HP01</a>	Sensor
<a href="#">PT1060HT01</a>	IP67, cable l=6 m, -50t250 °C
<a href="#">TST1300000</a>	1/8 Gas fitting, m12 electrical connection, -40t120 °C
<a href="#">TSOPZCV070</a>	7 M extension cable for pt1000 sensor
<a href="#">TSOPZCV100</a>	10 M cable for pt1000 sensor
<a href="#">TSOPZFGD30</a>	Sliding 1/4" gas fitting for ø 3 mm
<a href="#">TSOPZRV000</a>	M14 to 3/8 gas fitting adapter for tsc and tsm sensors
<a href="#">PT1060WF01</a>	PT1000 Temperature Sensor with 6m Cable
<a href="#">PT1060WP01 (10 pcs)</a>	Refrigeration Sensor
<a href="#">PTC0150000</a>	sensor
<a href="#">PTC015W000</a>	IP67, 1.5 M cable, -50t100 °C
<a href="#">PTC03000D1</a>	PTC Temperature Sensor with 3m Cable
<a href="#">PTC03000G1</a>	PTC Temperature Sensor with 3m Rubber Cable
<a href="#">PTC03000W1</a>	PTC Temperature Sensor with 3m PVC Cable
<a href="#">PTC0600000</a>	Sensor ptc ip65 0/150c l=6m sen.Kty81/121-20/5
<a href="#">PTC060W000</a>	IP67, 6 m cable, -50t100 °C
<a href="#">PTC060WA00</a>	Sensor ptc temperature sensor, bulb, 50 to 90 c
<a href="#">LSR0013000</a>	Level sensor
<a href="#">LSR0023000</a>	Level sensor
<a href="#">WS01AB2M20</a>	Access point 12 to 24 Vac - modbus®
<a href="#">WS01RB2M20</a>	Router-bridge 12 to 24 Vac - modbus®
<a href="#">WS01RC1M20</a>	Router
<a href="#">722</a>	Cacciavite magnetico rosso con logo carel
<a href="#">WS00BAT000</a>	Lithium battery for wireless sensors single package
<a href="#">WS00BAT200</a>	Battery for wireless sensors with connector -single package
<a href="#">WS01L01M00</a>	Controller
<a href="#">WS01F01M00</a>	wireless sensor
<a href="#">WS01G01M00</a>	RTM se wireless sensor
<a href="#">WS01U01M00</a>	Wireless temperature sensor
<a href="#">WS01U01M01</a>	Wireless temperature sensor
<a href="#">WS01VB2M10</a>	Router-sensor
<a href="#">WS01W02M00</a>	Wireless temperature sensor
<a href="#">WS01E02M00</a>	RTM se wireless counters ci 2di - 2ntc - modbus
<a href="#">WS01H02M20</a>	RTM se router-actuator
<a href="#">WS01N02M20</a>	RTM se router-sensor
<a href="#">WS01C010E0</a>	wireless electricity meter and remote control
<a href="#">WS01C010F0</a>	wireless electricity meter and remote control

Product	Description
<a href="#">WS01C010G0</a>	wireless electricity meter and remote control
<a href="#">WS01C010I0</a>	wireless electricity meter and remote control
<a href="#">WS01C010X0</a>	wireless electricity meter and remote control
<a href="#">DPDC11000N</a>	Duct sensor temp.
<a href="#">DPDC11100N</a>	Duct sensor temp.
<a href="#">DPDC11200N</a>	Duct sensor temp.
<a href="#">DPDC11400N</a>	Duct sensor temp.
<a href="#">DPDT01100N</a>	Duct temp. -20T70gr.C. (Out res.NTC) neutral
<a href="#">DPWC11500N</a>	Wall sensor temp.
<a href="#">DPPC11000N</a>	Industrial envir.Sensor temp.
<a href="#">DPPC11400N</a>	Industrial envir.Sensor temp.
<a href="#">PT1060PS00</a>	IP67, slow reaction time, 6 m cable, -50t105 °C
<a href="#">SPK1000000</a>	-0.5 To 7 barg (-8 to 100 psig)
<a href="#">SPK2400000</a>	-1 To 24 barg (-15 to 340 psig)
<a href="#">SPKC002311</a>	Cable
<a href="#">SPKC002313</a>	2m Cable for SPKT Sensors with Packard Vulcanized Connector
<a href="#">SPKC002321</a>	2m Cable for SPKT Sensors with Packard Molded Connector
<a href="#">SPKC002410</a>	Cable
<a href="#">SPKC002510</a>	Cable
<a href="#">SPKC005311</a>	IP67
<a href="#">SPKC005313</a>	IP67
<a href="#">SPKC005321</a>	Cable
<a href="#">SPKC005410</a>	Cable
<a href="#">SPKC00A300</a>	IP55, 12 m cable with packard connector for spkt*
<a href="#">SPKC00A310</a>	IP67, 12 m cable with co-moulded packard connector for spkt*
<a href="#">SPKC00A321</a>	Cable
<a href="#">SPKC00B311</a>	IP67
<a href="#">SPKC00C311</a>	IP67
<a href="#">SPKC00D311</a>	IP67
<a href="#">SPKC00E311</a>	IP67
<a href="#">SPKC00F310</a>	IP67, 4 m cable with packard connector for spkt*
<a href="#">SPKC00G310</a>	IP67, 6.6 M cable with packard connector for spkt*
<a href="#">SPKC00M311</a>	Cable
<a href="#">SPKS0019R1</a>	Ratiometric 0-5v sensor pressure transducer
<a href="#">SPKS0039R1</a>	Pressure Transducer
<a href="#">SPKS00B9R1</a>	Ratiometric Pressure Transducer
<a href="#">SPKS00F9R1</a>	pressure sensor
<a href="#">SPKD00C5N0</a>	0 To 50 pa
<a href="#">SPKD00U5N0</a>	0 To 1000 pa or 2500pa
<a href="#">SPK10000D0</a>	-0,5...7 Barg 4...20ma (-8...100psig)
<a href="#">SPK24000D0</a>	-1...24 Barg 4...20ma (-15...340psig)
<a href="#">SPK30000D0</a>	0...30 Barg 4...20ma (0...430psig)
<a href="#">SPKT0031D0</a>	1 To 30 barg (0 to 435 psig)
<a href="#">SPKT0041D0</a>	4-20 mA Pressure Transducer
<a href="#">SPKT00G1D0</a>	0 To 60 barg (0 to 860 psig)

Product	Description
<a href="#">SPKT00D8C0</a>	4To 20ma, 0 to 150 barg (0 to 2175 psig)
<a href="#">SPKT00H8C0</a>	4To 20ma, 0 to 120 barg (0 to 1740 psig)
<a href="#">SPKT0011C3</a>	4-20 mA Pressure Transducer with Cable Connection
<a href="#">SPKT0021C3</a>	4-20 mA Pressure Transducer (-0.5 to 7 barg)
<a href="#">SPKT0031C3</a>	4-20 mA Pressure Transducer (0 to 30 barg)
<a href="#">SPKT00B1C3</a>	4-20 mA Pressure Transducer (0 to 44.8 barg)
<a href="#">SPKT00G1C0</a>	4 To 20 ma, 0 to 60 barg (0 to 860 psig)
<a href="#">SPKT0043R1</a>	Ratiometric Pressure Transducer (0 to 17.3 bar)
<a href="#">SPKT0053R0</a>	Ratiometric Pressure Transducer (-1 to 4.2 bar)
<a href="#">SPKT00B6R1</a>	High-Pressure Ratiometric Transducer (0 to 44.8 bar)
<a href="#">SPKT00E3R1</a>	Ratiometric Pressure Transducer (-1 to 12.8 bar)
<a href="#">SPKT00F3R1</a>	Ratiometric Pressure Transducer (0 to 20.7 bar)
<a href="#">SPKT0011S0</a>	-1 To 9.3 Barg (-15 to 135 psig)
<a href="#">SPKT0041S0</a>	Pressure sensor
<a href="#">SPKT0051S0</a>	-1 To 4.2 Barg (-15 to 60 psig)
<a href="#">SPKT00B1S0</a>	0 To 45.0 Barg (0 to 650 psig)
<a href="#">SPKT00E1S0</a>	-1 To 12.8 Barg (15 to 185 psig)
<a href="#">SPKT00F1S0</a>	0 To 20.7 Barg (0 to 300 psig)
<a href="#">SPKT00G1S0</a>	0 To 60 barg (0 to 870 psig)
<a href="#">SPKT00L1S0</a>	0 To 90 barg (0 to 1305 psi)
<a href="#">ASET030002</a>	Temperature (-30t150 °C) 3 m cable
<a href="#">ASIT030000</a>	Temperature sensor
<a href="#">1413309AXX</a>	Casing for temperature sensor
<a href="#">62C588A005</a>	Coloured labels for passive sensors
<a href="#">62C588A006</a>	Coloured labels
<a href="#">CM00000006</a>	Dynamometric manual strap
<a href="#">NTCSOBS003</a>	Brass socket
<a href="#">NTCSOSS003</a>	Stainless steel socket
<a href="#">TSOPZPT000</a>	1/4" Gas fitting socket for tsn and tst sensors
<a href="#">DPDT011000</a>	Temperature Sensor
<a href="#">DPWT010000</a>	Temperature (-10t60 °C)
<a href="#">DPWT01100M</a>	Wall sensor temp.
<a href="#">DPWT01100N</a>	Wall sensor temp.
<a href="#">DPWT014000</a>	Temperature (-10t60 °C)
<a href="#">DPWT01400N</a>	Wall sensor temp.
<a href="#">DPPT01100N</a>	Industrial envir. Sensor temp.
<a href="#">DPPT01400N</a>	Industrial envir. Sensor temp.
<a href="#">DPWC11400N</a>	Wall sensor temp.
<a href="#">SPKT0013P1</a>	Ratiometric Pressure Transducer (0 to 45 bar)
<a href="#">SPKT0013P3</a>	Ratiometric Pressure Transducer (-1 to 9.3 bar)
<a href="#">SPKT0033P1</a>	Ratiometric Pressure Transducer (0 to 34.5 bar)
<a href="#">SPKT0033P3</a>	Ratiometric Pressure Transducer (0 to 34.5 bar)
<a href="#">SPKT0043P1</a>	Ratiometric Pressure Transducer (0 to 17.3 bar)
<a href="#">SPKT0053P0</a>	Ratiometric Pressure Transducer (-1 to 4.2 bar)
<a href="#">SPKT0053P1</a>	Ratiometric Pressure Transducer (-1 to 4.2 bar)

Product	Description
<a href="#">SPKT00B6P0</a>	Pressure sensor
<a href="#">SPKT00B6P1</a>	Ratiometric Pressure Transducer (0 to 45 bar)
<a href="#">SPKT00B6P3</a>	Press.Trasd.
<a href="#">SPKT00E3P0</a>	Ratiometric Pressure Transducer (-1 to 12.8 bar)
<a href="#">SPKT00E3P1</a>	Ratiometric Pressure Transducer (-1 to 12.8 bar)
<a href="#">SPKT00F3P0</a>	Ratiometric Pressure Transducer (0 to 20.7 bar)
<a href="#">SPKT00F3P1</a>	Ratiometric Pressure Transducer (0 to 20.7 bar)
<a href="#">SPKT0113P0</a>	Ratiometric Pressure Transducer (0 to 9.3 bar)
<a href="#">SPKT0133P0</a>	Press.Trasd.
<a href="#">SPKT0143P0</a>	Press.Trasd.
<a href="#">SPKT0153P0</a>	Press.Trasd.
<a href="#">SPKT01B6P0</a>	Press.Trasd.
<a href="#">SPKT01E3P0</a>	Press.Trasd.
<a href="#">SPKT01F3P0</a>	Press.Trasd.
<a href="#">09C425A003</a>	power supply
<a href="#">TRA0030000</a>	power supply
<a href="#">TRA0060000</a>	power supply
<a href="#">TRA00AE240</a>	Trasf. 230/24Vac, 10va, panel mounting
<a href="#">TRA00AE241</a>	Trasf.
<a href="#">TRA00BE240</a>	Transformer
<a href="#">TRA12UNI00</a>	power supply
<a href="#">TRA12UNI11</a>	power supply
<a href="#">TRA12VDE00</a>	power supply
<a href="#">TRA12VDE01</a>	power supply
<a href="#">TRA1806ITA</a>	power supply
<a href="#">TRA1810DIN</a>	power supply
<a href="#">TRA2400001</a>	power supply
<a href="#">TRADR1W024</a>	power supply
<a href="#">TRADR4W012</a>	power supply, panel mounting trasformer
<a href="#">TRADR4W024</a>	power supply, din rail mounting transformer
<a href="#">TRADRBE240</a>	power supply
<a href="#">TRADRFE240</a>	power supply
<a href="#">TRASP3E120</a>	power supply, socket mounting transformer
<a href="#">TRASP3E240</a>	power supply, socket mounting transformer
<a href="#">BLCT3C00W2</a>	Dismountable steam cylinder
<a href="#">UCHBP000X0200</a>	Chiller
<a href="#">THP00C0001</a>	Motor Protector
<a href="#">BL0T4D00H2SP</a>	Cylinder
<a href="#">ECKP008000</a>	Pump Kit
<a href="#">MCH2000051</a>	U Chiller Process Panel
<a href="#">P+300B00000L0</a>	Product Information Not Available
<a href="#">KUET3C0000</a>	Product Information Not Available
<a href="#">CPY0000200</a>	Controller
<a href="#">CPYCONN000</a>	Terminal Border
<a href="#">UEKTAM0001</a>	Transformer

Product	Description
<a href="#">NTC060WH01 (pack x10)</a>	Sensor
<a href="#">EVDIS00DE0</a>	display
<a href="#">EVDIS00IT0</a>	Display for EVD Evolution, Italian
<a href="#">E235SSM00</a>	Product Information Not Available
<a href="#">P+500BAA00EL</a>	pCO5+ Electronic Controller
<a href="#">SPKT0013P0</a>	Ratiometric Pressure Transducer (-1 to 9.3 bar)
<a href="#">NTC060WP10</a>	Sensor
<a href="#">9594471-00</a>	Service Kit
<a href="#">IP67, E2VCABS9I0</a>	Connection Cable, 9m Bipolar Shielded
<a href="#">UCHBP00000190</a>	Controller
<a href="#">BL0T2D00H2SP</a>	Steam Cylinder
<a href="#">GDWBS21A00</a>	Gas detector
<a href="#">GDOPZS2100</a>	Sensor
<a href="#">03497327</a>	Electronic Controller
<a href="#">IREVC0HC00</a>	Electronic Controller
<a href="#">13C499A030USP (13C499A030)</a>	Drain Valve Kit
<a href="#">MD33D5EB00</a>	MasterCella PID Temperature Controller
<a href="#">SPKS01E3P1</a>	pressure transducer
<a href="#">UCHBD00001230</a>	Uchiller Controller
<a href="#">IR32D1L000</a>	TEMPERATURE INDICATOR FOR DISPLAY PANEL
<a href="#">P+300B0000ELO</a>	pCO5+ Small Programmable Controller
<a href="#">PGD1000I00</a>	PGD1 Pixel with PCOI Enclosure
<a href="#">PSD1018400</a>	INVERTER
<a href="#">PCOX000CA0</a>	PCO5 COMPACT + USB CONTROL SCHEDULE
<a href="#">P+500BAA00ES0</a>	Controller
<a href="#">UCHBE00001230</a>	UChiller High-Efficiency Chiller Controller
<a href="#">PJS4C0H100</a>	panel
<a href="#">PJS5C0H300</a>	PJEZ Electronic Controller
<a href="#">UCHCONP000</a>	terminal
<a href="#">GDWRS02A00</a>	Product Information Not Available
<a href="#">NTC060WH01</a>	NTC Sensor
<a href="#">VFD150MS42F0</a>	Product Information Not Available
<a href="#">P+100B000D0M0</a>	controllers
<a href="#">BL0T4C00H2 SP</a>	Cylinder
<a href="#">ATA4001CD0</a>	230 Vac, temperature and humidity, flush mounting
<a href="#">UEKDRAIN01</a>	Pump
<a href="#">PCOX000BB0+PCOXCON0B0</a>	Controller + Terminal
<a href="#">E2V24CWAC0</a>	Electronic expansion valve
<a href="#">E2V18CWAC0</a>	Electronic expansion valve
<a href="#">E3VSTA0321</a>	Electrical Coil for E3V Electronic Expansion Valve
<a href="#">PJEZC8I040</a>	Electronic Controller
<a href="#">UU01GD0001 / S.n: A00002136</a>	steam humidifier
<a href="#">KUESRF0000</a>	Terminal Border
<a href="#">CPY03D02V0</a>	CONTROL BORD
<a href="#">BL0S1F00H2SP</a>	Cylinder



Product	Description
<a href="#">PCOX000DA0</a>	pCO compact
<a href="#">NTC060WH04</a>	sensor
<a href="#">PRK300M3F0</a>	controller
<a href="#">PRK300M3E0</a>	controller
<a href="#">UCHBP00000200</a>	µChiller controller
<a href="#">PSD10404C0</a>	inverter
<a href="#">EVD1S00ENO</a>	
<a href="#">PJEZC0P000</a>	Controller
<a href="#">URKCOPC02S</a>	Boiler Cover Kit for Humidifiers
<a href="#">UE045XL001</a>	humiSteam X-plus Isothermal Immersed Electrode Humidifier
<a href="#">IR33+ IREVC0LN00</a>	Electronic refrigeration controller
<a href="#">UC06501010</a>	Centrifugal Humidifier
<a href="#">UC01001010</a>	Centrifugal Humidifier
<a href="#">IREVC0HN00</a>	Electronic Controller
<a href="#">UEX90M0010</a>	Controller
<a href="#">UCHCONPMC0</a>	Adapter kit for MCH2
<a href="#">BLCT1C00W1</a>	steam cylinder for air conditioning
<a href="#">UPCA001DM0</a>	Circuit board
<a href="#">IR33W7HR20</a>	IR33 Universale Electronic Controller
<a href="#">PCOE00TLN0</a>	Card
<a href="#">UEY05L0200</a>	controller
<a href="#">BL0S3F00H2USP</a>	Steam Cylinder
<a href="#">PZUAS0JB20</a>	Electronic Controller
<a href="#">UEX90L0010</a>	Controller
<a href="#">BL0T5C00H0SP</a>	Steam Cylinder
<a href="#">BMESTDNA0K</a>	BMS Interface Module
<a href="#">IROPZSEM10</a>	RS485 Serial Interface Module
<a href="#">PGB10010FCCA0</a>	pGDx 10" Capacitive Touch User Terminal
<a href="#">P+300B0000ES0</a>	Controller
<a href="#">UU01FD0001</a>	Steam humidifier
<a href="#">EVD000401</a>	Module for electric TRV
<a href="#">E2V05CWAC0</a>	electronic expansion valve
<a href="#">WB000DG0F0</a>	UltraCella Double-Row LED Display Controller
<a href="#">URKCOPC00M</a>	Cylinder Cover Kit
<a href="#">URKSL00005SP</a>	Water Level Sensor
<a href="#">PRK300S3FK</a>	Product Information Not Available
<a href="#">PRK300M3FK</a>	pRack pR300 Medium Compressor Rack Controller
<a href="#">00428123</a>	Product Information Not Available
<a href="#">Digital Monitor for UE045YL001 (HCTLEYF020SP)</a>	Humidifier display
<a href="#">A00223162 / P+500B0A200Z0</a>	pCO5+ Medium Programmable Controller
<a href="#">E5VA5AST00</a>	Electronic Expansion Valve
<a href="#">SK Regler / 3396664</a>	Product Information Not Available
<a href="#">P+D0000NH1DEF0</a>	Controller
<a href="#">183206</a>	Exhaust valve housing
<a href="#">254001</a>	Humidair coil

Product	Description
<a href="#">141127</a>	humidifier
<a href="#">183205</a>	Valve anchor for exhaust valve
<a href="#">UR060HL104</a>	Product Information Not Available
<a href="#">E2V30FSMC0 + E2VSTA0330</a>	E2V Series Electronic Expansion Valve and Unipolar Stator Coil
<a href="#">E2V30FSMC0 + E2VSTA0200</a>	E2V Series Electronic Expansion Valve with Stator Coil
<a href="#">PGB07010FBCA0</a>	Display
<a href="#">P+50CON0L0</a>	removable screw connectors kit for pco5+/cpco large
<a href="#">UP2CONN0M0</a>	Product Information Not Available
<a href="#">BL0T3C00H2SP</a>	Cylinder
<a href="#">PJEZS0GB00</a>	Termostat Digital
<a href="#">BL0T4D00H2</a>	Steam Cylinder
<a href="#">DN33B7LR20</a>	Control system module (AIAS COMBOX)
<a href="#">P+D000UEDDEF0</a>	Product Information Not Available
<a href="#">CPY000D200</a>	HUMIDIFICATION CONTROL BOARD MULTI DENCO DMA030
<a href="#">98C615P005</a>	Adapter Kit
<a href="#">IXE1C0H1213</a>	Electronic controller
<a href="#">PYCO1SN50P</a>	Electronic controller
<a href="#">UPCB001BS0</a>	Board Controller
<a href="#">PS20024400110</a>	Power+ 24A, 380-480VAC 3-Phase Inverter
<a href="#">211052</a>	AIR CONDITIONING CONTROL UNIT IR33
<a href="#">BL0T2A00H2SP</a>	Cylinder
<a href="#">PSD1018500</a>	Inverter
<a href="#">DPWQ60B010</a>	Indoor Air Quality Sensor
<a href="#">PGB07010FBCA</a>	display
<a href="#">PGTA00FB30</a>	Product Information Not Available
<a href="#">HCTLEYF020</a>	Operation panel
<a href="#">UCHBP000P0200</a>	Chiller Process Panel
<a href="#">BL02TB00H2SP /400V</a>	Steam Cylinder for Humidifiers
<a href="#">ACS00CB000022</a>	Product Information Not Available
<a href="#">BL0T1C00H1</a>	Steam Cylinder
<a href="#">P+500BBA06EM0</a>	pCO5+ Medium Programmable Controller with Built-in pGD1 Display
<a href="#">UE015YLC01</a>	humidifier
<a href="#">P+500BAA00S0</a>	pCO5+ Small Programmable Controller with Built-in pGD1 Display
<a href="#">NTC030HP00-50</a>	NTC Temperature Probe with 3m Cable
<a href="#">EVD001N00 EVD mini 24 V with display</a>	EVD Mini Driver for Unipolar Electronic Expansion Valves
<a href="#">PLDH0GFP00</a>	Дисплей
<a href="#">A00099636</a>	ULTRACAP MODULE
<a href="#">P+500BBA00ES0</a>	Controller
<a href="#">KITVC10011SP</a>	Fill Valve Kit for Humidifiers
<a href="#">URKH03I401SP</a>	Boiler Heater Kit for Humidifiers
<a href="#">URKCFAN000SP</a>	Fan
<a href="#">URKREL2400SP</a>	Pump
<a href="#">URKCONT200SP</a>	Contacteur

Product	Description
<a href="#">URKSSR1020SP</a>	Relay
<a href="#">UEKVASC100SP</a>	Cylinder
<a href="#">URKBR00000SP</a>	Boiler Replacement Kit for Humidifiers
<a href="#">UEKF000020SP</a>	Boiler Filter Kit for Humidifiers
<a href="#">PJEZS0P100</a>	Electronic Controller
<a href="#">UC0650D100</a>	centrifugal humidifer
<a href="#">UC0100D000</a>	centrifugal humidifer
<a href="#">UC0650D000</a>	centrifugal humidifer
<a href="#">PCO1NN0WD0/ PCOWEB</a>	card
<a href="#">E2V03FSAC0</a>	Electronic Expansion Valve for Low Capacity Applications
<a href="#">NTC006HP0R - MOQ 50pcs</a>	NTC Temperature Probe with 6m Cable
<a href="#">PZUAC0E520</a>	Electronic Controller
<a href="#">E4V85FWSB1</a>	ELECTRONIC EXPANSION VALVE E4V-85 HERMETIC 1 1/8"x1 1/8" ODF W/O STATOR - W/O SIGHT
<a href="#">13C499A030</a>	Valve kit
<a href="#">BLCT2C00W0SP</a>	Cylinder
<a href="#">UCHBP00N00191</a>	controller
<a href="#">BL0T2A00H2USP</a>	Steam Cylinder
<a href="#">UPCCONN0M0</a>	
<a href="#">PGD0</a>	display
<a href="#">BLOS1F00H2SP</a>	Cylinder
<a href="#">PJEZC0M000 / C05817177</a>	Electronic Controller
<a href="#">GDWBI20A00</a>	Gas sensor
<a href="#">DPWC11000</a>	wall sensor
<a href="#">E2V30FSMC0</a>	Electronic Expansion Valve
<a href="#">IR33+ IREVC0LC00</a>	refrigerator controller
<a href="#">PN: 3651080 / MTALIVA000</a>	Chiller water level sensor / pressure sensor
<a href="#">BL0T1A00H2USP</a>	Steam Cylinder
<a href="#">KITBLCT2D2SP</a>	Cylinder Electrodes
<a href="#">KITBLC2FG0SP</a>	Filter and seal for cylinder BLCS2/BLCT2
<a href="#">#ZKN04880</a>	water probe
<a href="#">NTC060WP10 NTC</a>	NTC Temperature Sensor with 6m Cable
<a href="#">IXSEC0HH2A1</a>	controller
<a href="#">SP-43200101-D</a>	Specific Product Information Not Available
<a href="#">E4V95FWSB0</a>	Valve
<a href="#">E4V95FWSA0</a>	Valve
<a href="#">UEKDC10000SP</a>	Drainage circuit
<a href="#">UEKT1000XLSP</a>	Hose set
<a href="#">KITCN00000</a>	Conductometer
<a href="#">BLOT5C00H0SP</a>	Cylinder
<a href="#">UEKDC20000SP</a>	Drainage circuit
<a href="#">UEKT100XXLSP</a>	internal pipe kit
<a href="#">UEKCOLL000</a>	Manifold
<a href="#">BLOT4C00H2SP</a>	Cylinder
<a href="#">E4VE7VSTA0</a>	Bobina

Product	Description
<a href="#">GDWBS04A00/ R-404A</a>	Gas sensor
<a href="#">MOD0256E</a>	control module
<a href="#">LINEAR STEAM DISTRIBUTOR HIGH EFFICIENCY SERIES DP INOX L=1050MM DIAM.40</a>	High-Efficiency Stainless Steel Linear Steam Distributor
<a href="#">1312357APG</a>	SFH 040: Water Drain Hose Ø=40 mm (Pre-Cut 1 Meter Sections)
<a href="#">10T60GR.C.</a>	Duct Temperature and Humidity Sensor
<a href="#">20T70GR.C.</a>	Duct Temperature and Humidity Sensor
<a href="#">GDSRSHFC00</a>	Gas Detector
<a href="#">PGTA00CNV0- 9</a>	DB9 Adapter Cable for RS485 Communication
<a href="#">EVDIS00JP0</a>	Display for EVD Evolution
<a href="#">IR33Y7HR0S</a>	controller
<a href="#">E3V55BWRC0</a>	Expansion Valve
<a href="#">UU04RDAS01</a>	Adiabatic ultrasonic humidifiers
<a href="#">UU06RDAS01</a>	Adiabatic ultrasonic humidifiers
<a href="#">E2V24FSMC0</a>	Electronic Expansion Valve
<a href="#">UEKT10000LSP</a>	Hose set
<a href="#">UEKCOL000</a>	Collector
<a href="#">BL0T3D00H2</a>	Steam Cylinder
<a href="#">DN33H0HB00</a>	Electronic Controller
<a href="#">BL0T2C00H0SP</a>	Steam Cylinder for humiSteam Humidifiers
<a href="#">IJFPLA6B06S0286</a>	Controller
<a href="#">DN33C0HR00</a>	Cold room controller
<a href="#">SCE-AC10200B460V3</a>	Air Conditioner
<a href="#">EVDMM000N00</a>	EVD Mini Driver
<a href="#">BL0T3C00H2USP</a>	Steam Cylinder
<a href="#">KUE0300000</a>	
<a href="#">Steam Hose for A00555132 (1312367AXX)</a>	Steam hose Ø40mm
<a href="#">UPCA001BS0</a>	Board Controller
<a href="#">E2V18FSFC0</a>	Valve
<a href="#">PSD1016200</a>	Air Cooled Inverter
<a href="#">PRK100X3A0</a>	Controller
<a href="#">PRK300S3F0</a>	
<a href="#">PRK300L3F0</a>	
<a href="#">BXOPZI4850000</a>	
<a href="#">HCTLEYW020 / A17091RV70</a>	
<a href="#">PSD10354T0</a>	Speed drive
<a href="#">PT1060WP01</a>	SENSOR
<a href="#">Carel PZUAC0E520</a>	Electronic Controller
<a href="#">URKT00002M</a>	Internal Pipe Kit
<a href="#">PEOPZC1500</a>	1.5m Display Cable
<a href="#">ECKN0301D0</a>	NOZZLE
<a href="#">IJFPSA4N00S0280</a>	Electronic Controller
<a href="#">UPCC0NN0M0</a>	
<a href="#">UPCB001BM0</a>	

Product	Description
<a href="#">UPCCONN0S0</a>	
<a href="#">UEKGUAR000SP</a>	o ring
<a href="#">PCOE0N4850</a>	
<a href="#">Electode for UE065XL001 (KITBLCT5C0SP)</a>	
<a href="#">PZDDS0H00Y</a>	controllers
<a href="#">PZDDC0H00Y</a>	controllers
<a href="#">E3V35BSM50</a>	Valve
<a href="#">PGNE020F00</a>	Display
<a href="#">BL0SRE00H2SP</a>	filters
<a href="#">BL0SRF00H2SP</a>	filter
<a href="#">A00858196 / BL0T1D00H1SP</a>	
<a href="#">NTC030HF01 -50T90</a>	TEMP SENSOR
<a href="#">PJRIW0TT3K</a>	Temperature Controller Panel
<a href="#">EVD0000UCO</a>	
<a href="#">BLCT2C00W2SP</a>	
<a href="#">BLCT3C00W2SP</a>	
<a href="#">L401476/PGD0</a>	PGD0 TERMINAL (PANEL MOUNTING)
<a href="#">BL0T1D000H1</a>	
<a href="#">S90C0NN001</a>	Connection cable between the PGD1 dialog terminal and the PCO5+ 3 meters long
<a href="#">E401TA00V0</a>	
<a href="#">PJS8C0HW00</a>	
<a href="#">E2V24FSFC0</a>	valve
<a href="#">E2V14FSFC0</a>	valve
<a href="#">URKDH00020</a>	Column Exhaust Kit
<a href="#">URKDTV0000</a>	Drain Tempering Valve Kit
<a href="#">URKH03T505</a>	Titanium Heater Kit
<a href="#">E3V45SSRC0</a>	
<a href="#">E2V35FSMC0</a>	
<a href="#">UEX15L0010</a>	
<a href="#">IR33C0LR00</a>	Electronic Controller
<a href="#">KITBLCT5C0</a>	
<a href="#">PJS4C0H000</a>	
<a href="#">MTADISPL00</a>	Display
<a href="#">EC080DH000</a>	Pumping station with built-in automation
<a href="#">EC040DH000</a>	Pumping station with built-in automation
<a href="#">EC020DH000</a>	Pumping station with built-in automation
<a href="#">ECKDSV0000</a>	
<a href="#">MCKDSVWC00</a>	
<a href="#">ACKR100000</a>	Water pressure reducer kit
<a href="#">ACKPS00000</a>	
<a href="#">ECKN0205D0</a>	Set of 2.5 l/h injectors
<a href="#">ECKN0305D0</a>	1 Set of nozzles 4 l/h
<a href="#">ECKN0405D0</a>	Set of nozzles 5 l/h
<a href="#">ECKN0505D0</a>	Set of nozzles 6 l/h

Product	Description
<a href="#">MCH2CON021</a>	
<a href="#">E2V11FWBC0</a>	Carel E2V11FWBC0 Expansion Valve
<a href="#">KITPS00000SP</a>	
<a href="#">UR010HM004</a>	
<a href="#">UR006HL204</a>	HEATERSTEAM