



ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Cofi

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
TRK1 30 CVD	TRANSFORMER
TRK1-30CVD.0111229099	Transformer
TRS830P/6 220V	Electric Valve
160300050	Ignition transformer
TRE820PIS0230	ELECTRONIC IGNITION TRANSFORMER
TRS820p/33	Trafo
TRK1-20CVD	Electric Valve
TRS820P/T OEM	transformer
TRE820P/16	ignition transformer
830P	Transformer
TRE820	Transformer
TIPO 1020 T 35 E	Transformator
160300010	Ignition transformer
TRS818C/12	Transformator
TRk2-30PF VD	Transformer
TRS1220	TRANSFORMER
TRG1230	ignition transformer
TRK2P-230	Electric Valve
TRE 820P/4	Ignition transformer
TRK 1-20 PCUVD	Electric Valve
TRG 1035/4	IGNITION TRANSFORMER
TRG823PC	Ignition transformer
09CA036111	Electric Valve
TRS 820P/3	ignition-transformer
TRK1-20PCUVD 120v	Electric Valve
TRG1020PC	Ignition transformer
TRS1020/21	Ignition transformer
TRS820P/39	TRANSFORMER
HV cable for TRS820P/39	High Voltage Cable
TRG623PC	TRANSFORMER
TRE820PISO3	Ignition Transformer
TRE820PISO S3	Ignition Transformer
TRS812PCISO5	TRANSFORMER
4.622-021.0	Ignition transformer
TRG823PC/2	ignition transformer
TRS820/17	Transformer

Product	Description
CAVOTRK 09CA0A1882	Primary Cable for TRK Series Transformers
160 Type TRG623PCUS	IGNITION TRANSFORMER
TRG820PC	Transformer
TRS820P	transformer
09CA018130	High Voltage Cable for TRK2-30PVD
TRS818C/S	Ignition transformer
17GOST000K	Ignition Transformer
TRS812C S1	transformer
TRL12-30C	Ignition transformer
TRS723P US	Transformer
TRE 210 PC (Code: 010956880)	Transformer
09CA0A1882	cable
160300260	Connector cable
Successor for TRG1035/6	ignition transformer
TRK2-30UVD	TRANSFORMER
TKR 2-40HK	Ignition transformer,
TRS1020/23	TRANSFORMER
11PC112031	Connector
11PC112013	Connector
04PL041442	COFI TERMINAL COVER
CAPICORDA D.4 PER CAVO D.7 11PC112010	
17G0172601	Silicone hood
TRE820PS4	Ignition Transformer
TRK1-20PCVD	transformer
17GO172601	HOOD
TRS820PISO3	TRANSFORMER
P/N:160300220; Type:TRS8030P	Ignition transformer
TRS820P (160300200)	Ignition transformer
TRK30PUFVD	Transformer
TRS820	TRANSFORMER
TRE820P/15	IGNATION TRANSFORMER
TRS820P/8	Transformer
TRS820P/9	Ignition Transformer
11PC112018	Ignition Transformer
17GO172605	Ignition Transformer
Cofi TRS820P/11 TR.S 230V	transformer
RRK2-40 HD #0114531018	High-Voltage Ignition Transformer
TRE 820 PISO	transformer
TRK2-40 HD	Ignition transformer
TRS820P/45	Ignition Transformer
COFI TRE 820 PISO1	.
820P	Ignition Transformer
Type: 820 P	Ignition Transformer
TRG1020C	ignition transformer
TRG1020C10	transformer

Product	Description
TRS610PC/5	TRANSFORMER
TRK2-30PVD	Transformer
TRK2-35	Transformer
TRS818C/17	TRANSFORMER
TRE820PISO4	TRANSFORMER
TRG1020C22	Ignition Transformer
TRS820P/T2 230/800	COFI ignition transformer
TRS818PC	TRANSFORMER
TRE 210 PC	Transformer
E820P TRE820P	Ignition Transformer
Ignition Transformer for TRS723P	TRANSFORMER
11PC112011	SOCKET
TRK2-40PVD	Ignition Transformer
TRW1P4M	Ignition Transformer
STAFFA 3S	Ignition Transformer
09CA036108	cable
TRK2-30PUVD	COFI TRANSFORMER
Mod. TRE820PISO	TRANSFORMER
TRS820P/17	Ignition Transformer
09CA036105	full cable
TRK1-30PCVD	TRANSFORMER
TRH2-30CU	TRANSFORMER
TRE 820 P	ignition transformer
TRK2-40PHK	TRANSFORMED
E820PISO2	TRANSFORMER
TRG1035	transformer
TRG 832 PC/2	Ignition Transformer
TRG1230/4	transformer
TPITK400	Transformer
TRS820P/18	Ignition Transformer
TRK2 -40VD COFI 220V	IGNITION TRANSFORMER
TRS830P	Ignition Transformer
TRS820P.230V (#57607)	Ignition Transformer
TRS818C	Ignition transformer
TRS515PC	TRANSFORMER
TRS723P US4	TRANSFORMER
TRS830P/6	TRANSFORMER
TRH2-30C	TRANSFORMER
TRK1-30CHD	TRANSFORMER
TRL24-30C	Ignition Transformer
TRK2-30PUFVD	Ignition Transformer
connector for TRS723P US	Connector for TRS723P US
TRG623PC US	Transformer
TRS515PCISO1	TRANSFORMER
TRG1020C/2	transformer

Product	Description
TRS820P/32	Ignition Transformer
TRS830P.230V	Ignition Transformer
TRS820PISO	Transformer
TRK1-20CUVD	Ignition Transformer
TRL12-30PC	Electronic Transformers
TRS820P/T1	TRANSFORMER
TRE820P/10	COFI TRANSFORMER
TRG 835P	220V 1X8000V IGNITION TRANSFORMER
TRG1020C25	TRANSFORMER
mod. TRK1-30CVD	TRANSFORMER
TRKCABLESHORT	
TRS818PC/1	
TRS1220 / 230V	
TRS818C/11	TRANSFORMER
TRE820/S1	ignition transformer
TRG1035/6	TRANSFORMER
TRS 1020	transformer
TRS1020/29	Ignition Transformer
TRS830P /8	Ignition Transformer
TRE820P/S	TRANSFORMER
TRL24-30PC	IGNITION TRANSFORMER
TRE510PC	Cofi Ignition Transforme
TRE510PC2	Cofi Ignition Transformer
830 P 1 pole X 8000V	
CAPICORDA D.4 11PC112004	
TRG823PC/2/230V	ignition transformer
TRE8210PISO 4	