



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)



# Flovex

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

## BRAND'S PRODUCTS

Product	Description
<a href="#">AEU/FE 1005-19-2</a>	Cooler
<a href="#">P/N: 002003, Type: T-8035-A-4</a>	heat exchanger
<a href="#">BEW-S-404-B-2</a>	heat exchangers
<a href="#">BEW-1008-A-2</a>	Shell and Tube Heat Exchanger
<a href="#">T-8035-A-4 (ST1.8035.A40000)</a>	exchanger
<a href="#">BEW-CUNI-1210-23-2 - 70307, 010037</a>	gasket set
<a href="#">BEW-CUNI-1210-23-2 - 70307</a>	gasket set
<a href="#">9.RIC.TC.019 (004094) BEW-4,</a>	GASKETKIT BEWOTT402M
<a href="#">BEM-303-A-2</a>	heat exchanger
<a href="#">BEM-604-B4</a>	Heat exchanger
<a href="#">FAN-OO-NM-LT-7.4-A-20-400 V-50 Hz</a>	Öl-Luftkühler
<a href="#">003782</a>	Dichtungssatz
<a href="#">ST3.8061.A40000 AI2034</a>	Heat exchanger Model:Silver t/ott 8061-A-4
<a href="#">ST 8076-B-4 Heat exchanger type</a>	Shell-and-tube Heat Exchanger
<a href="#">FAN LTO 7.8 BB</a>	Oil-Air Cooler
<a href="#">T-8091-A-4</a>	heat exchanger
<a href="#">T-OTT-8061-A-4 002014</a>	heat exchangers
<a href="#">FAN-OO-NM-LT-2.3-A-20-230 V-50 Hz 005005</a>	oil-air cooler
<a href="#">3VA0.96.166</a>	kit
<a href="#">005070 LT-2.3-B-20-230</a>	Oil-Air Cooler
<a href="#">AEW-OTL-604-13-4</a>	Dichtungssatz
<a href="#">ST1.8091.B4.0000</a>	Wärmetauscher
<a href="#">BEM-503-A-4</a>	heat exchanger
<a href="#">ST1 8061 B4000</a>	cooler
<a href="#">BEM 301.2 B4</a>	Cooler
<a href="#">BEM-802-B-4 HPS16</a>	Wärmetauscher
<a href="#">ST-8076-A-4</a>	exchanger
<a href="#">002007) T-8061-B-4</a>	heat exchangers
<a href="#">BEM/S 4020 B4</a>	Shell and Tube Heat Exchanger
<a href="#">BEW 5036 L2</a>	Shell and Tube Heat Exchanger
<a href="#">BEM 5020-A-4</a>	Exchanger
<a href="#">ST1 8035-A-4-000</a>	Exchanger
<a href="#">9RIC.TC.023</a>	Seal Kit for BEW/SLX 1209-39-2 Heat Exchanger
<a href="#">ST1 8061 A41001</a>	Shell and Tube Heat Exchanger
<a href="#">ST1 8035 A41000</a>	heat exchanger
<a href="#">D-BEM-SSX-604-A-4</a>	Shell and Tube Heat Exchanger



Product	Description
<a href="#">BEM 605-B-4</a>	Exchanger
<a href="#">T 8061-A4 COP.ALL.</a>	exchanger
<a href="#">BEWSS 5026-A-2</a>	Heat exchanger complete
<a href="#">BEWSS 6030-A-2</a>	Heat exchanger complete
<a href="#">mod. ST3 8061-A-4</a>	exchanger
<a href="#">T-8076-A-4 (ST1.8076.A40000)</a>	heat exchanger
<a href="#">mod. BEM/EZ 5040-B-4</a>	exchanger
<a href="#">ST1 8061-A-4</a>	Exchanger
<a href="#">D/BEM/S 502.6-M-4.</a>	exchanger
<a href="#">BEM-503-B-4</a>	
<a href="#">BEM 804-A-4</a>	
<a href="#">BEM-605-A-4</a>	Fixed Straight Tubesheet Heat Exchanger
<a href="#">T-8061-B-4 / ST1.8061.B41000</a>	exchanger
<a href="#">BEM 504-A-4</a>	heat exchanger
<a href="#">BEM-S-302-A-1 / EM9.3020.A1F000</a>	heat exchanger
<a href="#">ST3.8061.A40000 (T/OTT 8061-A4)</a>	exchanger
<a href="#">ST1 8035-B-4</a>	EXCHANGER
<a href="#">9RIC.EM.013</a>	Maintenance Kit for Heat Exchanger
<a href="#">9RIC.EM.012</a>	Pair of lids Pair of lids with gaskets.
<a href="#">WEM.5020.A2G000</a>	Fixed Straight Tubesheet Heat Exchanger
<a href="#">BEM-S-505-B-4</a>	Heat exchanger
<a href="#">BEMS 5050-B-4</a>	Heat exchanger
<a href="#">BEM 806.B.4</a>	Exchanger
<a href="#">9RIC.WE.004</a>	Seal kit
<a href="#">Repair kit for BEWSS 6030-A-2</a>	Repair kit
<a href="#">BEM-602.6-B-4</a>	HEAT EXCHANGER
<a href="#">BEM 6020-A-4.</a>	Heat Exchanger.
<a href="#">Gasket kit for DPX AEW/OTL 504-17-2</a>	Spare parts for oil cooler
<a href="#">DPX AEW/OTL 504-17-2</a>	oil cooler
<a href="#">BEW/OTT 402.11-2</a>	Exchanger
<a href="#">NBR-OR6387</a>	O.R GASKET
<a href="#">9RIC.EM.001</a>	Pair of lids with gaskets
<a href="#">9RIC.EM.008</a>	Gasket for heat exchanger
<a href="#">BEM 505-A-4 / PL1.5050.A4G000</a>	heat exchanger
<a href="#">FAN/LT 1.3-A 24V</a>	Exchanger
<a href="#">mod. BEWSS 502-A-2-960305</a>	heat exchanger
<a href="#">FAN/LT 5.4-A 400V</a>	Oil Air Cooler
<a href="#">BEM-603-A-4</a>	Heat exchanger
<a href="#">BEM/SX 302.6-A-2</a>	Exchanger
<a href="#">BEM 502-A4</a>	heat exchanger
<a href="#">010063</a>	Heat Exchanger
<a href="#">010064</a>	Heat Exchanger
<a href="#">BEW/SSXI 502-A2 ( D960305 )</a>	Shell and Tube Heat Exchanger
<a href="#">BEM 503-B4 FL.UNI DN50 PN16</a>	Exchanger
<a href="#">BEM 605-B-4 (DN 65 - PN 16)</a>	heat exchanger



Product	Description
<a href="#">ST1.8035.A4.0000</a>	heat exchangers
<a href="#">SILVER/OTT-8061-A-4</a>	Exchanger
<a href="#">9RIC.ST.004</a>	pair of aluminium covers
<a href="#">BEM 303 B-4</a>	heat exchanger
<a href="#">BEM 301.2-A-4</a>	exchanger
<a href="#">seal kits for BEW/FE 1310-25-4</a>	seal kits
<a href="#">BEM 5030-B-4</a>	Fixed Straight Tubesheet Heat Exchanger
<a href="#">BEM 3030-B-4</a>	Fixed Straight Tubesheet Heat Exchanger
<a href="#">ST1-8061-A-4 OTT</a>	Exchanger mod.
<a href="#">9RIC.TC.021 / X 140201</a>	Gasket Kit for Heat Exchanger
<a href="#">BEM/S 503-B4</a>	Heat Exchanger
<a href="#">9RICST003</a>	plastic lids with seal
<a href="#">BEM 303-A-4</a>	Cooler
<a href="#">BP1 504-A-2 FL DN40</a>	Exchanger
<a href="#">Mod. ST1 8061-A-4</a>	Pair of covers complete with gaskets for heat exchanger
<a href="#">BEM 302.6-A-4</a>	exchanger
<a href="#">002010</a>	Lid Pair
<a href="#">ST1.8091.A4.1000</a>	heat exchangers
<a href="#">ST1.8091.B4</a>	Oil heat exchangers
<a href="#">BEW 1012.6-9-2</a>	Exchanger
<a href="#">BEM-806-A-4</a>	Exchanger
<a href="#">BEW 1208-7-2</a>	Exchanger
<a href="#">ST3.8061.A40000</a>	Exchanger
<a href="#">BEMS 502-A-4</a>	
<a href="#">BEM 8050-B-4-FL DN80 PN16</a>	Exchanger
<a href="#">BEM 3020-A-4-FLDN25PN16</a>	Fixed Straight Tubesheet Heat Exchanger
<a href="#">BEW 804-A-2</a>	exchanger
<a href="#">BEM 610.6-13-2</a>	Heat Exchanger
<a href="#">X25497</a>	Heat Exchanger Component
<a href="#">BEM 606-B-4</a>	Fixed Straight Tubesheet Heat Exchanger
<a href="#">T 8061-A4 (ST1.8061.A40000)</a>	Exchanger
<a href="#">BEW 1006-B-2</a>	Heat exchanger
<a href="#">T 8061-B-4</a>	Shell and Tube Heat Exchanger
<a href="#">BEM-505-A-4 HP30 Code X25171</a>	Fixed Straight Tubesheet Heat Exchanger
<a href="#">3VA0.96.166 (X29811)</a>	3/8" gas T-plug with zinc
<a href="#">Gasket kit for model BXU / SSLX 1204-1-2 dwg 100903</a>	complete set of housing seals
<a href="#">003039 - BEM-602-B-4</a>	heat exchanger
<a href="#">Gasket kit for BEM 505-A4 HP30 exchanger ( Cod. FLKITGUARN5" )</a>	Gasket Kit for Heat Exchanger
<a href="#">BEW/OTT 402.6-11-2</a>	Shell and Tube Heat Exchanger
<a href="#">BEW/OTT 402-11-2 (TWB.4020.970804)</a>	Shell and Tube Heat Exchanger
<a href="#">T8035-B4</a>	Exchanger
<a href="#">gasket kit for AEW / FE 505-25-2</a>	Gasket kits
<a href="#">606.8-13-1</a>	Shell and Tube Heat Exchanger
<a href="#">806-13-1 (dwg 130510)</a>	Shell and Tube Heat Exchanger



Product	Description
<a href="#">806-13-1 (dwg 130509)</a>	Shell and Tube Heat Exchanger
<a href="#">BEM/S 403M-4</a>	Fixed Tubesheet Heat Exchanger
<a href="#">002005</a>	Heat Exchanger
<a href="#">BEM/EZ 502.6-5-4</a>	Exchanger
<a href="#">P/N: 007069, Type: DPX-AEW-OTT-610-27-2 - 040902</a>	exchanger
<a href="#">Gasket kit</a>	Gasket Kit for Heat Exchangers
<a href="#">Tube bundle for BEU/SSL 504-L-2</a>	Replacement Tube Bundle for Heat Exchanger
<a href="#">Gasket kit for AEW/SSLXI 1012-25-2</a>	Complete kit
<a href="#">BEM 502-A-4 FL. UNI DN 40</a>	Heat Exchanger
<a href="#">coppia di coperchi per scambiatore ST3 8061</a>	Pair of Covers for Heat Exchanger
<a href="#">ST1.8035.A41000 Model: T 8035-A4</a>	Shell and Tube Heat Exchanger
<a href="#">002010/ T-80</a>	lid pair
<a href="#">T8035-A-4</a>	heat exchangers
<a href="#">BXU/SSLXI 2305-0-2</a>	
<a href="#">Camprofile with 321+MICA</a>	Gasket for Heat Exchanger
<a href="#">BEM/S-805-B-4(304L)</a>	Exchanger
<a href="#">ST1.8035.030217</a>	exchanger
<a href="#">BEM/S 503-M-4</a>	Exchanger
<a href="#">BEM 501.2-A2</a>	Exchanger
<a href="#">BEM-504-B-4</a>	Fixed Tubesheet Heat Exchanger
<a href="#">BEW/S 404-A-2</a>	Removable Bundle Heat Exchanger
<a href="#">2038 - T 8035-A4 ST1.8035.A41000</a>	Shell and Tube Heat Exchanger
<a href="#">BEM 803-B-4 / (EM1.8030.B4G000)</a>	Fixed Tubesheet Heat Exchanger
<a href="#">T 8035-A4 1</a>	Shell and Tube Heat Exchanger
<a href="#">BEM/S 605-B4</a>	Fixed Tubesheet Heat Exchanger
<a href="#">004152 BEW-4</a>	gasket kit
<a href="#">BEM 606-33-2</a>	Fixed Tubesheet Heat Exchanger
<a href="#">BEM 5" NBR (9RIC.EM.008)</a>	Gasket kit
<a href="#">T 8091-B4</a>	Heat exchanger
<a href="#">Kit caps with zincs</a>	Cap kit with zincs
<a href="#">Front Cover For SILVER T8035-A-4</a>	Replacement Front Cover for Heat Exchanger
<a href="#">BEM-502-B-4</a>	heat exchanger
<a href="#">BEW 1006-A-2</a>	Removable Bundle Heat Exchanger
<a href="#">replacement end cap for Silver T 8061-A-4</a>	Replacement End Cap for Heat Exchanger
<a href="#">9RIC.ST.005 / X6122</a>	gasket kit
<a href="#">9RIC.ST.003 / X6084</a>	pair of plastic covers (including gaskets)
<a href="#">BEM/OTT 604-B4</a>	Exchanger
<a href="#">BEW/SSXI 405-B2 TEMA C ASMEVIII</a>	Complete exchanger
<a href="#">Exchanger tube bundle BEW/SSXI 405-B2 TEMA C ASME VIII</a>	Exchanger tube bundle
<a href="#">Exchanger gasket kit BEW/SSXI 405-B2 TEMA C ASME VIII</a>	Exchanger gasket KIT
<a href="#">112009</a>	heat exchanger
<a href="#">010091</a>	gasket kit
<a href="#">010092</a>	tube bundle



Product	Description
<a href="#">ST1.8061.A41000 AN 0081</a>	Shell and Tube Heat Exchanger
<a href="#">KWL.5040.110320 BEU/SSLX 504-L2</a>	Shell and Tube Heat Exchanger
<a href="#">X39607</a>	cover
<a href="#">9RIC.WE.004</a>	Seal Kit for Heat Exchanger
<a href="#">9RIC.EM.013 / X14235</a>	Maintenance Kit for Heat Exchanger
<a href="#">Gasket kit for AEW/SSLXI 1512-41-4</a>	Seal kit
<a href="#">010094</a>	Pair of lids
<a href="#">BEM-SS-605-11-4 - HE3785.06 (112021)</a>	heat exchanger
<a href="#">BXU/SSLXI 1304-0-2</a>	EXCHANGER
<a href="#">BEM-302-A-2</a>	heat exchanger
<a href="#">003496 / BEM-501.2-A-2</a>	Exchanger
<a href="#">FAN/LT 5.4-B 400V</a>	exchanger
<a href="#">003003 / BEM-502-A-4</a>	heat exchanger
<a href="#">EM1-3012-A-4G</a>	Fixed Tubesheet Heat Exchanger
<a href="#">O-ring for T8076-A-4</a>	Replacement O-ring for Heat Exchanger
<a href="#">002021 / T-80</a>	Heat Exchanger Model T-80
<a href="#">SILVER T 8061-B-4</a>	exchanger
<a href="#">002005 / T-8061-A-4</a>	heat exchangers
<a href="#">006018 / BEU-SL-502-M-2 - 131213</a>	heat exchangers
<a href="#">RSR 4706</a>	Heat Exchanger Component
<a href="#">BEM-SX-504-B-4 - AF4932</a>	heat exchangers
<a href="#">BEW-CUNi-1312-13-2</a>	heat exchanger
<a href="#">BEM-810-A-2</a>	heat exchanger
<a href="#">006019 - BEU-SSLX-504-L-2 - 110320</a>	heat exchanger
<a href="#">010102 - Tube bundle for BEU-SSLX-504-L-2 - 110320</a>	Tube bundle
<a href="#">003537 - BEM-502-A-2</a>	Heat exchanger
<a href="#">BEM/SX 504-B4 (EL9.5040.B4G000)</a>	exchanger
<a href="#">T 8076-A-4</a>	heat exchanger
<a href="#">BEW/SS 402-A-2- 980211</a>	heat exchanger
<a href="#">Gasket set for BEW-OTL-504-29-2 - A11611+1612</a>	gasket set
<a href="#">T 8061-A4</a>	Shell and Tube Heat Exchanger
<a href="#">112043 / BEM-S-807-B-4 HPS25</a>	heat exchanger
<a href="#">DPX-BEM-S-403-13-2 - 150506</a>	Double cooler
<a href="#">003106 / BEM-8</a>	gasket kit
<a href="#">ST1.8076.A41000</a>	Shell and Tube Heat Exchanger
<a href="#">BEW/SSXI 402-A-2</a>	Exchanger
<a href="#">Exchanger gasket kit AEW/OTL 1012-33-2</a>	Gasket Kit for Heat Exchanger Model AEW/OTL 1012-33-2
<a href="#">DWG 030538</a>	gasket kit
<a href="#">DPX.606.8-41-2</a>	Double exchanger
<a href="#">T-OTT-8061-A-4</a>	heat exchanger
<a href="#">BEM 805-15-4 (EM1.8050.980426)</a>	EXCHANGER
<a href="#">BEM 605-A4 (EM16050A4G000)</a>	Heat exchanger
<a href="#">BEM/S 403-A-4</a>	heat exchanger
<a href="#">BEM-802.6-B-4</a>	heat exchanger
<a href="#">ST1.8035.A40001</a>	Shell and Tube Heat Exchanger



Product	Description
<a href="#">003101</a>	pair of covers
<a href="#">Pair of aluminum covers with gasket for T 8061-A-4 (ST1.8061.A41000)</a>	Replacement Aluminum Covers with Gasket for Heat Exchanger Model T 8061-A-4
<a href="#">BEW/SL 502-A-2 9RIC.WE.001</a>	Pair of covers with gaskets for exchanger
<a href="#">BEM 5026-A-4.</a>	Heat exchanger
<a href="#">UNIT AEW/OTL 403-13-2</a>	Gasket KIT
<a href="#">X6032</a>	KIT pair of covers and gaskets
<a href="#">OLC-S-605-7-1 HPT15 • DWG 040346</a>	Shell and Tube Heat Exchanger
<a href="#">OLC-S-605-7-1 HPT30 • DWG 040347</a>	Shell and Tube Heat Exchanger
<a href="#">OLC-S-805-7-1 • DWG 040345</a>	Shell and Tube Heat Exchanger
<a href="#">002038 - T-8035-A-4</a>	Shell and Tube Heat Exchanger
<a href="#">BEW/SX 402.6.B-2</a>	exchanger
<a href="#">BEM 505-B-4 FL. DN50PN16</a>	Fixed Tubesheet Heat Exchanger
<a href="#">2051 - T-8035-A-4 - ST1.8035.A41001</a>	heat exchanger
<a href="#">BEM-806-M-4</a>	heat exchanger
<a href="#">T8076-B-4</a>	exchanger
<a href="#">BEM/CuNi 90-10 604-B4</a>	
<a href="#">T 8076-A-4 ST1.8076.A4000078616</a>	heat exchanger
<a href="#">BEM1008L2</a>	Heat Exchanger
<a href="#">BEM 504-B4 (EM15040)</a>	
<a href="#">BEM-SS-808-B-4 HPS16-HPT10</a>	
<a href="#">FAN-OO-NM-LT-5.4-A-20-400 V-50 Hz</a>	
<a href="#">AEW/SSLXI 1512-41-4</a>	Gasket kit for exchanger
<a href="#">BEM 506-A-4</a>	exchanger
<a href="#">BEM/SSX 404.6-33-4</a>	Heat exchanger
<a href="#">003062 BEM-502-B-4</a>	
<a href="#">003097</a>	
<a href="#">BEM-805-B-4</a>	
<a href="#">BEM-302-A-4</a>	heat exchanger
<a href="#">BEM-605-M-2</a>	Heat exchanger
<a href="#">BEM 602-B-4</a>	exchanger
<a href="#">BEM/OT 1206.8-11-2</a>	Heat exchanger
<a href="#">BEM 302.6-A-4 Z=16 BAR</a>	heat exchanger
<a href="#">BEM 304-A4</a>	
<a href="#">T/OTT 8061-A4 COP.ALL.</a>	Heat exchanger
<a href="#">BEM 505-A-4 / EM1.5050.A4G000</a>	exchanger
<a href="#">X25485</a>	Exchanger
<a href="#">BEM 506-B4 (X21124)</a>	HEAT EXCHANGER