







93 S Railroad Avenue Unit C Bergenfield NJ 07621 USA www.enapart.com sales@enapart.com



Via del Canneto 35. Borgosatollo, Brescia - Italia www.enapart.it vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Ağaoğlu My Newwork No:3/15 Ataşehir / İstanbul www.enapart.net satis@enapart.net



PRIVADA 10 B SUR #3908 COL. ANZUREZ, C.P. 72530, PUEBLA, PUE www.enapart.com.mx sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325 Frankfurt am Main, Germany www.enapart.de anfrage@enapart.de



4 boulevard Carnot, 95400 villiers-le-bel, Paris, France www.enapart.fr sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА ФРАНКА, БУДИНОК 55, ПОВЕРХ 3 www.enapart.com.ua sales@enapart.com.ua



MUNICIPIUL BUCUREŞTI, SECTOR 3, B-DUL BASARABIA, NR.250, CORP P+5 Hempstead, HP1 3AF , United Kingdom www.enapart.ro sales@enapart.ro



〒584-0023 大阪府富田林市若松町 東2丁目2番16号 www.enapart.co.jp sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS NIEVES 12 ,LOCAL ,50012,ZARAGOZA www.enapart.es ventas@enapart.es



Складова база "Онгъл", Склад А2, п.к. 4006, гр. Пловдив, България www.enapart.bg sales@enapart.bg



3 Austin Mews, High Street, Hemel www.enapart.co.uk sales@enapart.co.uk





Gutor

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

S30-1940	Product	Description
OH-1075 Replacement Kit for DC Current XXW 0M-94005 REC SDC.0M-94005.GUTOR 0P0010AB Fan speed control board 490-0023 Transformer 0N-0901C ASSEMBLY CONTROLLER BOX 0P2556B PCB ASSY INTERFACE BOARD.0P2556B.GUTOR 0N-0903 FAN MODULE 3FAN.0N-0903.GUTOR 0N-0904A ASSEMBLY FAN MODULE 0N-0914A Assy fan module 516-0105A FUSE.515-9001.GUTOR 515-9015 FUSE.515-9001.GUTOR 515-9016 INDICATOR F.SEMIC. FUSE FM/FMM 0N-0908 ASSY SBS CONBOX.0N-0908.GUTOR 0P2405AA Board 0C0922 INVERTER POWER MODULE.0C0922.GUTOR 0P2552 PN: 640-2552 POWER CONNECTION BOARD 0P3306 POP2922A 0P1922A PCB CONTROLLER PARALLEL OPERATING A024 0C0949 RECTIFIER MODULE A030.0C0949.GUTOR 0P9912A RELAY BOARD A078.0P9912A.GUTOR 0P9912A RELAY BOARD A078.0P9912A.GUTOR 0C0946 STATIC SWITCH MODULE A035.0C0946.GUTOR 0N-0336A MODBUS PROTOCOL,A074 0G-0399924B,Gutor	<u>530-1940</u>	
DM-94005 REC SDC.0M-94005.GUTOR	<u>0P6291B</u>	
OP0010AB	<u>OH-1075</u>	Replacement Kit for DC Current XXW
490-0023	<u>0M-94005</u>	REC SDC.0M-94005.GUTOR
A30-0048A	<u>0P0010AB</u>	Fan speed control board
ON-0901C ASSEMBLY CONTROLLER BOX	<u>490-0023</u>	
OP2556B	<u>430-0048A</u>	Transformer
ON-0903	<u>0N-0901C</u>	ASSEMBLY CONTROLLER BOX
ON-0904A ASSEMBLY FAN MODULE 0N-0914A Assy fan module 516-0105A FUSE.515-9001.GUTOR 515-9001 FUSE.515-9001.GUTOR 515-9015 INDICATOR F.SEMIC. FUSE FM/FMM 0N-0908 ASSY SBS CONBOX.0N-0908.GUTOR 0P2405AA Board 0C0922 INVERTER POWER MODULE.0C0922.GUTOR 0P2552 P/N: 640-2552 POWER CONNECTION BOARD 0P3306 PCB CONTROLLER PARALLEL OPERATING A024 0C0949 RECTIFIER MODULE A030.0C0949.GUTOR 0P9912A RELAY BOARD A078.0P9912A.GUTOR 0C0946 STATIC SWITCH MODULE A035.0C0946.GUTOR 0N-0936A MODBUS PROTOCOL,A074 0G-0399924B,Gutor 0W90401 OP0280AB 0P02844 COMPLETE PCB PSU 220VDC OUT 0500160	<u>0P2556B</u>	PCB ASSY INTERFACE BOARD.0P2556B.GUTOR
ON-0914A Assy fan module 516-0105A 515-9001 FUSE.515-9001.GUTOR 515-9015 515-9017 INDICATOR F.SEMIC. FUSE FM/FMM 0N-0908 ASSY SBS CONBOX.0N-0908.GUTOR 0P2405AA Board 0C0922 INVERTER POWER MODULE.0C0922.GUTOR 0P2552 P/N : 640-2552 POWER CONNECTION BOARD 0P3306 PCB CONTROLLER PARALLEL OPERATING A024 0C0949 RECTIFIER MODULE A030.0C0949.GUTOR 0P9912A RELAY BOARD A078.0P9912A.GUTOR 0C0946 STATIC SWITCH MODULE A035.0C0946.GUTOR 0N-0936A 0G-0399924B MODBUS PROTOCOL,A074 0G-0399924B,Gutor 0W90401 0P0280AB PSU AC, A201 0P0280,Gutor 0P0284 COMPLETE PCB PSU 220VDC OUT 0500160	<u>0N-0903</u>	FAN MODULE 3FAN.0N-0903.GUTOR
516-0105A 515-9001 FUSE.515-9001.GUTOR 515-9015 515-9017	<u>0N-0904A</u>	ASSEMBLY FAN MODULE
\$15-9011 \$515-9015 \$15-9017 \$15-9018 INDICATOR F.SEMIC. FUSE FM/FMM ON-0908 ASSY SBS CONBOX.0N-0908.GUTOR 0P2405AA Board OC0922 INVERTER POWER MODULE.0C0922.GUTOR OP2552 P/N : 640-2552 POWER CONNECTION BOARD 0P3306 OP1922A PCB CONTROLLER PARALLEL OPERATING A024 OC0949 RECTIFIER MODULE A030.0C0949.GUTOR OP9912A RELAY BOARD A078.0P9912A.GUTOR OC0946 STATIC SWITCH MODULE A035.0C0946.GUTOR ON-0936A OG-0399924B MODBUS PROTOCOL,A074 OG-0399924B,Gutor OW90401 OP0280AB PSU AC, A201 0P0280,Gutor	<u>0N-0914A</u>	Assy fan module
515-9015 515-9018 INDICATOR F.SEMIC. FUSE FM/FMM 0N-0908 ASSY SBS CONBOX.0N-0908.GUTOR 0P2405AA Board 0C0922 INVERTER POWER MODULE.0C0922.GUTOR 0P2552 P/N: 640-2552 POWER CONNECTION BOARD 0P3306 PCB CONTROLLER PARALLEL OPERATING A024 0C0949 RECTIFIER MODULE A030.0C0949.GUTOR 0P9912A RELAY BOARD A078.0P9912A.GUTOR 0C0946 STATIC SWITCH MODULE A035.0C0946.GUTOR 0N-0936A MODBUS PROTOCOL,A074 0G-0399924B,Gutor 0W90401 OP0280AB 0P0284 COMPLETE PCB PSU 220VDC OUT 0500160	<u>516-0105A</u>	
515-9017 INDICATOR F.SEMIC. FUSE FM/FMM 0N-0908 ASSY SBS CONBOX.0N-0908.GUTOR 0P2405AA Board 0C0922 INVERTER POWER MODULE.0C0922.GUTOR 0P2552 P/N : 640-2552 POWER CONNECTION BOARD 0P3306 PCB CONTROLLER PARALLEL OPERATING A024 0C0949 RECTIFIER MODULE A030.0C0949.GUTOR 0P9912A RELAY BOARD A078.0P9912A.GUTOR 0C0946 STATIC SWITCH MODULE A035.0C0946.GUTOR 0N-0936A MODBUS PROTOCOL,A074 0G-0399924B,Gutor 0W90401 PSU AC, A201 0P0280,Gutor 0P0284 COMPLETE PCB PSU 220VDC OUT 0500160	<u>515-9001</u>	FUSE.515-9001.GUTOR
515-9018 INDICATOR F.SEMIC. FUSE FM/FMM 0N-0908 ASSY SBS CONBOX.0N-0908.GUTOR 0P2405AA Board 0C0922 INVERTER POWER MODULE.0C0922.GUTOR 0P2552 P/N: 640-2552 POWER CONNECTION BOARD 0P3306 PCB CONTROLLER PARALLEL OPERATING A024 0C0949 RECTIFIER MODULE A030.0C0949.GUTOR 0P9912A RELAY BOARD A078.0P9912A.GUTOR 0C0946 STATIC SWITCH MODULE A035.0C0946.GUTOR 0N-0936A MODBUS PROTOCOL,A074 0G-0399924B,Gutor 0W90401 PSU AC, A201 0P0280,Gutor 0P0280AB PSU AC, A201 0P0280,Gutor 0P0284 COMPLETE PCB PSU 220VDC OUT 0500160	<u>515-9015</u>	
ON-0908 ASSY SBS CONBOX.0N-0908.GUTOR 0P2405AA Board 0C0922 INVERTER POWER MODULE.0C0922.GUTOR 0P2552 P/N : 640-2552 POWER CONNECTION BOARD 0P3306 PCB CONTROLLER PARALLEL OPERATING A024 0C0949 RECTIFIER MODULE A030.0C0949.GUTOR 0P9912A RELAY BOARD A078.0P9912A.GUTOR 0C0946 STATIC SWITCH MODULE A035.0C0946.GUTOR 0N-0936A MODBUS PROTOCOL,A074 0G-0399924B,Gutor 0W90401 PSU AC, A201 0P0280,Gutor 0P0280AB PSU AC, A201 0P0280,Gutor 0P0284 COMPLETE PCB PSU 220VDC OUT 0500160	<u>515-9017</u>	
OP2405AA Board 0C0922 INVERTER POWER MODULE.0C0922.GUTOR 0P2552 P/N : 640-2552 POWER CONNECTION BOARD 0P3306 PCB CONTROLLER PARALLEL OPERATING A024 0C0949 RECTIFIER MODULE A030.0C0949.GUTOR 0P9912A RELAY BOARD A078.0P9912A.GUTOR 0C0946 STATIC SWITCH MODULE A035.0C0946.GUTOR 0N-0936A MODBUS PROTOCOL,A074 0G-0399924B,Gutor 0W90401 OP0280AB 0P0284 COMPLETE PCB PSU 220VDC OUT 0500160	<u>515-9018</u>	INDICATOR F.SEMIC. FUSE FM/FMM
OC0922 INVERTER POWER MODULE.0C0922.GUTOR 0P2552 P/N : 640-2552 POWER CONNECTION BOARD 0P3306 PCB CONTROLLER PARALLEL OPERATING A024 0C0949 RECTIFIER MODULE A030.0C0949.GUTOR 0P9912A RELAY BOARD A078.0P9912A.GUTOR 0C0946 STATIC SWITCH MODULE A035.0C0946.GUTOR 0N-0936A MODBUS PROTOCOL,A074 0G-0399924B,Gutor 0W90401 OP0280AB 0P0284 COMPLETE PCB PSU 220VDC OUT 0500160	<u>0N-0908</u>	ASSY SBS CONBOX.0N-0908.GUTOR
0P2552 P/N : 640-2552 POWER CONNECTION BOARD 0P3306 0P1922A 0C0949 PCB CONTROLLER PARALLEL OPERATING A024 RECTIFIER MODULE A030.0C0949.GUTOR 0P9912A RELAY BOARD A078.0P9912A.GUTOR 0C0946 STATIC SWITCH MODULE A035.0C0946.GUTOR 0N-0936A MODBUS PROTOCOL,A074 0G-0399924B,Gutor 0W90401 OP0280AB 0P0284 COMPLETE PCB PSU 220VDC OUT 0500160	<u>0P2405AA</u>	Board
0P3306 PCB CONTROLLER PARALLEL OPERATING A024 0C0949 RECTIFIER MODULE A030.0C0949.GUTOR 0P9912A RELAY BOARD A078.0P9912A.GUTOR 0C0946 STATIC SWITCH MODULE A035.0C0946.GUTOR 0N-0936A MODBUS PROTOCOL,A074 0G-0399924B,Gutor 0W90401 PSU AC, A201 0P0280,Gutor 0P0280AB PSU AC, A201 0P0280,Gutor 0P0284 COMPLETE PCB PSU 220VDC OUT 0500160	<u>0C0922</u>	INVERTER POWER MODULE.0C0922.GUTOR
0P1922A PCB CONTROLLER PARALLEL OPERATING A024 0C0949 RECTIFIER MODULE A030.0C0949.GUTOR 0P9912A RELAY BOARD A078.0P9912A.GUTOR 0C0946 STATIC SWITCH MODULE A035.0C0946.GUTOR 0N-0936A MODBUS PROTOCOL,A074 0G-0399924B,Gutor 0W90401 PSU AC, A201 0P0280,Gutor 0P0280AB PSU AC, A201 0P0280,Gutor 0P0284 COMPLETE PCB PSU 220VDC OUT 0500160	0P2552 P/N : 640-2552	POWER CONNECTION BOARD
0C0949 RECTIFIER MODULE A030.0C0949.GUTOR 0P9912A RELAY BOARD A078.0P9912A.GUTOR 0C0946 STATIC SWITCH MODULE A035.0C0946.GUTOR 0N-0936A MODBUS PROTOCOL,A074 0G-0399924B,Gutor 0W90401 PSU AC, A201 0P0280,Gutor 0P0280AB PSU AC, A201 0P0280,Gutor 0P0284 COMPLETE PCB PSU 220VDC OUT 0500160	<u>0P3306</u>	
0P9912A RELAY BOARD A078.0P9912A.GUTOR 0C0946 STATIC SWITCH MODULE A035.0C0946.GUTOR 0N-0936A MODBUS PROTOCOL,A074 0G-0399924B,Gutor 0W90401 PSU AC, A201 0P0280,Gutor 0P0280AB PSU AC, A201 0P0280,Gutor 0P0284 COMPLETE PCB PSU 220VDC OUT 0500160	<u>0P1922A</u>	PCB CONTROLLER PARALLEL OPERATING A024
0C0946 STATIC SWITCH MODULE A035.0C0946.GUTOR 0N-0936A 0G-0399924B 0W90401 MODBUS PROTOCOL,A074 0G-0399924B,Gutor 0P0280AB PSU AC, A201 0P0280,Gutor 0P0284 COMPLETE PCB PSU 220VDC OUT 0500160	<u>0C0949</u>	RECTIFIER MODULE A030.0C0949.GUTOR
ON-0936A MODBUS PROTOCOL,A074 0G-0399924B,Gutor 0W90401 PSU AC, A201 0P0280,Gutor 0P0280AB PSU AC, BSU 220VDC OUT 0500160	<u>0P9912A</u>	RELAY BOARD A078.0P9912A.GUTOR
0G-0399924B MODBUS PROTOCOL,A074 0G-0399924B,Gutor 0W90401 PSU AC, A201 0P0280,Gutor 0P0280AB PSU AC, A201 0P0280,Gutor 0P0284 COMPLETE PCB PSU 220VDC OUT 0500160	<u>0C0946</u>	STATIC SWITCH MODULE A035.0C0946.GUTOR
0W90401 PSU AC, A201 0P0280,Gutor 0P0280AB PSU AC, A201 0P0280,Gutor 0P0284 COMPLETE PCB PSU 220VDC OUT 0500160	<u>0N-0936A</u>	
0P0280AB PSU AC, A201 0P0280,Gutor 0P0284 COMPLETE PCB PSU 220VDC OUT 0500160	<u>0G-0399924B</u>	MODBUS PROTOCOL,A074 0G-0399924B,Gutor
<u>0P0284</u> COMPLETE PCB PSU 220VDC OUT 0500160	<u>0W90401</u>	
	<u>0P0280AB</u>	PSU AC, A201 0P0280,Gutor
450-0307B	<u>0P0284</u>	COMPLETE PCB PSU 220VDC OUT 0500160
	<u>450-0307B</u>	
UNC1-432-6830 transformer	<u>UNC1-432-6830</u>	transformer
P/N 0P2560A PCB, Assy static switch controller board	<u>P/N 0P2560A</u>	PCB, Assy static switch controller board
<u>0P6259</u> EXTERNAL CONN.BOARD	<u>0P6259</u>	EXTERNAL CONN.BOARD
0M-94000 REC SDC TH MOD NO SDIDC=<160ADC	<u>0M-94000</u>	REC SDC TH MOD NO SDIDC=<160ADC

Gutor Page 1 / 6





Product	Description
430-0048B	 Transformer
940-0290	CABLE TEMPERATURE PROBE
0P6290B	Rectifier
0H-1083	CB MOUNTING PLATE INSTALLATION KIT
OP0110	
234-9228	
<u>0P2560B</u>	PCB ASSY STATIC SWITCH CONTROLLER
<u>0P2439A</u>	PCB Assembly Master Logic II Type
<u>803-0090</u>	
<u>0W11710</u>	
<u>202-3682</u>	CAP HAND 350V 20% 6800UF 85C RD
<u>0W11712</u>	CB03 BRIDGE WIRE
<u>0W11711</u>	
<u>0C0950</u>	Module Rectifier,
<u>0C0920</u>	
<u>0P2562AA-018</u>	
<u>490-0021</u>	Fan
<u>0H-1075</u>	Replacement Kit for DC CURRENT XXW
<u>OP3895AC</u>	PCBASSYXXWCONTROLLER
<u>WGCSMIS</u>	
<u>202-0109</u>	
<u>0M-97221</u>	AC-DC MECH.KIT 775 1PH
<u>0W11714</u>	CB03 180MM_4MM2 WIRE
<u>451-0086</u>	Electronic Board
<u>0M-8190</u>	ASSEMBLY FAN
<u>205-1104</u>	CAPACITOR
<u>0H-1082</u>	FIXING OF CABLE CONN TO CAPACITORS
<u>0P-4916-001</u>	ASSEMBLY CAP BOARD
<u>0N-0906C</u>	POWER MODULE
<u>0M-97225</u>	
<u>515-9031</u>	
<u>0N-96488A</u>	
<u>430-9526B</u>	TRANSFORMER
<u>540-9198A</u>	SWITCH
<u>0C0074</u>	
<u>0N-0902A</u>	fan
<u>0N-0917</u>	ASSEMBLY FAN MODULE
<u>0M-94001</u>	REC SDC TH MOD NO SD160ADC <idc=<315ad< td=""></idc=<315ad<>
<u>0P6287B</u>	Kit for DC current
<u>0N-0937A</u>	
<u>0M-94028</u>	
<u>340-9106</u>	
<u>0M-94035B</u>	BOARD PRINTED CIRCUIT
<u>0P9917</u>	
<u>0W90434</u>	

Gutor Page 2 / 6





Product	Description
<u>0P6286B</u>	CURRENT Transducers
0P6284B	CURRENT Transducers
515-9004	FUSE: SEMICONDUCTOR
0P6258AA	Power supply
0M-6728	ASSY FANBOX SDC SMALL
<u>0N0916</u>	MODULE
<u>0</u> P0108	
<u>0M-94088</u>	
<u>540-9108</u>	
530-1937	
<u>OP9895</u>	
101-1000	
0P6285B	
0P6281AC	
202-5222	
<u>202-3222</u> 0P6258AB	Power supply
814-0009	1 Owel supply
516-0129	
511-0069	
<u>511-0065</u>	
0P6286AC	
<u>515-9024</u>	FUSE
	FUSE
<u>515-9027</u>	FUSE
<u>0P2438AA</u>	
<u>P007</u>	
<u>P009</u>	
<u>0P6277AC</u>	
<u>0P9907AA</u>	
<u>0P0285AC</u>	
<u>0P1923A</u>	
<u>0P2406AA</u>	
110-0000	
WGCSSOFTWARE	SOFTWARE UPDATE TO SP6
WGCSDRAWING	DRAWING UPDATE 4 HOURS
<u>0P1922AB</u>	PCB controller parallel operating
<u>0P6276AC</u>	
<u>0P6279AC</u>	
<u>0H-1541</u>	neutral connection kit
<u>0H-1539</u>	wire fixation kit
<u>234-9225</u>	Capacitor
<u>0P9914</u>	Board printed circuit
<u>351-0003</u>	Battery
<u>0P6274AC</u>	
<u>0C0919</u>	PM 1/2 24-300VDC 500ARMS/1425APEAK UL
<u>0P0110AA</u>	

Gutor Page 3 / 6





Product	Description
0P6257	CONTROL UNIT
0M-6727	Fan
490-0025	
515-9046	FUSE.515-9046.GUTOR
0N-0905C	ASSY HUMAN MACHINE INTERFACE
0P6264AA	Board
OM-94028	SUB ASSEMBLY FAN 230VAC FOR ROOF XXW E02x
515-9016	
430-4081B	Transformer
0P0284AC	COMPLETE PCB PSU
0P3895AD	Controller
P/N : 0P6290B	Lithium battery for inverter type
OC0921	Zianam Saasiy loi involtor typo
515-9030	
<u>515-9904</u>	
515-9053	
0P0071AB	
234-1126	Capacitor
0P2552AB	Power Connection Board Assembly
430-9530B	TRANSFORMER
875-2167	AIR FILTER ASSEMBLY
0N-09024	ASSEMBLY FAN MODULE
530-9662	MCB AUX CONTACT (1CO) ACTI9 IC60
540-9152	BYPASS MAN. SW. 1P. 3POS 50A 2AX NO.NC
0P5617AA	PCB ASSY XXW RS232 INTERFACE
Certificate of origin	
357-0064	
0M-8190A	
UNC1X-0P-00089	Board
<u>515-9026</u>	
0M-90703	
0P6284AC	
0M-8190B	
515-9019	
0P9909AA	
515-9043	
0N-74143	
0P6289AC	SENSOR
0P9895AB	
0P820-9604S	
PD820-9604	
0M-9635CHGUTOR	
870-27994	
515-9226	
515-9128	

Gutor Page 4/6





Product	Description
<u>0P1161AA</u>	XXW I/F BOARD 220 VDC EMC REINFORCED
<u>0P6282AC</u>	CT DC 205A
UNC1X-0P-00086	
Certificate of origin by our local chambre of commerce	
530-9445	
<u>870-17049</u>	
0P6205AB	
<u>0N-0295</u>	
610-0123A	
610-0283A	
610-0286A	
3PH 760.5A ACC	
0C0083B	
920-0047	Voltage transducer
UNC1-391-0178	- Jiago Ranodooi
AP9810	APC Dry Contact I/O Accessory
986-3782D	Al O bly Collact I/O Accessory
<u>960-9762B</u> 0P1439AB	PCB ASSY SDC Controller
0P1261AB	Specification Interface/ PSU Board
UNC1X-0P-00112	Specification interface/ F30 board
0M-9643GUTOR	ASSY AP9643 AND FW GUTOR XXW SDC
0N-0882	ASST AF9043 AND FW GOTOR XXW SDC
0M-8190C-SP	SUBASSY FAN
<u>0M-95081</u>	SUBASSI FAN
<u>0N-74145</u>	
0P0285AD	
<u>0N-74144</u>	
<u>0C0918B</u>	
<u>0N-74160</u>	
<u>0N-0906D</u>	
<u>0P3306AB</u>	
<u>0P2558AB</u>	
<u>0N-74153</u>	
<u>UNC1-432-7544</u>	BYPASS STABILZIER STABILIZER
<u>UNC1-432-7559</u>	TRAFO FOR BYPASS STABILIZER
<u>0P6285AC</u>	
PXP 1010-400/230-EN-R	
<u>0P0926AA</u>	PCB ASSY External
<u>0P8593AA-001</u>	Electronic board
<u>430-9529B</u>	Interface Transformer
<u>0M-97220</u>	AC MECHANICAL KIT
<u>0P0010AB</u>	·
<u>0W11713A</u>	wire
CAPACITOR RDL 3UF 400V +/-5%// 234-0335A	CAPACITOR
<u>0P6288AC</u>	TRANSFORMER

Gutor Page 5 / 6





Product	Description
<u>TME08851</u>	CAP Film MKP CYLSCREW
<u>490-0023</u>	
<u>515-9028</u>	SEMICONDUCTOR FUSE
certificate of conformity	
<u>0P0930AA</u>	Static switch control, PCB Assy
<u>940-0024E</u>	

Gutor