



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Hontko

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">A2-G-256 NR</a>	Encoder
<a href="#">A3-XB022</a>	
<a href="#">HPG-N2-100-L</a>	Manual Pulse Generator
<a href="#">HPS-M1-20-420</a>	Linear Wire Potentiometer
<a href="#">HPS-M1-20-420-F</a>	Linear wire encoder
<a href="#">HPSSR10</a>	Encoder
<a href="#">HTR-HB-8-1024A-P</a>	Rotary encoder
<a href="#">HTR-HB-8-600-2-X188</a>	Rotary Encoder
<a href="#">HTR OS 400 2 C</a>	Rotary encoder
<a href="#">HTR-W3-100-2-PP-SA100</a>	SMALL ROTARY ENCODER
<a href="#">HTR-HB-8-10A-P</a>	ROTARY ENCODER
<a href="#">HPG-A-A1EN6M-BHL-S3</a>	PENDANT HAND-HELD
<a href="#">HSK-300-2</a>	ROTARY ENCODER
<a href="#">HTR-M2-400-HV</a>	Rotary Encoder
<a href="#">HTR-M2-100-2-HV</a>	ROTARY ENCODER
<a href="#">HTR-MWK-1-2-PP</a>	rotary encoder
<a href="#">HTR-MWR-1-2-PP</a>	
<a href="#">HTR-M2-100-HV</a>	ROTARY ENCODER
<a href="#">HTR-MWB-10A-P</a>	Meter Wheel Encoder
<a href="#">HTR-G-360A-C</a>	ROTARY ENCODER
<a href="#">HTR-G-360A-C (10 pcs)</a>	ROTARY ENCODER
<a href="#">HTR-W-100-2-C</a>	Rotary Encoder
<a href="#">HTR-W-100A-C</a>	
<a href="#">HTR-5B-1000A-P-SA20</a>	ROTARY ENCODER
<a href="#">HTR – OS – 400 – 2 – C – FC39007</a>	Encoder
<a href="#">HTR-6C-1024-2-PP-SA100</a>	ROTARY ENCODER
<a href="#">MLS-M-10</a>	LINEAR WIRE TRANSDUCER
<a href="#">HTR M2 400 2HV</a>	Encoder
<a href="#">HTR-HB-8-600A-P</a>	ROTARY ENCODER
<a href="#">HTR-OS-500-2-C-SC2</a>	ROTARY ENCODER
<a href="#">HTR-MWB-1A-P</a>	Rotary Encoder
<a href="#">HLS L1 30 008 X242 1</a>	ENCODER HONTKO CUSTOM MADE
<a href="#">HTR-W-10A-C</a>	ROTARY ENCODER
<a href="#">HTR-5B-500A-P-SA20</a>	ROTARY ENCODER
<a href="#">HTR-5B-100A-P-SA20</a>	
<a href="#">HTR-6C-1024-2-HL-SA100</a>	Rotary encoder

Product	Description
<a href="#">HPS M1 10 RF</a>	WIRE POTENTIOMETER
<a href="#">HTR-W-2000A-P</a>	ROTARY ENCODER
<a href="#">HTR-W-800A-V-SA20</a>	ROTARY ENCODER
<a href="#">HTR-6C-1000-2</a>	
<a href="#">HTR-HB-8-12-X235-2</a>	
<a href="#">HTR-6C-360A-V</a>	
<a href="#">HPS-M1-05-420-F</a>	
<a href="#">HPG-N2-100-V</a>	encoder
<a href="#">HPG-N2-100-V5</a>	
<a href="#">HTR OS 60 2 C</a>	ROTARY ENCODER
<a href="#">HTR-W3-100A-P-SA100</a>	ROTARY ENCODER
<a href="#">HTR-W-400A-P</a>	ROTARY ENCODER
<a href="#">HTR-MWB-1A-V</a>	ROTARY ENCODER
<a href="#">EE 6C003 A01</a>	Cable
<a href="#">HPG-A-B3EP6M-AV-S5</a>	PENDANT HAND-HELD
<a href="#">HTR W 10A P</a>	
<a href="#">HSK-50-2</a>	ROTARY ENCODER
<a href="#">HTR-W-360A-P</a>	Rotary Encoder
<a href="#">old code HSK-100-2-C-SA20, new code HSK-100A-C-SA20</a>	Encoder
<a href="#">HTR-3A-1000A-V-SA100</a>	encoder
<a href="#">HTR-W-1000A-P-SA100</a>	Rotary encoder
<a href="#">HTR-MWB-01A-H</a>	METER WHEEL ENCODER
<a href="#">HTR-W3-900A-H</a>	ROTARY ENCODER
<a href="#">HPG N4 25 L</a>	MANUAL PULSE GENERATOR
<a href="#">HTR-W-200A-P-SA100</a>	Rotary encoder
<a href="#">HTR-HB-8 1024A-H</a>	ROTARY ENCODER
<a href="#">HTR W 360A C</a>	ROTARY ENCODER
<a href="#">HPS-M1-15-R-F</a>	Linear Wire Potentiometer
<a href="#">HTR-MWB-10A-V</a>	METER WHEEL ENCODER
<a href="#">HTR W 500A P</a>	ENCODER
<a href="#">HPG-N4-100-L</a>	HAND WHEEL ENCODER
<a href="#">HLS-S-10-01A-H</a>	Wire encoder
<a href="#">HTR-W2-500A-H</a>	ROTARY ENCODER
<a href="#">HTR-HB-10-1000A-P</a>	ROTARY ENCODER
<a href="#">HSK-100A-V</a>	Rotary Encoder
<a href="#">HTR-MWB-01A-V</a>	ROTARY ENCODER
<a href="#">HTR-6C-1024A-P-SA100</a>	Rotary Encoder
<a href="#">HTR-OS-100-2-C</a>	ROTARY ENCODER
<a href="#">HSK-100A-C</a>	ENCODER
<a href="#">HTR-W3-360A-P-SA100</a>	
<a href="#">HTR-W2-1000A-P</a>	Rotary Encoder
<a href="#">HTR-MWB-05A-P</a>	ROTARY ENCODER
<a href="#">HTR-W2-500-3-PP</a>	ROTARY ENCODER
<a href="#">A2-G-256</a>	ABSOLUTE ENCODER
<a href="#">HTR-HB-8-360A-H</a>	ROTARY ENCODER

<b>Product</b>	<b>Description</b>
<a href="#">HTR-G-40A-P</a>	Rotary Encoder
<a href="#">HTR-W-360-X186</a>	Rotary Encoder
<a href="#">HTR-HB-8-250A-C</a>	Rotary encoder
<a href="#">HLS-S-10-04A-P</a>	Linear wire encoder
<a href="#">HTR-W2-500A-P</a>	rotary encoder
<a href="#">HLS-M-20-01A-C</a>	LINEAR WIRE ENCODER
<a href="#">HTR-OS-100-2-C</a>	ROTARY ENCODER
<a href="#">HTR-HG-40-1024A-P</a>	ROTARY ENCODER
<a href="#">HTR -3A-360A-P</a>	Rotary encoder
<a href="#">HSK-100A-C-SA20</a>	Rotary Encoder
<a href="#">HTR-HB-8-60A-P-SA30</a>	Rotary switch
<a href="#">HPG-A-B3FP6R-AL-S3</a>	Pendant Hand-Held
<a href="#">CB-A0002-001</a>	Push button
<a href="#">HLS-L-X089</a>	LINEAR WIRE ENCODER
<a href="#">HPS-M1-15-R-F25</a>	LINEAR WIRE POTENTIOMETER
<a href="#">HTR-5B-1000A-P</a>	Rotary Encoder
<a href="#">HPS-M1-10-420</a>	linear encoder
<a href="#">HTR-OS-60-2-C-FC39007</a>	
<a href="#">HTR-MWK-1A-P</a>	Rotary Encoder
<a href="#">HTR-3A-1024A-H</a>	Rotary Encoder
<a href="#">HTR-M2-60-2-HV.</a>	ROTARY ENCODER
<a href="#">HPS-S-05-R-F25</a>	LINEAR WIRE POTENTIOMETER
<a href="#">HPG-A-B3CP6M-AL-S3</a>	Hand Held Pendant
<a href="#">HTR OS 100 2 C</a>	HONTKO ENCODER
<a href="#">HTR MWB 01A P</a>	
<a href="#">HTR-W-XA122</a>	ENCODER
<a href="#">HLS-L-100-1A-C</a>	LINEAR WIRE ENCODER
<a href="#">pn HLS-L-100-1-C</a>	LINEAR WIRE ENCODER HONTKO
<a href="#">HLS-S-10-01A-H-SA20</a>	LINEAR WIRE ENCODER
<a href="#">HTR 6C 1000A P</a>	
<a href="#">HLS-M-40-01A-V</a>	
<a href="#">HLS-S-10-01A-P</a>	Linear Wire Encoder
<a href="#">HPS-M1-125-10V</a>	LINEAR WIRE POTENTIOMETER
<a href="#">HTR-W2-1024A-P</a>	ROTARY ENCODER
<a href="#">HPS-S-10-R</a>	Linear wire potentiometer
<a href="#">HTR 3A 200A P</a>	ENCODER