



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

# Hydrocar

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

## BRAND'S PRODUCTS

Product	Description
<a href="#">400C4204000</a>	Pneumatisches Geberventil CP4000-2
<a href="#">400C420400M</a>	Pneumatisches Geberventil CP4000-2 Totmannschaltung
<a href="#">400PM100001</a>	COM.PNEUM. PM MONOST. T6
<a href="#">400PM100003. PM1</a>	pneumatic transmitter valve
<a href="#">P82V6P10201</a>	auxiliary drive
<a href="#">199K8020000</a>	Montagesatz
<a href="#">P82M3P10204</a>	hydraulic motor
<a href="#">201FX047DSE</a>	axial piston pump
<a href="#">201FX016DSE</a>	piston pump
<a href="#">DM70P028200</a>	
<a href="#">194KES5E212 ( 194EC015212)</a>	Controller
<a href="#">201FX016D7E</a>	Pump
<a href="#">201PE060Z00</a>	straight axial piston pump
<a href="#">201PE0140SE</a>	Straight piston pump
<a href="#">194KE043000</a>	Controller
<a href="#">SBSA047DG00</a>	
<a href="#">P82M5P10294</a>	auxiliary drive
<a href="#">199K0300000</a>	Assembly kit for auxiliary drive
<a href="#">D15EPP00500</a>	Tilt valve
<a href="#">200FZ0015D0</a>	
<a href="#">200BLH0900S</a>	gear pump
<a href="#">200FZ0043DS</a>	gear pump
<a href="#">P90SBP15811</a>	
<a href="#">P/N: 199K9430000</a>	Montagekit
<a href="#">201FX084DSE</a>	pump
<a href="#">3VDMR000000</a>	Hydraulic control valve
<a href="#">FOX 64 (With Suction Connection)</a>	Pump
<a href="#">201FX034DSE</a>	Piston Pump
<a href="#">200BPC016S4</a>	Hydraulic pump
<a href="#">194KES13000</a>	servo motor
<a href="#">P18G3P13201</a>	Side auxiliary drive
<a href="#">200FZH075DS</a>	gear pump
<a href="#">200FZH075DV</a>	tandem gear pump
<a href="#">197KFL12000</a>	Flange
<a href="#">P82M5P10201</a>	Nebenantrieb für die 3- Loch Variante
<a href="#">198KPP03000</a>	clutch kit

<b>Product</b>	<b>Description</b>
<a href="#">P018G2EA400201</a>	auxiliary drive
<a href="#">P81Z1P15204</a>	for drop box
<a href="#">PC 65 S (mounted on 3 screws)</a>	pump
<a href="#">PC 65 S (mounted on 4 screws)</a>	pump
<a href="#">200FZ0057DS</a>	Pump
<a href="#">1120081000</a>	
<a href="#">12920088000</a>	
<a href="#">12401110000</a>	cover
<a href="#">200BPS016S4</a>	pump
<a href="#">U001A26E1-AI</a>	PULSATION DAMPER - AD2000
<a href="#">P2189P10201</a>	
<a href="#">P90MBP15830</a>	
<a href="#">09900119800</a>	Seal kit for tilting valve
<a href="#">199K8150000</a>	mounting kit
<a href="#">D160PP2B5C0</a>	Hydraulic valve
<a href="#">201PE070ZSE</a>	Pressure Pump
<a href="#">201PE080ZSE</a>	Pressure Pump
<a href="#">201PE090ZSE</a>	pressure Pump
<a href="#">194KE028000</a>	Power converter
<a href="#">19900999000</a>	electrical installation kit
<a href="#">P82Z1P10201</a>	PTO
<a href="#">194KES14000</a>	servomotor
<a href="#">D180PP2B4X2</a>	Valve
<a href="#">1950090P000</a>	Seal kit
<a href="#">0200BPC011S0</a>	Pump
<a href="#">3600ST09125G</a>	
<a href="#">Type 201PE0250SE</a>	Pump
<a href="#">201FX025DSE</a>	axial piston pump
<a href="#">200FZ0022D0</a>	Pump
<a href="#">Gasket set for D160</a>	Gasket set for valve
<a href="#">200FZ0043S0</a>	Gear pump
<a href="#">200FZ0065DV</a>	tandem gear pump
<a href="#">606X03C0600</a>	
<a href="#">P82Z1P15294</a>	Power take-off
<a href="#">199K8100000</a>	Assembly kit
<a href="#">194KES5E212</a>	controller
<a href="#">Repair kit for 195ECO15212</a>	
<a href="#">P23Z5E93201</a>	23Z5 electric auxiliary drive
<a href="#">P2266NQH94B</a>	Eaton 2266 auxiliary drive + accessories
<a href="#">DM40P018100</a>	cylinder
<a href="#">195RGFOX</a>	Gasket set
<a href="#">200FZ0065D0</a>	gear pump
<a href="#">199K9450000</a>	
<a href="#">6036SP07500</a>	
<a href="#">133KE008000</a>	

Product	Description
<a href="#">194KSP28000</a>	Control switch
<a href="#">194KE063000</a>	
<a href="#">194KE069000</a>	
<a href="#">194KEKES5B0</a>	Cable set for electric auxiliary drive
<a href="#">1951600PSEO</a>	Seal set
<a href="#">V160PL16400</a>	
<a href="#">PF0252P1000811</a>	pneumatic multi-plate clutch
<a href="#">201PE060ZSE</a>	Straight axial piston pump
<a href="#">PTO P93Z3O10811</a>	
<a href="#">P1705P15394</a>	Power take-off
<a href="#">199K2130000</a>	Mounting kit
<a href="#">201FX084SSE</a>	axial piston pump
<a href="#">606X01K0000000</a>	adapter for standard pumps
<a href="#">P2264P1E294</a>	
<a href="#">199K2690000</a>	Mounting kit
<a href="#">3VDMR000N00</a>	diverter valve
<a href="#">200FZ0043D0</a>	gear pump
<a href="#">P82Z2P10294</a>	
<a href="#">P82Z1P10294</a>	
<a href="#">P082Z1PF000204</a>	
<a href="#">P1802P20294</a>	PTO (presa di forza) model reference
<a href="#">P09J4P15201</a>	Power take-off
<a href="#">500361616</a>	complete PTO
<a href="#">P020Z2E14A1201</a>	20Z2 Electric Auxiliary Drive
<a href="#">P19N2M34201</a>	
<a href="#">P81Z2P10204</a>	
<a href="#">195ECO15212</a>	servomotor
<a href="#">11103537000 HVR100/2</a>	cogwheel
<a href="#">11103554000 HVR100/3</a>	cogwheel
<a href="#">606X03F0800</a>	Adapter
<a href="#">P2266P1C294</a>	
<a href="#">201PE050ZSE</a>	Straight axial piston pump
<a href="#">199K2970000</a>	Mounting kit
<a href="#">195KLB20000</a>	lubrication kit
<a href="#">P2905P15890</a>	Pto
<a href="#">198KPP02000</a>	clutch kit
<a href="#">200BPC022S4</a>	Hydraulic pump
<a href="#">09900528000 (EDH 4320)</a>	solenoid valve
<a href="#">09900513000</a>	Coil
<a href="#">8867368</a>	
<a href="#">201FX108DSE</a>	pump
<a href="#">200FZ0036D0</a>	pump
<a href="#">200BPC011D8</a>	pump
<a href="#">200FZ0090SV</a>	HYDRAULIC PUMP
<a href="#">194KSP17000</a>	control switch

Product	Description
<a href="#">200FZ0022DO</a>	gear pump
<a href="#">P17A2I12294</a>	.
<a href="#">P22Z3E93201</a>	power
<a href="#">200FZ0015SS</a>	Pump
<a href="#">198KPP04000</a>	Clutch kit
<a href="#">200FZ0015S0</a>	Gear pump
<a href="#">200FZH116DV</a>	Gearpump
<a href="#">P30KZP10503</a>	
<a href="#">405TXZ00040</a>	SINGLE-LEVER MECHANICAL CONTROL
<a href="#">3VFCFR02000</a>	valve
<a href="#">P17AAI12744</a>	power taker
<a href="#">501PRS163A1</a>	pressure switch
<a href="#">501PRS357A1</a>	pressure switch
<a href="#">P2900R890B</a>	
<a href="#">201PE050Z00</a>	pump
<a href="#">P86Z1P10294</a>	power take-off
<a href="#">201PE040ZSE</a>	pump
<a href="#">D51F4F11010</a>	electric tilt valve
<a href="#">P/N: 00801025000</a>	shaft seal
<a href="#">P/N: 00802003000, Type: OR-119</a>	O-ring
<a href="#">P/N: 00802056000, Type: OR-3187</a>	O-ring
<a href="#">802064</a>	O-ring
<a href="#">P/N: 00802191000, Type: OR-2125</a>	O-ring
<a href="#">D140PP17500</a>	Tilt valves
<a href="#">3VDMR100N00</a>	valve
<a href="#">P1802P15294</a>	power take-off
<a href="#">P81Z1P10204</a>	Power take-off
<a href="#">P1604P10294</a>	
<a href="#">199K1950000</a>	
<a href="#">6036SP19800</a>	spacer
<a href="#">19900622000</a>	
<a href="#">200FZ0036S0</a>	gear pump
<a href="#">201FX064SSE</a>	axial piston pump
<a href="#">P1602P15294</a>	Repair kit
<a href="#">P890000760</a>	
<a href="#">P18G2H15201</a>	
<a href="#">201PE0190SE</a>	
<a href="#">09900568000</a>	bipolar switch
<a href="#">09900882000</a>	cover cap
<a href="#">09900337000</a>	Warning light 12V orange
<a href="#">09900336000</a>	12V red warning light
<a href="#">9900887000</a>	KES5/13 connection cable
<a href="#">09900895000</a>	KES5/13 PTO connection cable
<a href="#">P18G2P11201</a>	power take-off
<a href="#">194KCI17000</a>	Switch

Product	Description
<a href="#">19500902000</a>	gasket kit
<a href="#">200FZ0022S0</a>	gear pump
<a href="#">405TXZ00035</a>	
<a href="#">01001705P394</a>	pump
<a href="#">03DS1F052000</a>	hydraulic pump
<a href="#">201FX034D7E</a>	axial piston pump
<a href="#">200FZ0065SS</a>	gear pump
<a href="#">KE043/02</a>	control unit
<a href="#">1342KE04300</a>	
<a href="#">201PE019000</a>	piston pump
<a href="#">200BPS01600</a>	gear pump
<a href="#">P19N2M36201</a>	auxiliary drive
<a href="#">200FZ0057SS</a>	gear pump
<a href="#">P23N3E73201</a>	
<a href="#">Type: P19N2M34201 Serial: 0131077</a>	Nissan UNI Mechanical Auxiliary Drive
<a href="#">201PE014000</a>	piston pump
<a href="#">200BPH1050S</a>	hydraulic pump
<a href="#">P88Z1P25294</a>	auxiliary drive
<a href="#">KE-KES05B</a>	Wire for Actuator
<a href="#">P1705P21394</a>	
<a href="#">194EC015212</a>	electric actuator switch
<a href="#">200BPS01100</a>	gear pump
<a href="#">200BPS02200</a>	
<a href="#">802DB01KF46</a>	hydraulic pump
<a href="#">200BPC011S4</a>	Left Gear Pump
<a href="#">P22Z3E73201</a>	solenoid valve
<a href="#">194ECO15212</a>	
<a href="#">200FZH116DT</a>	Tandem gear pump
<a href="#">P23Z2E93201</a>	auxiliary drive
<a href="#">200FZ0022DT</a>	Tandem gear pump
<a href="#">200FZH085D0</a>	
<a href="#">Type P20Z1E201 / Code 5010245565B</a>	power take-off
<a href="#">405TXZ00020</a>	Bauden train
<a href="#">201PE0300SE</a>	straight axial piston pump
<a href="#">201FX03407E</a>	
<a href="#">201PE040200</a>	
<a href="#">200BPS0110X</a>	Pump
<a href="#">PAI 80 D SE</a>	
<a href="#">Sealing ring 00801098000</a>	
<a href="#">OR-3375 00802105000</a>	
<a href="#">200FZ0110D0</a>	Gear pump
<a href="#">8870969</a>	power take off
<a href="#">3VDMR040000-pump</a>	hydraulic pump
<a href="#">P1602P14294</a>	
<a href="#">200FZ0065DS</a>	

Product	Description
<a href="#">201FX047SSE</a>	axial piston pump
<a href="#">Seal kit for 201PE040ZSE</a>	Seal kit for 201PE040ZSE pump
<a href="#">P17A1111294</a>	power-take-off pump
<a href="#">D162PT2B5CG</a>	
<a href="#">099005690R0</a>	CO 2120 GDP switch
<a href="#">200BPS03200</a>	gear pump
<a href="#">sight glass on hydraulic tank for D162PT2B5CG</a>	sight glass on hydraulic tank for D162PT2B5CG
<a href="#">200FZH085SS</a>	Pump
<a href="#">20FZ0090DS0000</a>	
<a href="#">200BPH0900S</a>	
<a href="#">Seal Kit for Model: 2011E0530AM SN# 99015</a>	
<a href="#">201PE025000</a>	HYDRAULIC PUMP
<a href="#">22PEV025000000</a>	Straight axial piston pump
<a href="#">D162PT2B2CG</a>	
<a href="#">20BPH1050S0000</a>	
<a href="#">200FZ0090S0</a>	gear pump
<a href="#">200DAB210S0</a>	Hydraulic Pump
<a href="#">01102016000000</a>	spare part 36
<a href="#">09902857000000</a>	spare part 14
<a href="#">P082Z1PF000294</a>	auxiliary drive
<a href="#">P82V6P10294</a>	
<a href="#">P23Z4E93201</a>	
<a href="#">24FXG047DS0010A</a>	
<a href="#">21901500000</a>	gasket kit
<a href="#">old code P18G2H15201/new code P018G2HA400201</a>	
<a href="#">802057</a>	
<a href="#">802103</a>	
<a href="#">194KE086000000</a>	Electromagnetic CMD control unit
<a href="#">200FZH085DV</a>	
<a href="#">P02905PB400813</a>	
<a href="#">400C22S10A0</a>	Pneumatic Control
<a href="#">P17A2111294</a>	
<a href="#">199K2970000000</a>	
<a href="#">P086Z6PF000294</a>	86Z6 auxiliary drive for ZF
<a href="#">199K7820000000</a>	
<a href="#">195KLB35000000</a>	KLB35 lubrication kit
<a href="#">601K6410000000</a>	K641 shaft set for Iveco
<a href="#">20FZ0065DS000T</a>	
<a href="#">IPH 12V 00099181000</a>	12 volt servomotor
<a href="#">20FZH130D00000</a>	
<a href="#">194KID01000000</a>	Negative pressure operation
<a href="#">P017A7IB000294</a>	
<a href="#">199K3220000000</a>	
<a href="#">PF252P10811+ MALE SLEEVE FOR PF252P10811</a>	
<a href="#">20FZL110SS0000</a>	

Product	Description
<a href="#">199K810000000</a>	Gearbox mounting kit
<a href="#">20BPC011S33000</a>	gear pump
<a href="#">22PEV0190S0000</a>	Straight axial piston pump
<a href="#">20FZ0065DS0000</a>	
<a href="#">20FZH116SS000T</a>	
<a href="#">P18G2E74201</a>	hydraulic pump
<a href="#">00099128000</a>	actuator
<a href="#">201FX064D7E</a>	Multi-piston pump
<a href="#">12901602000000</a>	
<a href="#">12901158000000</a>	
<a href="#">195ECO15212000</a>	servo motor
<a href="#">P081Z1PF000204</a>	
<a href="#">23PE51510S000W</a>	
<a href="#">606X03F0500</a>	
<a href="#">194KEKES5B0000K</a>	
<a href="#">20BPS022</a>	
<a href="#">200BPS02800</a>	
<a href="#">P009J5HA000201</a>	
<a href="#">200FZH116DS</a>	Pump
<a href="#">400C2101000</a>	
<a href="#">PAM9918100- 194EC015212</a>	
<a href="#">20BPS011010000</a>	gear pump
<a href="#">24FXG064SS0010</a>	pump
<a href="#">P017A5IA000294</a>	
<a href="#">199K0060000000</a>	Assembly kit
<a href="#">22PEV0900S0000</a>	
<a href="#">FCFR00200A80N3</a>	
<a href="#">200bBPS022 S0</a>	
<a href="#">194EC015212 REINFORCED</a>	
<a href="#">VDMR 3/4</a>	diverter valve
<a href="#">20FZ0027S00000</a>	
<a href="#">20FZ0027SS0000</a>	
<a href="#">0210PEH050UNI</a>	
<a href="#">P023Z2ED400201</a>	
<a href="#">PAM1X0110SP B002</a>	Pump
<a href="#">Cable for P20Z1M33201</a>	
<a href="#">200FZH075D0</a>	hydraulic pump
<a href="#">20FZH075D00000</a>	FZH 075/Right 3 hole UNI
<a href="#">P017A2IA000294</a>	
<a href="#">PKES30RVI</a>	
<a href="#">22PEH060000000</a>	Straight axial piston pump 60 ltr.
<a href="#">1026</a>	
<a href="#">K199</a>	
<a href="#">12201050000000</a>	FORK
<a href="#">P82V1P10204</a>	

Product	Description
<a href="#">P023Z2PC0A5201</a>	
<a href="#">11301589000000</a>	
<a href="#">P082V1PF000204</a>	
<a href="#">20FZ0090S00000</a>	
<a href="#">20FZ0065S00000</a>	
<a href="#">194KE043000000</a>	
<a href="#">20FZ0036SS</a>	
<a href="#">PAM1110002</a>	pump
<a href="#">194KES13000000</a>	
<a href="#">P083Z1PB000877</a>	auxiliary drive
<a href="#">20FZ0015D00000</a>	pump
<a href="#">P18G3E73201</a>	actuator
<a href="#">A50CHWDP420</a>	actuator
<a href="#">D180PP2B4XS</a>	Adjustable tilt valve
<a href="#">201PH040ZSE</a>	
<a href="#">P20Z1M33201</a>	Auxiliary drive 20Z2 Z.F. S5-200
<a href="#">PE14 3 Loch UNI</a>	piston pump
<a href="#">200FZH085DS</a>	
<a href="#">22PEH0400S0000</a>	Erade axial piston pump
<a href="#">20FSL057SS0000</a>	gear pump
<a href="#">P009J5EA400201</a>	09J5 auxiliary drive
<a href="#">00801237000000</a>	Shaft sealing ring
<a href="#">P02000PA000201</a>	
<a href="#">2264/38</a>	cogwheel
<a href="#">20BLH1250S0000</a>	
<a href="#">22PEV0300S0000</a>	
<a href="#">P022Z4EA40020122Z4</a>	
<a href="#">P022Z4EA400201</a>	
<a href="#">P081Z1PF100204</a>	Auxiliary drive Z.F. 6.80 - 16S221 pneumatic + Merit switch
<a href="#">P90ZBP1510</a>	
<a href="#">19900803000000</a>	Control panel
<a href="#">20FZ090SS00000</a>	
<a href="#">P090ZBPF200810</a>	Power take-off
<a href="#">P019N2ND600201</a>	
<a href="#">P02264PB1AL294</a>	
<a href="#">197KFL76000000</a>	Flange
<a href="#">P19N2M33201</a>	
<a href="#">P018G2PC0A5201</a>	
<a href="#">24FXG084DS0010A</a>	
<a href="#">20DAB010S40020</a>	
<a href="#">200FZL090SS</a>	
<a href="#">5802502283</a>	
<a href="#">20BPC022S33000</a>	gear pump
<a href="#">500397606</a>	
<a href="#">VVDMR0000AH2D0</a>	diverter valve

Product	Description
<a href="#">201PE040Z00</a>	pump
<a href="#">P023N3EA400201</a>	
<a href="#">P82M1P10201</a>	hydraulic pump
<a href="#">200B00110S0</a>	gear pump
<a href="#">20FZ0110DS0000</a>	gear pump
<a href="#">606X80A0000000</a>	ADAPTER
<a href="#">200FZH150DS</a>	Pump
<a href="#">20FZ0015S0000</a>	
<a href="#">P088Z7PF100294</a>	
<a href="#">P018G2PC400201</a>	auxiliary drive
<a href="#">199K3700000000</a>	Assembly kit
<a href="#">tank for D162PT3B5CG</a>	tank
<a href="#">PAM120198</a>	
<a href="#">PEH50 3-Loch UNI//22PEH050000000</a>	piston pump
<a href="#">pump 22H91 for ref: PB6M1P15W1C</a>	hydraulic pump
<a href="#">11305521000000 (1800/11)</a>	Wave
<a href="#">3VFCR1T1200</a>	