



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)



## MarzochiBiRa

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### AhND'S cPhO'UMC

PTaduRo	'itRTesoeap
<a href="#">1P-DAP-92GM10L3</a>	4nterface Felay R4F1O
<a href="#">1P-DAP-2GN10L3</a>	4nterface Felay
<a href="#">1P-DAP-2GA10T-3 F</a>	4nterface Felay R4F1O
<a href="#">1PPA</a>	Uockel
<a href="#">10DA0-GN10L3</a>	Utandard 4ndustrial Felay
<a href="#">10DA0-N2GN1P0-DP083</a>	1ontrol Felay
<a href="#">1TDAT-72GN10L3</a>	industrial relays
<a href="#">1TDAT-GA10T-3F</a>	4ndustrial Felay R6F1O
<a href="#">1TDAT-GA10L3 5-/B</a>	4ndustrial Felay R6F1O
<a href="#">1TDAT-72G-0L3N1</a>	Slug 4n Sower Felay
<a href="#">1TAT-2PP83A1</a>	Felay
<a href="#">1TD6P-N2GN1PP-3</a>	1ontrol Felay
<a href="#">1TDF0-KGA10T-3 Rone pieceO</a>	Femanence relay
<a href="#">1LDAL-N2GN10L3</a>	Sower relay
<a href="#">18DAT-GN1P0-DP083</a>	Utandard 4ndustrial Felay
<a href="#">18DAT-N2GN100-3 F</a>	4ndustrial Felay R6F1O
<a href="#">18DAT-2GN100-3</a>	Utandard 4ndustrial Felay
<a href="#">1IDA0-GN10L3</a>	6iniature 4ndustrial Felay RHF1O
<a href="#">1IDA0-GA10L-3 5-/B</a>	6iniature 4ndustrial Felay RHF1O
<a href="#">1IDA0-N2GN10L3</a>	Felay
<a href="#">1IDA0-N2GN10L3 F</a>	6iniature 4ndustrial Felay RHF1O
<a href="#">1IDA0-2GA1PP83 F</a>	6iniature 4ndustrial Felay RHF1O
<a href="#">1IDA0-2GN1P03</a>	6iniature 4ndustrial Felay RHF1O
<a href="#">1(DALPGN10L3</a>	6iniature 4ndustrial Felay RHF1O
<a href="#">1(DALP72GN10L3</a>	4ndustrial Felay
<a href="#">1S7PPGN10L3</a>	Uolide Utate Felay
<a href="#">1UDPP</a>	Uockets
<a href="#">1U0GM1P0D0L-3</a>	6M)#47MK1#4ZK #46E NE)A+ FE)A+
<a href="#">1#TDET-G/ M1(-D0583</a>	#imer
<a href="#">1P-DAP892GM10L3F</a>	4K#EF7A1E FE)A+
<a href="#">FU P0PGA#2 A100-D0L-3</a>	#46E NE)A+ FE)A+ 6M)#41Z6A#
<a href="#">UP-D6</a>	Feleco socket for 1P- relays Rbase P contactO
<a href="#">U0D9</a>	1ontrol Felay
<a href="#">UTDU</a>	relay socket
<a href="#">ULDC RSackO</a>	Uocket
<a href="#">UID1</a>	Uocket

















Product	Description
<a href="#">ALPA2-D-30</a>	pump
<a href="#">ALP2-D-12</a>	GEAR PUMP
<a href="#">K0.5-S-1.00-G</a>	pump
<a href="#">GHPP1-D-5-FA</a>	
<a href="#">K1P-D-4.2-G</a>	HYDRAULIC PUMP
<a href="#">ALP2-D-9-FG</a>	GEAR PUMP
<a href="#">ALP2-D-10-T3</a>	GEAR PUMP
<a href="#">ALP3A-D-94-S1</a>	GEAR PUMP
<a href="#">GHPA3A-D-60-S1-FG</a>	GEAR PUMP
<a href="#">GHP2A-D-25-C2</a>	GEAR PUMP
<a href="#">GHP2-D-34-FG</a>	Pump
<a href="#">1BK7-9,2D</a>	
<a href="#">0.25-D-36</a>	
<a href="#">ALM2-R-16-E1</a>	HYD. FAN MOTOR
<a href="#">GHP1A-D-4</a>	pump
<a href="#">650150/R</a>	
<a href="#">ALP3-D-135</a>	
<a href="#">GHP3-D-135</a>	
<a href="#">GHPA3-D-60</a>	
<a href="#">GHPP2D-25</a>	
<a href="#">KIT 3+2 ALP</a>	
<a href="#">KIT 2+2 ALP</a>	
<a href="#">U0.25-R-36</a>	
<a href="#">U0.25-R-24-VN-KX</a>	pump
<a href="#">ALP3A-D-66-FA</a>	
<a href="#">ALP3-D-110</a>	PUMP
<a href="#">GHP3-D-110</a>	
<a href="#">GHP2-D-30-T3-FG</a>	Pump
<a href="#">GHPC2A-D-40/6-C2-KA</a>	Pump
<a href="#">ALP1AQ-S-6-G1-P636</a>	
<a href="#">GHP2-D-20-FG</a>	Hydraulic Gear Pump
<a href="#">ALPA4 -D-160</a>	
<a href="#">ALPA1-D-4+ALPI1-4+ALPP1-D-3</a>	pump
<a href="#">GHPA3-D-94</a>	
<a href="#">GHPP2-D-40</a>	
<a href="#">GHPP1-D-2-AS</a>	Gear Pump
<a href="#">ALP3A-S60-S1-E</a>	
<a href="#">A0.5-D-1.30+P0.25-D-24</a>	DOUBLE PUMP
<a href="#">GHP3A-S-60-S1-E</a>	
<a href="#">E20800042 / PDELI2-D-9,6/9,6-T0-D-D-N</a>	Pump
<a href="#">ALP2BK7-S-9</a>	
<a href="#">ALP2-D-34-FG</a>	pump
<a href="#">GHPA3A-D-80-S1-D</a>	Pump
<a href="#">MA00000000</a>	PUMP
<a href="#">ELI4AC-D-127,4-C0-A-N</a>	Pump



Product	Description
<a href="#">ALPA1-D-4-P524A + ALP11-4-P524A + ALPP1-D-3-P524A</a>	TRIPLE PUMP
<a href="#">GHP3-D-50</a>	pump
<a href="#">ALM3A-R-80-S1-E-E3</a>	pump
<a href="#">GHM2A-R-34-E2</a>	
<a href="#">1PHL-D-2.5/10-8/35-30-P606</a>	HIGH-LOW DOUBLE PUMP
<a href="#">ALP3S-50</a>	PUMP
<a href="#">ALPA3D-110+ALPP2D-20</a>	
<a href="#">1P-D-1.6-KA</a>	
<a href="#">GHPA2-D-40+ALPP2-D-10</a>	pump
<a href="#">ALPP1-D-9-FG</a>	PUMP
<a href="#">ALPP2-S-30</a>	REAR PUMP
<a href="#">ALM1-R4-E1</a>	ENGINE
<a href="#">ALPA4-S-190</a>	FRONT pump
<a href="#">GHM3C-R-50-EP-MU-E1</a>	Engine
<a href="#">K1PS1.2G</a>	Gear pump
<a href="#">MA90000124</a>	GEAR PUMP
<a href="#">K1P-D-2.5-AS-P199</a>	pump
<a href="#">K1P-D-6.7-G</a>	GEAR PUMP
<a href="#">ALP/GHP 3+1 (650169)</a>	
<a href="#">ALP-P1D5</a>	
<a href="#">GHP35-D-135</a>	PUMP
<a href="#">G1.3B40X ALP1A-D-4</a>	Bomba
<a href="#">ALP1A-D-4</a>	ALP1A-D-4 GEAR PUMP
<a href="#">GHPP2-D-9-FA-AC12</a>	External gear pump
<a href="#">ALP2-D-13-C0-FG</a>	
<a href="#">MZ.650226/R</a>	
<a href="#">650351/R</a>	sEAL KIT
<a href="#">ALPA1-D-6-FG-TR</a>	FRONT PUMP
<a href="#">K1PS9.2G</a>	GEAR PUMP
<a href="#">ALP2A-D-34</a>	GEAR PUMP
<a href="#">ELI-1PD4.3-T0-D-N</a>	ELIKA GEAR PUMP
<a href="#">1BK7-S-6.7</a>	PUMP
<a href="#">ALM3-D-50</a>	MOTOR
<a href="#">GHPA3-D-66-V</a>	Double pump
<a href="#">GHPP2-D-16-EP-V</a>	double pump
<a href="#">FT1006-363</a>	ASSEMBLY KIT
<a href="#">K1P D 15 G P199</a>	GEAR PUMP
<a href="#">UK0.25-D-60-G</a>	GEAR PUMP
<a href="#">ALM2A-R-25</a>	
<a href="#">K1P R 1.6XG</a>	GEAR PUMP
<a href="#">P1.33210</a>	
<a href="#">P1.62080</a>	
<a href="#">P1.41220</a>	
<a href="#">MA90000024</a>	
<a href="#">ALPA1D-5+ALPP1D-5</a>	DOUBLE PUMP



Product	Description
<a href="#">ALP-2S30</a>	
<a href="#">GHPA3-D-80 + GHPP3-D-80</a>	DOUBLE PUMP
<a href="#">ALP3A-D-60-S1-E</a>	GEAR PUMP
<a href="#">ALPA3-D-66+ALPI1-9+ALPP1-D-3</a>	
<a href="#">GHPA3-D-66+GHPI1-9+GHPP1-D-3</a>	TRIPLE PUMP
<a href="#">LTH-ND108C</a>	
<a href="#">LTH-R103</a>	
<a href="#">LTH-ND108P2</a>	
<a href="#">MA00000000 - 1P S 11.5</a>	PUMP
<a href="#">ALPA3-D-135</a>	FRONT PUMP
<a href="#">GASKET KIT FOR 1PD-2</a>	
<a href="#">ALPP1-D-3</a>	REAR PUMP
<a href="#">ALPP1-D-13</a>	REAR PUMP
<a href="#">GHP2BK7-D-16-FG-KA</a>	Pump
<a href="#">ALM2-D-22</a>	GEAR MOTOR
<a href="#">ALP3-D-80-FG</a>	GEAR PUMP
<a href="#">ALM2-R-40-E1</a>	GEAR MOTOR
<a href="#">ALPP2-D-40</a>	pump
<a href="#">GHPA3AD-40-AC12+GHPP2D-9-FA-AC12</a>	DOUBLE PUMP
<a href="#">ALPP3-D-80-FG</a>	REAR PUMP
<a href="#">GHPP2-D-10</a>	REAR PUMP
<a href="#">GHPA2-D-10</a>	FRONT PUMP
<a href="#">P1.367821</a>	Front section
<a href="#">P1.42565</a>	End section
<a href="#">P1.62121</a>	Assembly kit
<a href="#">ALPA2D-10</a>	FRONT PUMP
<a href="#">KL1PS 2,5G GAS</a>	GEAR PUMP
<a href="#">A0.25D36+I0.25D/S36+I0.25D/S36+P0.25D36</a>	
<a href="#">A0.25D18+I0.25D/S18+P0.25D18</a>	
<a href="#">ELI2-D-11,4-T0-D-N</a>	
<a href="#">ALPA2-D-40+ALPI1-9+GHPP1-D-6</a>	
<a href="#">GHP1A-R-6-FG-E1</a>	
<a href="#">GHP1A-D-3-FG</a>	
<a href="#">GHP1A-D-4-FG</a>	
<a href="#">GHP1A-D-5-FG</a>	
<a href="#">GHP1A-D-6-FG</a>	
<a href="#">GHP1A-D-7-FG</a>	
<a href="#">GHP1A-D-9-FG</a>	
<a href="#">GHP1A-D-11-FG</a>	
<a href="#">GHP1A-D-13-FG</a>	
<a href="#">GHPP3-S-110</a>	
<a href="#">ALPA4-D-130</a>	
<a href="#">Tandem pump ALP-A4D130 + GHP-P3S110</a>	
<a href="#">ALPA2-D-13-FG + ALPP1-D-7-FG</a>	
<a href="#">K1P-D-5-G</a>	GEAR PUMP



Product	Description
<a href="#">ELI2BK7-S-8,2-G0-D-N</a>	PUMP
<a href="#">ALPA2D-13+ALPP1D-7</a>	DOUBLE PUMP
<a href="#">ALP2BK7-D-40</a>	GEAR PUMP
<a href="#">ALPA2-D-25</a>	FRONT PUMP
<a href="#">2+1 ASSEMBLY KIT (650167)</a>	ASSEMBLY KIT
<a href="#">GHPA3-D-80</a>	
<a href="#">ALPA2A-D-30-FC</a>	GEAR PUMP
<a href="#">1PD1.6</a>	
<a href="#">ELI2A-D-28-C2-D-N</a>	GEAR PUMP
<a href="#">ALP3-D-66 MU</a>	pump
<a href="#">GHPA1-D-7</a>	
<a href="#">GHPP1-D-7</a>	
<a href="#">ALP1A-D-4-FC</a>	GEAR PUMP
<a href="#">NBR ALP/GHP 3 D/S</a>	SEAL KIT
<a href="#">K1P-S-5.8-C</a>	
<a href="#">ALPA1-D-7+ALPP1-D-7</a>	
<a href="#">GHPA1-D-7 + GHPP1-D-7</a>	
<a href="#">GHPA1-D-9+GHPP1-D-3</a>	ASSEMBLED DOUBLE PUMP
<a href="#">ALP1A-D-4-FG-OR (P716)</a>	
<a href="#">0.25-S-30-V</a>	Gear pump
<a href="#">ALPA3-D-33</a>	FRONT PUMP
<a href="#">GEAR PUMP 0.25-S-30-V</a>	
<a href="#">ALP/GHP3 (650231/R)</a>	
<a href="#">MA90000247</a>	
<a href="#">ALP2-D-50-FG</a>	GEAR PUMP
<a href="#">1P-D-2 - 01</a>	
<a href="#">ALP1A-D-6</a>	
<a href="#">K1P-D-1,6-G-1/4X1/4</a>	
<a href="#">601505/R</a>	gasket kit
<a href="#">GHPA3-D-50 + GHPP3-D-50</a>	
<a href="#">GHP3A-D-50</a>	
<a href="#">ALP2-D-25-FG</a>	
<a href="#">ALP3A-D-50</a>	BOMB
<a href="#">ALP3A-D-50-E</a>	
<a href="#">1P-D-2-GAS</a>	GEAR PUMP
<a href="#">1PD2-GAS-VMDI/220</a>	
<a href="#">650169</a>	ASSEMBLY KIT
<a href="#">OM.07520</a>	damping ring
<a href="#">ELI2A-D-11.4-S2-D-N</a>	pump
<a href="#">0.5 S 1.00</a>	GEAR PUMP
<a href="#">WD13804626</a>	STEEL PRESSURE GAUGES
<a href="#">ALM2A-S-50-T3-FG-V/12 / N1101044</a>	motor
<a href="#">GHP-A3D66</a>	Front section
<a href="#">GHP-i1-9</a>	Inner section
<a href="#">ALP/GHP 1+1 (650164)</a>	Mounting kit



Product	Description
<a href="#">ALPA3-D-40</a>	FRONT PUMP
<a href="#">0.5 D 0.50</a>	
<a href="#">MA90000542</a>	gear pump
<a href="#">MA90000873</a>	gear pump
<a href="#">MA90000354</a>	gear pump
<a href="#">ELI-3D78.3-T0-A-N (low noise)</a>	
<a href="#">ELI-3D52.0-T0-A-N (low noise)</a>	
<a href="#">ELI-2D21.0-T0-D-N (low noise)</a>	
<a href="#">GHP2-D-10</a>	Gear pump
<a href="#">GHPP2-D-16</a>	REAR PUMP
<a href="#">GHPA3-D-50+ALPP3-D-40</a>	DOUBLE PUMP
<a href="#">K0.5-S-0.50-G</a>	micro pump
<a href="#">P40FORK455011</a>	
<a href="#">GHP2A-D-10</a>	GEAR PUMP
<a href="#">GHPA3A-D-80-S1 + ALPP2-D-30</a>	DOUBLE PUMP ASSEMBLED
<a href="#">ALPA3-D-60+ALPP2-D-10</a>	DOUBLE PUMP
<a href="#">GHP2BK7-D-16-FG</a>	
<a href="#">GHP2BK7-D-37-FG KA</a>	
<a href="#">GHPA1 D9 + GHPP1 D9</a>	ASSEMBLED DOUBLE PUMP
<a href="#">MA11100201</a>	
<a href="#">GHPA3A-S-50-S1-E + ALPP2-S-10</a>	ASSEMBLED DOUBLE PUMP
<a href="#">GHPA3A-D-80-S1-E + ALPP2-D-30</a>	ASSEMBLED DOUBLE PUMP
<a href="#">GHM2A-R-25-E2</a>	ENGINE
<a href="#">K1P-S-6.7 C</a>	pump
<a href="#">ALPA1D-4+ALPI-4+ALPP1D-3</a>	TRIPLE PUMP
<a href="#">Seal kit GR.1P (2000) 601505/R</a>	Seal kit GR.1P (2000)
<a href="#">IP D 5 GAS</a>	GEAR PUMP
<a href="#">230107</a>	