



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)



# Metasol

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

## BRAND'S PRODUCTS

Product	Description
<a href="#">MC-32A-A240</a>	
<a href="#">MC-185A 100-240VAC/DC 2A2B</a>	Contactator
<a href="#">1362002300</a>	Contactator
<a href="#">P/N: 1386000700, Type: MC-150A</a>	Contactator
<a href="#">P/N: 1375005600, Type: MT-150</a>	thermal relays
<a href="#">UA42A2B</a>	Auxiliary contact block
<a href="#">MC-50a AC110V</a>	Electromagnetic AC Contactor
<a href="#">UA-1 Hulpcontactblok 1NO+1NC MC-9~150a</a>	
<a href="#">ABS403C 250A</a>	
<a href="#">ABH403c 300A</a>	Short- circuit breaking capacity
<a href="#">ABS403C 350A</a>	
<a href="#">ABS403C 400A</a>	
<a href="#">ABH 203c</a>	
<a href="#">ABH 103c</a>	
<a href="#">PB-C3-FRL</a>	
<a href="#">PB-D3 FRL</a>	
<a href="#">MC-85A 110VAC 1A1B</a>	Contactator
<a href="#">MC-100a / 1384013900</a>	Contactator
<a href="#">MT-32</a>	
<a href="#">MT-32 3K 3.3</a>	
<a href="#">MC-85a</a>	Contactator
<a href="#">MC-85A-A240</a>	
<a href="#">ABS203C/125</a>	
<a href="#">ABN 403c 350A</a>	Circuit Breaker
<a href="#">ABS32c 20A EXP /0128002000</a>	special LS breaker
<a href="#">UTV-230</a>	Under Voltage Trip Device
<a href="#">MC-150a/4</a>	Conductor Relay
<a href="#">1347000800</a>	Contactator
<a href="#">MC-32a (1336013100)</a>	Contactator
<a href="#">MC-150A-22-AC120</a>	
<a href="#">ABH203c 200A EXP</a>	Short- circuit breaking capacity
<a href="#">ABH203c 250A</a>	Short- circuit breaking capacity
<a href="#">MC150A-30-22-FV-S-E</a>	
<a href="#">UTS150H FTU 100A 3P LL UL</a>	
<a href="#">MC-150a Code: 1386000100</a>	Contactator
<a href="#">MC-65a - 230Vac / 1381001200</a>	



Product	Description
<a href="#">1346000800</a>	
<a href="#">MC-9B-AC240</a>	
<a href="#">1339012900 / MC65A-30-22-K7-S-E</a>	
<a href="#">Number: 2210552 Type ABS103C</a>	
<a href="#">Number: 2210551 Type ABS103C</a>	
<a href="#">ABH103c 50A</a>	
<a href="#">ABH103c 40A</a>	
<a href="#">MC-50a 3P AC 110V</a>	contactor
<a href="#">ABS403C</a>	
<a href="#">MC-9a/4</a>	Contactor
<a href="#">MC-18a/4</a>	Contactor
<a href="#">ABS32C (30AF / 3A)</a>	
<a href="#">MC-150a 230V AC</a>	Contactor
<a href="#">ABS203C250</a>	
<a href="#">1362002800 / MC-130a</a>	IEC Contactor
<a href="#">MC-85A-AC120V</a>	
<a href="#">1366000300 / MC-185A</a>	
<a href="#">AN-16D3-16H</a>	
<a href="#">MC-22b 3p 230V 1a1b</a>	
<a href="#">MC-9B 3P 230V AC 1a1b</a>	
<a href="#">Shunt Trip Coil for AS - 13D3 - 13A</a>	Shunt Trip Coil
<a href="#">MC-9A-AC120V-22S</a>	
<a href="#">ABS53C-40A</a>	
<a href="#">ABH103c 60A EXP</a>	
<a href="#">ABS53C20</a>	switch
<a href="#">ABH203c 225A EXP</a>	Automatic switch
<a href="#">MC-32a /AC230V 1a1b</a>	Contactor
<a href="#">MC12BAC230</a>	CONTACTOR
<a href="#">MC-40A-AC230V</a>	
<a href="#">UA-1-11</a>	
<a href="#">MW9BMB22BMB</a>	
<a href="#">1345000800</a>	Contactor
<a href="#">1362002600</a>	Contactor
<a href="#">1336007000 / MC32AAC230</a>	CONTACTOR
<a href="#">1347000800 / MC22BAC230</a>	CONTACTOR
<a href="#">ABN803C630A</a>	CIRCUIT BREAKER (MCCB)
<a href="#">1386001600 MC150AAC24L</a>	
<a href="#">0108003200 / TS630N3PATU630</a>	
<a href="#">MT-225/3K- 120-185 A</a>	THERMAL RELAY
<a href="#">MC-130A 110V AC</a>	CONTACTOR COIL
<a href="#">MC-225A 100-240VAC/DC 2A2B</a>	Contactor
<a href="#">MC-9B (DC24V)</a>	
<a href="#">MC-12B (DC24V)</a>	
<a href="#">MT-32/3K-18</a>	Thermal Overload Relay
<a href="#">MC32ADC24</a>	contactor



Product	Description
<a href="#">MC185A-AC 240V</a>	Contactor
<a href="#">1374000500 / MC800A-30-22-IV-B-E</a>	Contactor
<a href="#">UA11A1B</a>	auxiliary contacts
<a href="#">MC40A4PAC230</a>	CONTACTOR
<a href="#">ABH403c 400A EXP</a>	
<a href="#">AS-40E3-40A M2D2D2BX AC6U0AL</a>	Air Circuit Breaker
<a href="#">ABN403C400A</a>	MCCB box circuit breakers
<a href="#">ABN203C250A</a>	MCCB box circuit breakers
<a href="#">ABS103C50A</a>	CIRCUIT BREAKER
<a href="#">BKN2PC2A</a>	CIRCUIT BREAKER
<a href="#">ABS104C30A</a>	CIRCUIT BREAKER
<a href="#">MC22BAC230</a>	CIRCUIT BREAKER
<a href="#">EBN53c50A30mA</a>	CIRCUIT BREAKER
<a href="#">GMRM3A1B230</a>	CONTACTOR
<a href="#">77121641119</a>	
<a href="#">MR-4-120</a>	Rele
<a href="#">ABS33C10A</a>	
<a href="#">P/N: 1337000800, Type: MC-40a</a>	Contactor 3P
<a href="#">UA-4 4B</a>	Auxiliary shooter
<a href="#">MC-22A/4</a>	Magnetic Contactor
<a href="#">AN-10D3-10A</a>	Air Circuit Breaker, 500VAC, 1000A
<a href="#">AS-50F3-40A</a>	Air Circuit Breaker, 500VAC, 4000A
<a href="#">AS-20E3-20A</a>	Air Circuit Breaker, 500VAC, 2000A
<a href="#">1389001200</a>	Contactor
<a href="#">CODE: 1342012900 / MODEL: MC-100A</a>	
<a href="#">TS400N ATU 400A 3P</a>	Circuit breaker
<a href="#">EBN 203c 150 A</a>	
<a href="#">ABS53C30A</a>	
<a href="#">ABS33C30A</a>	CIRCUIT BRAKER
<a href="#">ABH53C30A</a>	Circuit Breaker
<a href="#">ABS33C15A</a>	Circuit Breaker
<a href="#">LSLV0015S100-4EOFNM</a>	Inverter
<a href="#">MC-22A/4 2A2B AC110V</a>	AC magnetic contactor
<a href="#">LSCRADLE-AS20</a>	
<a href="#">AS-20E3-20</a>	
<a href="#">ABN53C50A</a>	
<a href="#">0131001600</a>	
<a href="#">0129002100</a>	
<a href="#">0129001700</a>	
<a href="#">1328000800/ MC-18a</a>	Contactor
<a href="#">1336000800/ MC-32a</a>	Contactor
<a href="#">1383014000/ MC-85a</a>	Contactor
<a href="#">MC150AAC230L 1363001200</a>	
<a href="#">MC130AAC220L 1385000300</a>	
<a href="#">MC100AAC230L 1384008300</a>	



Product	Description
<a href="#">MC265V100200L 1369000200</a>	
<a href="#">ABS204c 250AF/ 100AT</a>	
<a href="#">ABS104c 125AF/ 50AT</a>	
<a href="#">ABS32c (30AF / 5A)</a>	
<a href="#">ABS32c (30AF / 10A)</a>	
<a href="#">ABS32c (30AF / 20A)</a>	
<a href="#">ABS32c (30AF / 15A)</a>	
<a href="#">ABS32c (30AF / 30A)</a>	
<a href="#">ABS32c (30AF / 50A)</a>	
<a href="#">ABN404C300A</a>	MCCB box circuit breakers
<a href="#">MMS-32S 26 A 0705100441</a>	ENGINE GUARD
<a href="#">0129006600 / ABN53C30A</a>	Circuit Breaker
<a href="#">MC-32a/DC24/2a2b</a>	Contactora
<a href="#">1368000300 / MC225a AC/DC24V 2a2b</a>	contactora
<a href="#">MC32ADC24</a>	
<a href="#">MC32A4PAC230</a>	Contactora
<a href="#">ABS103C60A</a>	
<a href="#">0142034200</a>	
<a href="#">MC-9A 240V 50/60HZ</a>	CONTACTOR
<a href="#">MC75AAC230L</a>	CONTACTOR
<a href="#">ABS32C30A</a>	
<a href="#">1347000400</a>	
<a href="#">MC-22B 10VAC 1A1B</a>	
<a href="#">ABN103D 75A</a>	
<a href="#">ABH403c 250A EXP</a>	
<a href="#">MC-32A-1A-1B</a>	
<a href="#">MC40A-30-22-U7-S-E</a>	CONTACTOR
<a href="#">MC-32A 230V AC 1a1b</a>	Contactora
<a href="#">ABS54C20A</a>	
<a href="#">MR-4 DC110V 4°</a>	
<a href="#">MC32AAC230</a>	CONTACTOR
<a href="#">0131007700</a>	
<a href="#">0132001700</a>	
<a href="#">MC-40a</a>	contactora LS IS MC 3P
<a href="#">1386001800</a>	
<a href="#">AS-40E3-40A M2D2D2BX AD6U0AL EXP</a>	
<a href="#">MC185V100200L</a>	CONTACTOR