



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Robertshaw

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

| Product                               | Description   |
|---------------------------------------|---|
| <a href="#">5000-811</a>              | Thermostat  |
| <a href="#">365A-A2</a>               | vibration switch explosion-proof                        |
| <a href="#">366-A2</a>                | vibration switch  |
| <a href="#">366-A3-H</a>              |   |
| <a href="#">368-R</a>                 | Pneumatic Vibration Detector                            |
| <a href="#">376A-A1-CO</a>            | Vibraswitch® Malfunction Detectors                      |
| <a href="#">613-NHU-TD07-B</a>        | Liquid Level Detector                                   |
| <a href="#">613-NLU-TD07-B</a>        | Model 613 coolant level detector                        |
| <a href="#">913-NLU-000-T</a>         |   |
| <a href="#">913-NLU-TD10-T</a>        |   |
| <a href="#">EURO366G-D0-W2-H-FX-F</a> | VIBRASWITCH   |
| <a href="#">RT-1009-A1</a>            | TEMPERATURE REGULATOR EXACTLY PER SERIAL NUMBER E98B759 |
| <a href="#">GE158A7585P065</a>        | Temperature Regulator                                   |
| <a href="#">613 NLU-0000-0</a>        | DETECTOR, MINITEK LOLVL ( BTO)                          |
| <a href="#">PO112201</a>              | Pressure piston   |
| <a href="#">P011-2201</a>             | pressure operator                                       |
| <a href="#">5S4-501-889</a>           | Commercial Gas Valves                                   |
| <a href="#">K-1-60</a>                | Thermostat  |
| <a href="#">TA-158A7585P052</a>       | THERMOSTATIC ASSEMBLY FOR 4"RT-1010-A3 REGULATOR        |
| <a href="#">EURO366G-D0-W3-H-FX-F</a> |   |
| <a href="#">613-N??-0000-0</a>        | Mini-Tek Miniature Liquid-Level Detector                |
| <a href="#">EURO366G-D2-W2-H-FX-F</a> | VIBRASWITCH   |
| <a href="#">EURO366G-D0-W2-H-FX-X</a> | VIBRASWITCH   |
| <a href="#">900SA647-01</a>           | SWITCH ASSEMBLY   |
| <a href="#">904GC402-02</a>           | SPACE HEATER  |
| <a href="#">160KB044-03</a>           | COIL ASSEMBLY   |
| <a href="#">EURO366G-D2-W2-H-X-X</a>  | VIBRASWITCH   |
| <a href="#">PS2197/4</a>              | SOLENOID  |
| <a href="#">5500-208M</a>             | SWITCH  |
| <a href="#">571A-D</a>                | Vibration transmitter                                   |
| <a href="#">086568A0016</a>           | 16' IP-66 CABLE   |
| <a href="#">E365A-G0</a>              | Vibraswitch (ATEX)                                      |
| <a href="#">S291</a>                  | Coolant level sensor                                    |
| <a href="#">613-N??-0000-B</a>        |   |
| <a href="#">613-N??-0000-C</a>        |   |

| Product                                 | Description  |
|---|--|
| <a href="#">613-N??-TD12-0</a>          |  |
| <a href="#">613-N??-TD12-B</a>          |  |
| <a href="#">365A-A0-E</a>               | VIBRATION SWITCH,                                      |
| <a href="#">UW-GE158A7585P0</a>         | UPPER WORKS FOR GE158A7585P052                         |
| <a href="#">EAC-4L</a>                  | Thermostat   |
| <a href="#">HAZMAT BOX</a>              | SPECIAL PACKING HAZARDOUS MATERIAL                     |
| <a href="#">UW-RT1010-A1</a>            | COMPLETE UPPERWORKS                                    |
| <a href="#">82179-S3</a>                | Valve Repair Kit                                       |
| <a href="#">82440-B1</a>                | INDICATING LOCKOUT RELAY RED/GREEN                     |
| <a href="#">82653-B1</a>                | Snap-Acting Position Indicator                         |
| <a href="#">83939-D23</a>               | Aluminium High Capacity Relay                          |
| <a href="#">83939-E1</a>                | Aluminium Lockout Relay                                |
| <a href="#">83939-G321</a>              | KNOB-ACUTATED RELAY, ALUMINUM BODY                     |
| <a href="#">83939-H221</a>              | ALUMIMUM LEVEL ACT INDICATING RELAY                    |
| <a href="#">83939-H323</a>              | Lever Operated Relay                                   |
| <a href="#">84370-B1</a>                | PNEUM VALVE  |
| <a href="#">84370-B2</a>                | Pressure Sensor  |
| <a href="#">83939-B21</a>               | Aluminium Relay  |
| <a href="#">81073-A1</a>                | Check Valve  |
| <a href="#">82653-B8</a>                | SNAP-ACTING POSTN INDICATOR                            |
| <a href="#">82653-B3</a>                | SNAP-ACTING POSITION INDICATOR                         |
| <a href="#">7000DERHC-S7C (700-059)</a> | Gas valve  |
| <a href="#">624-NLU-TD12-B</a>          | Level indicator  |
| <a href="#">1720-801</a>                | Electromagnet Replacement Kit                          |
| <a href="#">700-057</a>                 | Gas Valve  |
| <a href="#">E365A-G2-E</a>              | VIBRASWITCH  |
| <a href="#">614-NHG-0000-C</a>          | Robertshaw Mini-Tek Level Sensor                       |
| <a href="#">E365A-A-O-E</a>             |  |
| <a href="#">EURO366-A2-H2-A-FX-X</a>    | VIBRATION SWITCH                                       |
| <a href="#">365AD8</a>                  | Vibration Switch Dpdt 5a 120vac                        |
| <a href="#">366-A0</a>                  | Vibration Switch                                       |
| <a href="#">EAC-4L , 203-05-SSH-450</a> | THERMOSTST   |
| <a href="#">E87C515</a>                 | Thermostatic Control Valve                             |
| <a href="#">E87C514</a>                 | Thermostatic Control Valve                             |
| <a href="#">710-101</a>                 | Non Regulated LC valve 1/2" In x 1/2" Out Manual Model |
| <a href="#">Smart 2000</a>              | Digital Programmable Thermostat                        |
| <a href="#">110-326</a>                 | Natural Gas Water Heater Valve Uni-Kit w/ 1-3/8"       |
| <a href="#">631-NLU-TD07-B</a>          | Mini-Tek Level Sensor                                  |
| <a href="#">82665-A10</a>               |  |
| <a href="#">606-191-00400</a>           |  |
| <a href="#">606-191-00401</a>           |  |
| <a href="#">606-191-00412</a>           |  |
| <a href="#">606-191-00406</a>           |  |
| <a href="#">606-191-00407</a>           |  |
| <a href="#">606-191-00403</a>           |  |

| Product   | Description                                     |
|---|---|
| <a href="#">606-191-00405</a>                           |   |
| <a href="#">606-191-00420</a>                           |   |
| <a href="#">606-191-00421</a>                           |   |
| <a href="#">606-191-00426</a>                           |   |
| <a href="#">606-191-00427</a>                           |   |
| <a href="#">606-191-00424</a>                           |   |
| <a href="#">606-191-00425</a>                           |   |
| <a href="#">606-191-00429</a>                           |   |
| <a href="#">606-191-00404</a>                           |   |
| <a href="#">571A-A</a>                                  | STUD MOUNTED VIBRATION TRANSMITTER              |
| <a href="#">167-A1</a>                                  | Level Transmitter                               |
| <a href="#">613-NLU-0000- B</a>                         | Detector  |
| <a href="#">366-A8</a>                                  | Vibration Switch                                |
| <a href="#">22777-C1</a>                                | O-ring  |
| <a href="#">96995-A18</a>                               | POWER PILL                                      |
| <a href="#">90-360013</a>                               |   |
| <a href="#">RT-1010-A2</a>                              | temperature regulator                           |
| <a href="#">613-NLU-0000-C</a>                          | Sensor  |
| <a href="#">365A-A8</a>                                 | SPDT Switch                                     |
| <a href="#">EURO366-D0-H1-H-FX-X</a>                    | VIBRATION SWITCH, DPDT, GOLD CONTACTS           |
| <a href="#">CR 101-A2</a>                               | RATIO RELAY W/ ADJ. BIAS, 1:2 RATIO (81032-G1)  |
| <a href="#">CR-101-A1</a>                               | VOLUME BOOSTER RELAY W/ ADJUSTABLE BIAS         |
| <a href="#">EURO366-D9-H2-E-FX-M</a>                    | Robertshaw Vibraswitch Explosion Proof.         |
| <a href="#">P/N: 5S4-501-889, Model: U701ODERHC-S7C</a> | Gas Valve                                       |
| <a href="#">613-NLG-0000-B</a>                          | Mini-Tek Level Sensor                           |
| <a href="#">90-285-LSD-00</a>                           | Coolant Level Sensor                            |
| <a href="#">4290-006</a>                                | Robertshaw Commercial Gas Fryer Oven Thermostat |
| <a href="#">GSF 90602300</a>                            |   |
| <a href="#">S18*24*JG1/4*BHB*A0.35</a>                  |   |
| <a href="#">613-NHU-0000-B</a>                          | Coolant Level Detector                          |
| <a href="#">624-NHU-0000-B</a>                          |   |
| <a href="#">82653-B2</a>                                | STATUS INDICATOR RELAY(ON/OFF)                  |
| <a href="#">83939-H321</a>                              | DRIVE RELAY.                                    |
| <a href="#">83939-F211</a>                              | PUSH BUTTON RELAY                               |
| <a href="#">83939-Q3</a>                                | ALARM RELAY                                     |
| <a href="#">83939-B34</a>                               | 3-PORT RELAY ORIFICE                            |
| <a href="#">90-285-LSD-10</a>                           |   |
| <a href="#">P/N: 100-00834-38 Model: SP 845</a>         | Ignition Module                                 |
| <a href="#">R-1220</a>                                  |   |
| <a href="#">366A-A8</a>                                 | JB PUMP VIBRATION SWITCH                        |
| <a href="#">624-NLU-0000-B</a>                          | Mini-Tek Level Sensor                           |
| <a href="#">82059-C1</a>                                | Receiver Indicator Relay                        |
| <a href="#">81073-A2</a>                                | Check Valve                                     |
| <a href="#">360026</a>                                  |   |
| <a href="#">MODEL 613-NLU-TD07-B</a>                    | Level Sensor                                    |

| Product                                       | Description                                      |
|---|--|
| <a href="#">84370-A1</a>                      | Pressure Sensor                                  |
| <a href="#">4350-040</a>                      | Gas Thermostat                                   |
| <a href="#">1720-004</a>                      | Gas Safety Valve                                 |
| <a href="#">EURO366-A0-H2-A-FX-X</a>          | VIBRATION SWITCH                                 |
| <a href="#">V180</a>                          |  |
| <a href="#">UW-GE158A7585P052</a>             |  |
| <a href="#">S1615 S6660</a>                   | Water Valve                                      |
| <a href="#">5500-202</a>                      |  |
| <a href="#">EURO366-A0-HorW2-A-FX-X</a>       | VIBRATION DETECTOR                               |
| <a href="#">VC-210-BQR 1/2"</a>               | PNEUMATIC DIAPHRAGM CONTROL VALVE                |
| <a href="#">EURO366-A7-H2-A-FX-X</a>          | vibraswitch                                      |
| <a href="#">R-5S4-501-889</a>                 | gas valve  |
| <a href="#">365A-D0</a>                       |  |
| <a href="#">9200H</a>                         | THERMOSTAT                                       |
| <a href="#">R-5500-202</a>                    |  |
| <a href="#">12601530</a>                      |  |
| <a href="#">6220</a>                          |  |
| <a href="#">SP715A</a>                        | Intermittent Pilot Ignition Control              |
| <a href="#">5300614</a>                       |  |
| <a href="#">NGV 10MU</a>                      | Termostat  |
| <a href="#">RT1001-R5413</a>                  | Temperature Regulator                            |
| <a href="#">7000BMVR-L</a>                    | Gas Valve  |
| <a href="#">780-845</a>                       | thermostat                                       |
| <a href="#">R-402-811-460</a>                 | valve  |
| <a href="#">P/N:1262780; Type:S 19 05 V19</a> | Water Valve                                      |
| <a href="#">624-NLU-0000</a>                  | Level Sensor                                     |
| <a href="#">571A-F</a>                        | transmitter                                      |
| <a href="#">TA-GE158A7585P0 46</a>            | THERMOSTATIC ASSEMBLY                            |
| <a href="#">365A-A7</a>                       | Malfunction Detector                             |
| <a href="#">5318B-A1-A</a>                    |  |
| <a href="#">700-059</a>                       | valve  |
| <a href="#">5000-202</a>                      |  |
| <a href="#">570B-E</a>                        | SENS.VIBRA                                       |
| <a href="#">GE347A5759P001</a>                | 5" Temperature Regulator                         |
| <a href="#">MiniTek 613-NLG-TD12-C</a>        |  |
| <a href="#">U7010DERHC</a>                    |  |
| <a href="#">613-NLU-TD12-C</a>                | Coolant Level Detector                           |
| <a href="#">R-5000-811</a>                    |  |
| <a href="#">RT1010A1</a>                      |  |
| <a href="#">365A-D2</a>                       |  |
| <a href="#">SP735P (R-780-746)</a>            |  |
| <a href="#">TA-GE158A7585P0</a>               | THERMOSTATIC ASSEMBLY FOR 4"RT-1010-A3 REGULATOR |
| <a href="#">1950-001</a>                      |  |
| <a href="#">700-506</a>                       | Gas Valve  |
| <a href="#">E98B553 (RT1010-A1)</a>           | 3" Temperature Regulator                         |

| <b>Product</b>                                     | <b>Description</b>                    |
|--|---------------------------------------|
| <a href="#">RX-2-24</a>                            | RX ASSEMBLY                           |
| <a href="#">82158-A1</a>                           | SPRING ASSEMBLY                       |
| <a href="#">22777-B1</a>                           |                                       |
| <a href="#">82159-C4</a>                           |                                       |
| <a href="#">376A-A1-D0</a>                         |                                       |
| <a href="#">614-NLG-0000-C</a>                     | Mini-Tek Level Sensor                 |
| <a href="#">1265800</a>                            | solenoid valve                        |
| <a href="#">816291317 / LED145/201</a>             | Digital Timer Assembly                |
| <a href="#">086568A0016</a>                        | Cable                                 |
| <a href="#">RSCERT</a>                             | CERTIFICATE OF CONFORMANCE AND ORIGIN |
| <a href="#">R-700-522</a>                          | Gas control Valve                     |
| <a href="#">83939-Q1</a>                           | Lockout Relay                         |
| <a href="#">83939-H211</a>                         | Relay                                 |
| <a href="#">366-D8</a>                             | Vibraswitch                           |
| <a href="#">EUR 366-A8-H2-A-FX-X</a>               |                                       |
| <a href="#">365A-D0E</a>                           |                                       |
| <a href="#">83939-G221</a>                         | PUSH-BUTTON-OPERATED RELAY            |
| <a href="#">82059-C2</a>                           | INDICATOR RELAY                       |
| <a href="#">VC-210-BR 3/4"</a>                     |                                       |
| <a href="#">VC-210-BR 1/2"</a>                     |                                       |
| <a href="#">SL-705-E3-S11-B21-1</a>                |                                       |
| <a href="#">365A-D8-H</a>                          |                                       |
| <a href="#">84392-B2</a>                           |                                       |
| <a href="#">84392-A3</a>                           | PRESS SENSOR                          |
| <a href="#">EURO366-D0-H2-H-FX-X</a>               | Vibration Switch                      |
| <a href="#">EURO366-A8-H2-A- FX-X</a>              | VIBRATION DETECTOR                    |
| <a href="#">compression spring for 1010A200</a>    | compression spring for fitting        |
| <a href="#">571A-E</a>                             | Vibration Transmitter                 |
| <a href="#">624-NHG-000-C</a>                      | Level Sensor                          |
| <a href="#">1491350</a>                            | micropump                             |
| <a href="#">85380 E0012</a>                        | valve                                 |
| <a href="#">624-NLU-TD12-C</a>                     | Level indicator                       |
| <a href="#">R-5300-711</a>                         |                                       |
| <a href="#">7000DERHC</a>                          | GAS valve                             |
| <a href="#">E365A-A2</a>                           | Vibraswitch                           |
| <a href="#">5500-213M</a>                          | Energy regulators                     |
| <a href="#">R-402-811-460 (7000BMVR nat 4)</a>     |                                       |
| <a href="#">7000ERHC-120-S7C</a>                   |                                       |
| <a href="#">1009-A1</a>                            | Thermostatic Valve                    |
| <a href="#">366-A7</a>                             | VIBRATION SWITCH                      |
| <a href="#">7000derch s7c</a>                      |                                       |
| <a href="#">Euro366-A7-W1-A-XX-X (USA version)</a> | vibraswitch malfunction detector      |
| <a href="#">5318B-B1-A</a>                         | Level Switch                          |
| <a href="#">5000-814</a>                           | Hot Thermostat                        |
| <a href="#">K-78918</a>                            | Sprayer (ALT) part solenoid valve     |

| Product   | Description  |
|---|--|
| <a href="#">EA5-10-36-1U</a>                      | Operating Thermostat                                   |
| <a href="#">375A-A3-F4</a>                        | Vibraswitch  |
| <a href="#">365A-D2-E</a>                         | VIBRATION SWITCH                                       |
| <a href="#">K-79392</a>                           |  |
| <a href="#">7000 DERHC-S7C</a>                    | Gas Valve  |
| <a href="#">EURO366G-A2-W3-A-X-X</a>              | Vibration switch                                       |
| <a href="#">H2170840200</a>                       |  |
| <a href="#">EA5-7-60U</a>                         |  |
| <a href="#">WH9</a>                               |  |
| <a href="#">1285QS102</a>                         | Temperature Regulator                                  |
| <a href="#">22700130</a>                          | solenoid valve   |
| <a href="#">375A-A1-C0</a>                        | Vibration Switch                                       |
| <a href="#">Z-94406-6</a>                         | FJ Coil 120 volt                                       |
| <a href="#">84370-A2</a>                          | VALVE  |
| <a href="#">7835800</a>                           | micro pump   |
| <a href="#">365A-A8-E</a>                         | Switch   |
| <a href="#">K-909-42</a>                          |  |
| <a href="#">12602130</a>                          |  |
| <a href="#">K-65354-2</a>                         | valve  |
| <a href="#">41-604</a>                            | Oven igniter   |
| <a href="#">570B-F</a>                            | Vibration sensor                                       |
| <a href="#">2560021</a>                           |  |
| <a href="#">366-A8 /117V</a>                      | VOLTAGE RESET=117V AC=DC 0,1A SPDT 7 A 120/460 50/60HZ |
| <a href="#">086568A0064</a>                       | cable for vibration transmitter                        |
| <a href="#">6000-005 (366-A8)</a>                 |  |
| <a href="#">EURO366 D9-W2-G-FL-X</a>              | sensor   |
| <a href="#">086568A0032</a>                       |  |
| <a href="#">614-NLU-0000-C</a>                    | LIQUID LEVEL DETECTOR                                  |
| <a href="#">614-NLU-0000-0</a>                    | LIQUID LEVEL DETECTOR                                  |
| <a href="#">9200V</a>                             |  |
| <a href="#">365A-A2-E</a>                         | Malfunction Detector                                   |
| <a href="#">376A-A3-D3</a>                        | VIBR. SENSOR   |
| <a href="#">6000-007</a>                          | Vibrasw  |
| <a href="#">5000-071</a>                          | Thermostat   |
| <a href="#">IMV-202</a>                           | Water Valve  |
| <a href="#">DOCUMENTS FOR HAZARDOUS MATERIALS</a> |  |
| <a href="#">HAZARDOUS BOX</a>                     |  |
| <a href="#">EA5-10-36U</a>                        | thermostats  |
| <a href="#">040KB132-10</a>                       | PLASTIC COVER FOR MODEL 366/368 VIBRATION SWITCH       |
| <a href="#">904GC402-04</a>                       | RESISTOR, HEATER 120V                                  |
| <a href="#">570B-C</a>                            | Stud Mount Vibration Transmitter                       |
| <a href="#">376 A-A1-C0</a>                       | VIBRATION SWITCH,120VAC, 50-60HZ, 15 SEC DELAY         |
| <a href="#">7000BDER-S7A/ 700-056</a>             | Gas valve  |
| <a href="#">HTV1101092-01U</a>                    | Electric thermostats                                   |

| Product                                      | Description  |
|--|--|
| <a href="#">HTV1201092-01U</a>               |  |
| <a href="#">365A-A-0</a>                     | Vibraswitch  |
| <a href="#">5300-219</a>                     |  |
| <a href="#">22606180</a>                     |  |
| <a href="#">12605350</a>                     |  |
| <a href="#">SJ-152-20</a>                    | ELECTRIC COOKING CONTROL MODEL SJ ASSY             |
| <a href="#">613-NHG-0000-C</a>               | Detector, Minitex High Lvl Oil                     |
| <a href="#">570B-D</a>                       | Loop Powered Stud Mount Vibration Transmitter      |
| <a href="#">7000MVRHC-S7C</a>                | 700 Series Millivolt Gas Valves                    |
| <a href="#">DANGEROUS DOCS</a>               | DOCUMENTS FOR HAZARDOUS MATERIALS                  |
| <a href="#">RT-1009-A1/E09C054</a>           |  |
| <a href="#">84372-A3</a>                     | pneumatic pressure switch                          |
| <a href="#">U7010DERHC-S7A/5P9501887</a>     |  |
| <a href="#">82665-B1</a>                     |  |
| <a href="#">EA5-8-36U</a>                    |  |
| <a href="#">5300-406</a>                     |  |
| <a href="#">ST1205133</a>                    | resistive loads thermostat                         |
| <a href="#">K-78103-2</a>                    | Valve, Mixing Dispenser                            |
| <a href="#">E365A-A8</a>                     | SPDT Switch  |
| <a href="#">376AA3F2</a>                     | Malfunction Detectors - Weather Proof Model (376A) |
| <a href="#">366-A3</a>                       | Vibration Switch                                   |
| <a href="#">614-NLG-0000-0</a>               |  |
| <a href="#">365A-D-8-E</a>                   |  |
| <a href="#">376A-A3-E4</a>                   | VIBRO SWITCH                                       |
| <a href="#">10-227 S-1</a>                   | Replacement S1 Sensor                              |
| <a href="#">EURO366-A9-H2-A-FX-X</a>         |  |
| <a href="#">K-5-60</a>                       | Electric Thermostat                                |
| <a href="#">39385-F1</a>                     |  |
| <a href="#">22777</a>                        |  |
| <a href="#">K-78103-1-AM</a>                 |  |
| <a href="#">KA-1119-42</a>                   | ELECTRIC COOKING CONTROL THERMOSTAT                |
| <a href="#">710-502</a>                      | gas valve  |
| <a href="#">GE158A7585P046 4" RT-1010-A2</a> |  |
| <a href="#">6000-002</a>                     | Motor Protection                                   |
| <a href="#">571A-DO-0.5 IPS</a>              |  |
| <a href="#">S23-35 V19 /12600600</a>         | Solenoid valve                                     |
| <a href="#">86568-A64</a>                    |  |
| <a href="#">613-NLG-0000-C</a>               |  |
| <a href="#">E365A-A2-E</a>                   |  |
| <a href="#">162-602-1</a>                    | Dryer Timer  |
| <a href="#">12601920</a>                     |  |
| <a href="#">E365A-A7</a>                     | Vibration switch                                   |