



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Ağaoğlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Samwon

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">C37HD-20PB-1</a>	
<a href="#">C40HF-10PB-1</a>	
<a href="#">C40HF-10PX-1</a>	Cable
<a href="#">C40HF-15PB-1</a>	
<a href="#">C40HF-20PB-1</a>	I/O Cable (2m)
<a href="#">R16Q-PS5A-M</a>	
<a href="#">R1T-YC</a>	
<a href="#">R32C-YNT-V</a>	
<a href="#">R40HH-30SM</a>	
<a href="#">R4T-16P-S</a>	Relay Terminal
<a href="#">R4T-YC</a>	CONTROL RELAY
<a href="#">R6T-16P-A</a>	RELAY BOARD
<a href="#">R8T-24V</a>	Relay
<a href="#">S4T-16P-202D</a>	CONTROL RELAY
<a href="#">SE-1H80D</a>	I/O LINK BOARD
<a href="#">TG7-1H40S IMO</a>	Breakout Terminal Board
<a href="#">TG-COM 20</a>	
<a href="#">XTB-20H</a>	
<a href="#">C40HF-30PB-1</a>	Connecton Cable
<a href="#">C40HF-100PB-1</a>	IO-LINK , SAMWON ACT INTERFACE TERMINALS
<a href="#">TG7-1H40L-N</a>	.
<a href="#">TG7-1H40CB</a>	
<a href="#">R32C-PS5A-CV</a>	
<a href="#">C40HF-40PB-1</a>	PLC Connection Cable
<a href="#">C40HF-65PB-1</a>	
<a href="#">SS-2P-80M-B</a>	
<a href="#">DL-72</a>	
<a href="#">SA-1H40S</a>	
<a href="#">C40HF-18PB-1</a>	Cable
<a href="#">SE-4F80D</a>	Interface Terminal Block
<a href="#">XTB-50H</a>	INPUT LINK MODULE
<a href="#">R16C-YNT</a>	Terminal Relay
<a href="#">S1A-24V-2Z</a>	SOLID STATE RELAY
<a href="#">R32C-YPT</a>	Terminal Relay
<a href="#">R4G 24V</a>	Relay Terminal
<a href="#">R16C-NS5A-16P</a>	I/O LINK RELAY TERMINAL

Product	Description
<a href="#">R4Q-24V</a>	
<a href="#">TG-3M20S</a>	I/O LINK TERMINAL BLOCK
<a href="#">C40HF-15PX-1</a>	I/O LINK CABLE
<a href="#">R32G-NT</a>	
<a href="#">S4T-16P-202V</a>	
<a href="#">SU-105PT</a>	Temperature Controller
<a href="#">C40HH-20PH-XBI</a>	
<a href="#">SD94M</a>	Digital Temperature Controller
<a href="#">C40HH-15PH-XBI</a>	cable for connection with expansion module
<a href="#">XTB-34H</a>	Interface Terminal Block
<a href="#">S4A-24V-DS</a>	relay board
<a href="#">S1T-4P-202D</a>	Control Relay
<a href="#">M-107pt</a>	VEGETABLE ROOM INDICATOR
<a href="#">C40HF-100PX-1</a>	Cable signal PLC- IO link
<a href="#">C40HF-25PX-1</a>	Cable signal PLC- IO link
<a href="#">XTB-COM20B</a>	Interface Terminal Block
<a href="#">R32C-YNT</a>	Relay terminal
<a href="#">XTB-LS1</a>	Terminal Block
<a href="#">MPT-L80P-B/BK</a>	Terminal block mounting type branch box
<a href="#">R4P-DC24VC</a>	
<a href="#">R4T-G6D</a>	
<a href="#">M12S-G43-V050</a>	
<a href="#">M12S-G43-V080</a>	
<a href="#">M12S-G43-V100</a>	
<a href="#">SD-4F40S</a>	
<a href="#">MPT-K80P-B/BLWH</a>	Multi Connection Box
<a href="#">R2G-24V</a>	
<a href="#">SA-1T50S</a>	ACT TERMINAL BLOCK
<a href="#">SA-1T40S</a>	
<a href="#">R4G-24V-E3</a>	
<a href="#">MPT-K40P-B/BLWH</a>	
<a href="#">MPT-K60P-B/BLWH</a>	
<a href="#">S4T-E3-202V</a>	Relay
<a href="#">C40HT-20S-OB32</a>	
<a href="#">C40HF-15PB-3</a>	
<a href="#">C40HT-20LB-IB32</a>	
<a href="#">R1T-4P</a>	
<a href="#">R32C-PS5A-40P</a>	
<a href="#">SU-105IP</a>	Temperature Controller
<a href="#">R16C-PS5A-20P</a>	Relay Terminal
<a href="#">R32T-PS5A-40P</a>	
<a href="#">R32T-NS5A-40P PNP</a>	terminal block
<a href="#">R32T-NS5A-40P NPN</a>	
<a href="#">R32C-NS5A-40P PNP</a>	
<a href="#">R16C-NS5A-34P NPN</a>	

Product	Description
<a href="#">R16C-NS5A-20P NPN</a>	
<a href="#">C40HF-90PB-1</a>	
<a href="#">C40HH-20PH-XBE</a>	CABLE
<a href="#">C20HH-20PD</a>	CABLE
<a href="#">C40HH-20PD</a>	CABLE
<a href="#">SD-94M (RRRN)</a>	Temperature & Humidity Controller
<a href="#">C40HF-15LB-MIN1</a>	
<a href="#">C40HF-15LB-MIP1</a>	
<a href="#">C40HF-20LB-MIN1</a>	
<a href="#">C40HF-20PBU-MIP1</a>	
<a href="#">C37HD-20LB-MIP1</a>	
<a href="#">TG7-1H40L</a>	
<a href="#">R32G-PT</a>	
<a href="#">C37HD-20PBU-MIP1</a>	
<a href="#">C40HF-05PB-1</a>	Connection cable relay
<a href="#">R32C-NS5A-40P</a>	Relay Board
<a href="#">R32C-NS5A-8CV</a>	
<a href="#">TG7-1H40L-P</a>	Terminal Block
<a href="#">C40HT-20S-1756-IB32 (SIMPAC)</a>	
<a href="#">C40HT-20S-1756-IV32 (SIMPAC)</a>	
<a href="#">C40HT-20S-1756-OB32 (SIMPAC)</a>	
<a href="#">C40HF-150PB-OM3</a>	cable
<a href="#">C40HF-150PB-3</a>	cable
<a href="#">RIT-YC</a>	
<a href="#">C40HF-15LB-MINI</a>	
<a href="#">C40HF-15LB-MIPI</a>	
<a href="#">C40HF-20PBU-MIPI</a>	
<a href="#">C37HD-20PBU-MIPI</a>	
<a href="#">C40HF-20LB-MINI</a>	
<a href="#">ST540E-00/RS/DI</a>	
<a href="#">M12S-A43-V020</a>	Sensor cable
<a href="#">SLF-9LH-IC</a>	
<a href="#">STF-#4D-IB</a>	Turbo Fan
<a href="#">SU-105Ta3</a>	
<a href="#">MPT-K80P-B/BL</a>	
<a href="#">M12S-A43-V050</a>	
<a href="#">M12S-B43-V020</a>	
<a href="#">M12S-B43-V050</a>	
<a href="#">M12S-C43-V020</a>	
<a href="#">M12S-C43-V050</a>	
<a href="#">U78T-5DN-M12</a>	
<a href="#">S4A-24V-2Z</a>	