



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)



# Yuke

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

## nBRAND'S BPNOYU'

CuTrod	NctoCsidsup
<a href="#">1 0-1 1F0 R01</a>	Halve
<a href="#">2PIR01</a>	
<a href="#">2-P1F2 S 2THON F- UM 6K</a>	FS- way coa3ial valve e3ternally controlled,
<a href="#">2THON F- 6V DS6L 2FBF70</a>	-S- way coa3ial e3ternally controlled valve
<a href="#">VC BIII B :D8T:I2</a>	Voa3ial valve
<a href="#">221BBB S ON I1 6V</a>	valve
<a href="#">2I200IS ON I1 6V</a>	EmulsionSgrinding oil
<a href="#">ON I2</a>	Halve
<a href="#">2F2BBI S ON -2</a>	Halve
<a href="#">2-FI-2 S 4D8T: I2</a>	Dressure relief valve
<a href="#">HON I1 6V 5Art.6r.2I2BRR9</a>	valve
<a href="#">2120RI</a>	Nxhlwasser
<a href="#">2II-7- ON -1 6V IP -1VII1S1AV-F1G I7</a>	Halve
<a href="#">2I11-2</a>	Halve
<a href="#">6K</a>	6ormally Kpen Voa3ial Halve
<a href="#">4onderabdichtungen</a>	4pecial 4eals
<a href="#">21-RP1 ON I2 UM FP I2VI IS-UV -PA P1</a>	emulsionSwater
<a href="#">A P2 6V S 2P1-11</a>	
<a href="#">21B-FI</a>	air dry
<a href="#">6K 521B-FI9</a>	6ormally Kpen Voa3ial Halve 5Oodel 21B-FI9
<a href="#">2P210B</a>	IP I1KF IS-UV -PG I7
<a href="#">211000</a>	Mepair Nit for ONI16V Halve
<a href="#">2FIIBR</a>	Halve
<a href="#">Endschalter induktiv</a>	Oagnetspule
<a href="#">ON I1 6V 5B111P9</a>	Oodular valve
<a href="#">ON -1</a>	Emulsion
<a href="#">IPRI1V- FS0AV--1A11</a>	4KGE6K(U
<a href="#">2IRB01</a>	4olenoid Halve
<a href="#">2-7-0B</a>	2TH4HTO P1 Halve Mepair Nit
<a href="#">2TH4HTO P1 52-7-0B9</a>	Emulsion
<a href="#">O I-3ITUesina</a>	Oagnetspule
<a href="#">Oagnetspule O I-3ITUesina</a>	4olenoid Voil O I-3ITUesina
<a href="#">NA)11I01I.</a>	)ube suit to 2-7-0B S H4HTO P1
<a href="#">2-7FR-</a>	4olenoid Voil
<a href="#">2FI0F2</a>	4olenoid Voil
<a href="#">21RF27</a>	4olenoid Halve

























<b>Product</b>	<b>Description</b>
<a href="#">Z072-00059-99999</a>	VANE PUMP
<a href="#">CJT140-CA63B65N-AND-EM-20</a>	Hydraulic Cylinder
<a href="#">DSGL-01-3C2-D24-60</a>	Hydraulic valve
<a href="#">ZCT-03-B-10</a>	VALVE
<a href="#">FCG-01-4-1080</a>	Flow Control Valve
<a href="#">DSHG-04-3C3-51130</a>	VALF, DOGRUSAL, YON
<a href="#">LDS-50-20-1-0-P32-1308</a>	Direcional valve
<a href="#">LDS-50-05-1-D24-N-13</a>	Direcional valve
<a href="#">DSPG-03-C-D24-10</a>	Direcional valve
<a href="#">SVPF-12-70-B-20</a>	Variable displacement pump
<a href="#">PV2R14-19-200-L-RAAA-33</a>	pump
<a href="#">PV2R14-19-153-L-RAAA-33</a>	pump
<a href="#">PV2R2-26-L-RAA-41 (with foot)</a>	
<a href="#">PV2R2-26-F-RAA-41</a>	
<a href="#">YBG-02-C-10</a>	relief valve
<a href="#">A56-L-R-01-H-K-32388</a>	pump
<a href="#">MMC-01-3-4080</a>	
<a href="#">MBK-01-03-30</a>	
<a href="#">MPW-01-2-L-70</a>	Valve
<a href="#">MRP-01-B-30</a>	
<a href="#">MRA-01-C-30</a>	
<a href="#">MBK-01-04-30</a>	
<a href="#">VPSM-PSF0-9BR-20</a>	Pump
<a href="#">DSG-01-2B2-A100-N50</a>	
<a href="#">Connector for DSG-01-2B2-A100-N50</a>	
<a href="#">PV2R1-17-F-RAA-43</a>	hydraulic pump
<a href="#">PV2R2-41-F-RAA-43</a>	
<a href="#">A56-F-L-02-K-D24-3218</a>	Pump
<a href="#">260Y-010-02600 Type DSG-01-3C2-D12-N-70</a>	Valve
<a href="#">260Y-010-02650 Type DSG-01-3C2-D24-N-70</a>	Valve
<a href="#">260Y-010-02700 Type DSG-01-3C2-R200-N-70</a>	Valve
<a href="#">260Y-010-02750 Type DSG-01-3C2-A240-N-70</a>	Valve
<a href="#">DSG-03-2B2B-A100-70</a>	electrovalve
<a href="#">DSG-03-2B2-A100-70</a>	electrovalve
<a href="#">DSG-01-2B2-A100-70L</a>	electrovalve
<a href="#">EDG-01V-C-1-PNT15-50</a>	
<a href="#">VPVQQ-PSA0-06CA-06CA-60</a>	pump
<a href="#">PVR150-FF-110-RAA</a>	
<a href="#">DSG-01-3C2-D24-50</a>	
<a href="#">EDG-01V-A-1-PNT22-601349</a>	Valve
<a href="#">DSG-01-2D2-D24-70</a>	
<a href="#">DG-02-H-22</a>	Safety valve
<a href="#">AR22-FR01B-20</a>	mechanical seal
<a href="#">PV2R12-23-41-F-REAR-40-50 OEM</a>	pump
<a href="#">MRB-01-B-3019</a>	Valve



Product	Description
<a href="#">S-BG-06-L-40T270</a>	valve
<a href="#">DSGL-01-2B2-A110-N1-60</a>	valve + coils
<a href="#">DSG-01-3C4-A200-70</a>	
<a href="#">MRA-01-B-30</a>	
<a href="#">CIT-06-05-30T</a>	
<a href="#">CIT-10-35-30T</a>	
<a href="#">ELDFG-03EH-80-3C2-XY-C-D-10</a>	Proportional Hydraulic Valve
<a href="#">C-SA3-100-50</a>	Solenoid
<a href="#">VPSM-PSF0-16BR-20</a>	Pump
<a href="#">A110V (Coil for DSG-01-3C2-A110-50)</a>	SOLENOIDS
<a href="#">CJT140-FY63B55H-ABD-K 20</a>	Hydraulic cylinder
<a href="#">MRLP-03-1080</a>	over block pressure regulating valve
<a href="#">CPV2R1-17-R-43MY</a>	
<a href="#">KS-PV2R1-41</a>	
<a href="#">DSG-01-3C2-D24-N1-51T</a>	Hydraulic valve
<a href="#">CJT140-FY100B100N-BNB-</a>	
<a href="#">CJT140-FY160A80N-CND-EK-20</a>	
<a href="#">CJT140-FY40B30N-AND-K-20</a>	
<a href="#">CJT140-FY40B30N-BND-K-20</a>	
<a href="#">CJT140-FY40B30N-DNB-K-20</a>	
<a href="#">CJT140-FY40B25N-BND-K-20</a>	
<a href="#">Cylinder Block for A37-F-R-01-B-K-32</a>	Cylinder Block
<a href="#">Flat distributor for A37-F-R-01-B-K-32</a>	Flat distributor
<a href="#">Piston series for A37-F-R-01-B-K-32</a>	Piston series
<a href="#">PV2R34-76-136-FREAA-31</a>	Hydraulic pump
<a href="#">PVV-10-F-C-D-1080</a>	Vane pump
<a href="#">DSG-01-3C4-A100-60</a>	valve
<a href="#">CPDG-10-20-60</a>	VALVE; LOCK
<a href="#">SE1011-10</a>	Linear Servo Valve
<a href="#">S-DSG-03-3C12-D24-50PG13.5V</a>	Solenoid valve
<a href="#">S-DSG-03-2B2B-D24-50PG13.5V</a>	Solenoid valve
<a href="#">DSG01-3C2-D24-50PG13.5V</a>	Solenoid valve
<a href="#">DSG01-2B2-D24-50PG13.5V-L</a>	Solenoid valve
<a href="#">DSG-03-3C60-A240-N-50</a>	Solenoid valve
<a href="#">DSG-03-3C3-D24-N-50</a>	Hydraulic switchboard Cetop3
<a href="#">DSG-01-3C3-D24-N-70</a>	Solenoid valve
<a href="#">TC2G-01-40</a>	throttle
<a href="#">A10-FR01B-11</a>	pump
<a href="#">DSG-01-2D2-D24-50</a>	Valve
<a href="#">A10-FR01B-13</a>	Axial piston pump
<a href="#">M1-1,5-40</a>	Elektromotor
<a href="#">C-SA3-200-50</a>	coil for DSG-03-3C4-A200-50
<a href="#">MRP-03-H-70</a>	REDUCING MODULAR VALVE
<a href="#">MBB-03-H-30</a>	RELIEF MODULAR VALVE
<a href="#">DSLHG-04-1-E-A120-13</a>	Multi purpose valve



Product	Description
<a href="#">Type: EHFBG-06-250-C-5001</a>	Flow Control Valve
<a href="#">SE1013-ET-1321</a>	Servo valve
<a href="#">AR16-FR01C-22</a>	Axial piston pump
<a href="#">SVPF-30-55-20</a>	Pump
<a href="#">DSG-03-3C40-D24-N1-50</a>	
<a href="#">MSW-06-Y-30</a>	
<a href="#">MCA-01-2-30 C</a>	
<a href="#">BG-06-P-32</a>	PRESSURE RELIEF VALVE
<a href="#">DSG-03-2B2-D12-N-50</a>	directional valve
<a href="#">A37-L-R-01-C-K-32</a>	Foot monuted pump
<a href="#">CJT140-FY40B30N-BND-EK-20</a>	Piston
<a href="#">SK 1102 - 1I</a>	Linear Servo Amplifier
<a href="#">MCP-01-0-30</a>	Check Modular Valves
<a href="#">KS-MSW-01-50</a>	Spare part Kit for Trhottle check valves Code MSW-01-Y-50
<a href="#">SK1102-20T-AV-12</a>	Linear servo amplifier
<a href="#">DSG-01-3C2-D24-N-50</a>	valve
<a href="#">DSG-01-3C2-D24-N-70</a>	Hydraulic switchboard Cetop3
<a href="#">MPA-03-2-2001</a>	Hydraulic modular lock
<a href="#">DSHG-04-3C60 A240-N-52</a>	valve
<a href="#">CPG-10-04-50</a>	
<a href="#">MRA-03-H-20</a>	PRESSURE REDUCING MODULAR VALVE
<a href="#">MCP-03-2-10</a>	HYDRAULIC MODULAR CHECK VALVE
<a href="#">MRA-03-B-30</a>	valve Cetop5
<a href="#">MCB-03-0-20</a>	HYDRAULIC CHECK VALVE
<a href="#">MCA-03-0-20</a>	HYDRAULIC CHECK VALVE
<a href="#">MRA-03-H-30</a>	Valve
<a href="#">CPV2R2-41-R-41</a>	Cartridge
<a href="#">A110/60HZ</a>	
<a href="#">SVPF-20-70-20</a>	Hydraulic pump
<a href="#">DSG-01-3C60-A240-50</a>	valve
<a href="#">Coil for DSG-01-3C2-A240-N1-5</a>	coil
<a href="#">SK1102-10 old design, SK1102-12 new design</a>	Power amplifier
<a href="#">SE1014-ET-1301</a>	Servo Valve
<a href="#">EFBG-06250-0-1720</a>	valve
<a href="#">DSG-01-2D2-A100-70 (260Y-020-03552)</a>	magnetic valve
<a href="#">S-DSG-01-2B2-D24-N-70</a>	Solenoid valve
<a href="#">DSG-01-2B2-D24-N1-50-L</a>	SOLENOID DIRECTION VALVE
<a href="#">A90-FR04HAS-A-60366</a>	
<a href="#">DSG-01-3C2-A200-60</a>	VALVE
<a href="#">PVR1-8-F-RAA-43</a>	
<a href="#">PV2R12-25-65F-REAA-4222</a>	pump
<a href="#">Shaft for PV2R34-116-237-F-RHAR-31</a>	shaft
<a href="#">Cartidge for PV2R34-116-237-F-RHAR-31</a>	Cartidge
<a href="#">PV2R4-184-F-RAA-30</a>	Vane Pump
<a href="#">DSG-01-2B2-A240-N1-50</a>	SOLENOID VALVE



Product	Description
<a href="#">DSG-01-3C2-A240-N1-50</a>	
<a href="#">DSG-01-3C4-A240-N1-70 (052336)</a>	
<a href="#">CDSG-03-C-D24-21</a>	hydraulic valve
<a href="#">MPB-01-2-4001</a>	hydraulic valve
<a href="#">CDST-03-C-D24-21</a>	00Solenoid operated poppet type
<a href="#">CDSC-03-C-D24-21</a>	00Solenoid operated poppet typy
<a href="#">PV2R1-8-F-RAA-43</a>	Vane pump
<a href="#">DSG-03-3C4-A240-50</a>	Cetop 5 hydraulic switchboard
<a href="#">DSG-01-2B3B-D24-N1-70</a>	Hydraulic switchboard Cetop3
<a href="#">BSG-06-2B3B-A120-48</a>	
<a href="#">DSHG-04-2B2-E-A100-52</a>	
<a href="#">SVPF-12-70-20</a>	Pump
<a href="#">MRA-03-B-20</a>	
<a href="#">DSG-03-3C4-A100-N-50</a>	
<a href="#">DSG-01-2B2-A240-N-70</a>	
<a href="#">PV2R1-14-F-RAA-41</a>	pump
<a href="#">S-DSG-01-3C4-D24-70</a>	Directional Valve
<a href="#">PV2R12-10-47-F-R-EAA-42</a>	
<a href="#">EFBG-03-125-H-20T350</a>	Proportional valve - special
<a href="#">Coil for DSG-01-2D2-A100-50</a>	Coil
<a href="#">ML1-0.75-10</a>	Elektromotor ML Series
<a href="#">DSG-01-2B2-A120-70</a>	Directional Valve
<a href="#">EFBG-03-125C-20T233-L</a>	PROPORTIONAL BLOCK
<a href="#">S-BSG-03-2B2-D24-N1-51</a>	hydraulic distributor
<a href="#">DSHG-04-3C2-T-D24-N1-50</a>	hydraulic distributor
<a href="#">S-BSG-06-2B3B-D24-N-51</a>	hydraulic divider
<a href="#">DSG-01-3C2-D24-7090</a>	
<a href="#">EFBG-03-125-H-17</a>	flow control + relief valve
<a href="#">PV2R2-47-F-RAA-41</a>	Single Vane Pump
<a href="#">PM10-01B-0.75-3019</a>	PAL Pumps, pressure
<a href="#">PV2R2-33-F-RAA-41</a>	pump
<a href="#">DSGL-01-3C2-D24-N1-60</a>	solenoid valve
<a href="#">CPG-03-20-50</a>	PILOT CONTROLLED CHECK VALVE
<a href="#">F-DSHG-06-3C2-C1-C2-D24-N1-53</a>	electrohydraulic switchboard + C1 + C2 +
<a href="#">MRP-06-C-70</a>	Cetop8 pressure reducing valve
<a href="#">L-DSG-01-3C4-D24-70</a>	Directional valve
<a href="#">C-L-SD1-24-70</a>	D24 Coil for terminal block
<a href="#">L-DSG-01-3C4-D24-N-7</a>	Directional valve
<a href="#">C-L-SD1-24-N-70</a>	D24 Coil for terminal block
<a href="#">Piston shoes for A145 FR04HS-60</a>	
<a href="#">DSG-01-3C60-A240-N-70</a>	Hydraulic switchboard Cetop3
<a href="#">PV2R13-19-76-F-RBAA-43</a>	Vane pump
<a href="#">PV2R12-17-53-F-REAA-42</a>	Vane pump
<a href="#">PV2R14-23-153-F-RAAA-42</a>	Vane pump
<a href="#">EDG-01V-H-1-PNT11-5115-R</a>	Proportional E-H Pilot Relief Valve



<b>Product</b>	<b>Description</b>
<a href="#">MPW_01_4_40</a>	Valve
<a href="#">MFW-01-Y-10</a>	VALVE
<a href="#">MPW-01-4-4001</a>	
<a href="#">SE1014-E-1301</a>	
<a href="#">SB1166-R-03-140--4-76-1205</a>	Control Valve
<a href="#">SK1102-12</a>	Linear servo amplifier
<a href="#">DSHG-06-3C40-T-A100-52</a>	Direction control valve
<a href="#">DSG-01-3C12-A100-70</a>	Direction control valve
<a href="#">DSHG-06-3C4-T-A100-52</a>	Direction control valve
<a href="#">DSHG-04-3C10-T-A100-51</a>	Direction control valve
<a href="#">DSG-03-2B2B-A100-50</a>	Direction control valve
<a href="#">DSHG-06-2B2-T-A100-52</a>	Direction control valve
<a href="#">DSHG-06-3C10-T-A100-52</a>	Direction control valve
<a href="#">MPW-01-2-30</a>	PILOT CHECK VALVE
<a href="#">PV2R34-116-237-F-REAA-35</a>	
<a href="#">ERBG-06-H-5111</a>	Special valve
<a href="#">DSG-01-2B2A-D24-N1-70-L</a>	
<a href="#">DSG-01-3C2-A100-60</a>	solenoid valve
<a href="#">ERBG-06-H-5011</a>	PILOT CHECK VALVE
<a href="#">EDG-01V-B-1-PNT22-5119</a>	SOLENOID VALVE
<a href="#">S-PV2R34-116-237-F-REAA-35</a>	pump
<a href="#">PV2R1-23-F-RAA-42</a>	
<a href="#">DSG-01-2B2-A220-51T</a>	valve
<a href="#">DSG-01-2B2-A240-70</a>	
<a href="#">HG-10-B4-22</a>	Safety valve
<a href="#">S-BSG-06-V-2B2B-D24-5206</a>	RELIEF VALVE
<a href="#">260Y-020-03650 (DSG-01-3C9-D24-70)</a>	directional valve
<a href="#">EFBG-06-250-C-20</a>	valve
<a href="#">CRG-06-04-50</a>	
<a href="#">HG-06-B4-22</a>	sequential valve with bypass
<a href="#">BSG-06-2B3B-D24-N1-48</a>	Safety valve with relief
<a href="#">CRG-06-04-50T</a>	
<a href="#">FG-01-4-N-11</a>	Throttle valve with stabilization
<a href="#">DSG-01-3C4-D24-60</a>	valve
<a href="#">CPG-06-35-50</a>	PILOT OPERATED CHECK VALVE
<a href="#">MSW-01-X-70</a>	Throttling intermediate plate Cetop3
<a href="#">DSG-01-2B2-A100-N1-70</a>	
<a href="#">DSG-01-3C4-A100-N1-70</a>	
<a href="#">MBA-01-C-70</a>	valve
<a href="#">MBA-03-B-30</a>	
<a href="#">PV2R2-41-F-RAA-41</a>	Vane pump
<a href="#">DHG-06-3C9-51</a>	Valve
<a href="#">DSG-01-2D2-D24-N1-50</a>	
<a href="#">DSG-01-2D2-D24-N1-70</a>	
<a href="#">A90-LR01CS-60</a>	



Product	Description
<a href="#">A37-L-R-01-B-K-32</a>	
<a href="#">VPSM-PSFO-9AR-20</a>	Vane pump
<a href="#">DSG-01-2D2-D24-N-70</a>	Hydraulic switchboard Cetop3
<a href="#">DSG-01-3C3-A240-N-70</a>	Hydraulic switchboard Cetop3
<a href="#">DSG-01-2B2B-D24-N-70</a>	Hydraulic switchboard Cetop3
<a href="#">MRA-01-H-30</a>	Modular pressure reducing valve Cetop3
<a href="#">PVR1T-6-FRA-2080</a>	
<a href="#">PV2R1-6-F-RAA-43</a>	
<a href="#">ARL1-12-FR01S-10</a>	Pump
<a href="#">MBR-01-C-30</a>	
<a href="#">MSW-01-Y-30</a>	
<a href="#">SO-NA-P9</a>	O-Ring (NBR)
<a href="#">PV2R1-25-F-RAA-43</a>	Vane pump
<a href="#">PV2R1-12-F-RAA-42</a>	Vane pump
<a href="#">A10-FR01B-1322</a>	Axial piston pump
<a href="#">Z122-00048-99999 KS-CJT80C-20</a>	gasket set
<a href="#">DSG-01-3C40-D24-70</a>	
<a href="#">PV2R3-116-F-RAA-31</a>	Vane pump
<a href="#">MBP-01-H-70</a>	
<a href="#">A100</a>	Coil
<a href="#">DSG-03-3C2-D24-N1-50</a>	Hydraulic distributor Cetop5
<a href="#">KS-PV2R34-31</a>	Seal kit
<a href="#">CPV2R33-116-L-31</a>	Cartridge
<a href="#">CPV2R34-237-R-30</a>	Cartridge
<a href="#">MRP-01-A-7042</a>	
<a href="#">DSG-01-2B2-A100-7006-L</a>	
<a href="#">A3H56-FR01KK-10</a>	pump
<a href="#">A3H145-LR01KK-10-1112</a>	Pump
<a href="#">DSHG-06-2B2-T-D125-5359</a>	valve
<a href="#">DSG-01-3C2-A240-N-70</a>	Hydraulic switchboard Cetop3
<a href="#">BSG-06-2B3A-D24-N146</a>	
<a href="#">DSGL-01-3C12-A110-51T</a>	valve
<a href="#">PV2R3-76-F-RAA-31</a>	PUMP
<a href="#">DSG-01-2B2-A100-N-70</a>	
<a href="#">C-SA1-100-N-70</a>	
<a href="#">PV2R2-53-F-RAA-41</a>	pump
<a href="#">repair kit for CJT140-FY160A80N-CND-EK-20</a>	
<a href="#">072-120-02400</a>	vane pump
<a href="#">PG1-109-P-1-P-B-R-3080</a>	gear pump
<a href="#">old pn PV2R1-F-RAA-40 / new pn PV2R1-31-F-RAA-43</a>	pump
<a href="#">DSG-03-3C4-D100-50</a>	solenoid valve
<a href="#">DSG-03-3C2-A220-51T</a>	
<a href="#">DSG-01-3C2-A220-51T</a>	
<a href="#">PV2R1-31-F-RAA-43</a>	vane pump
<a href="#">T-DSG-03-3C40-D24-50310</a>	



Product	Description
<a href="#">PV2R12-31-41-F-RELR-43</a>	
<a href="#">DSG-01-2B2-D24-70185</a>	VALVE, SOLENOID
<a href="#">DSG-03-2B8-D24-50</a>	
<a href="#">CPG-06-E-35-50</a>	
<a href="#">CRG-06-50-50</a>	Hydraulic distributor Cetop5
<a href="#">PV2R23-65-94-F-REAA-41</a>	pump
<a href="#">DSGL-01-2D2-D24-N1-60T</a>	directional valve
<a href="#">DGS-03-3C3-D24-N-50</a>	hydraulic valve yuken directional valve.
<a href="#">PV2R23-41-116-F-REAA-41</a>	vane pump
<a href="#">PV2R23-47-116-F-REAA-41</a>	Vane pump
<a href="#">A37-F-R-07-K-32</a>	Variable displacement axial piston pump with pressure regulator 37cc clockwise
<a href="#">CA37-R-30</a>	Cartridge to pump A37-F-R-07-K-32
<a href="#">DSHG-06-3C40-T-RB-A240-5127</a>	VALVE
<a href="#">DSHG-03-3C10-E-D24-12</a>	
<a href="#">DSHG-03-3C10-E-D24-14</a>	
<a href="#">LD-16-05-S-1-X05-12</a>	Directional and flow logic valve
<a href="#">MPA-01-2-40</a>	valve
<a href="#">DSG-01-2B3B-D24-51T</a>	Valve
<a href="#">DSG-01-2B3B-D24-70</a>	
<a href="#">A3HG145-FR01KK-E1D-10</a>	
<a href="#">MPA-01-2-L-70</a>	Hydraulic lock mod. Cetop3
<a href="#">T-DSG-01-2B2-D24-70207</a>	Valve
<a href="#">PV2R12-8-41-L-REAA-41</a>	PUMP
<a href="#">DSG-03-3C3-A240-N-50</a>	
<a href="#">PV2R2-33-F-RA-41</a>	
<a href="#">DSG-03-2D2-D220-4035</a>	Solenoid Operated Directional Valves
<a href="#">BG-03-P-32</a>	
<a href="#">CJT140L-FF50B220B-ABD-EKX11-20</a>	
<a href="#">YBG-01-250-1080H01</a>	
<a href="#">ERG-01-1113</a>	ERG Valve
<a href="#">MPW-06-4-70</a>	
<a href="#">CIT-02-04-5080</a>	Reverse throttle valve
<a href="#">MSTW-01-X-10</a>	
<a href="#">DSG-01-3C60-D24-N1-70</a>	
<a href="#">MSW-01-Y-70</a>	
<a href="#">DSG-03-2D2-A100-N1-50</a>	valve
<a href="#">ARL1-8-FR01A-10</a>	pump
<a href="#">MBK-01-01-70</a>	Stud Set
<a href="#">DSGM-01Y-31</a>	Plate
<a href="#">LSVG-01EH-10-W-C-A1-10</a>	Servo Valve
<a href="#">DSG-03-2B2-A100-5090</a>	Directional Valve
<a href="#">DSG-03-2B2-A100-5090 American Design</a>	
<a href="#">DSG-03-2B2-A100-50 Japanese Design</a>	
<a href="#">F-MRP-03-H-70</a>	PRESSURE SAFETY VALVE



<b>Product</b>	<b>Description</b>
<a href="#">F-MBW-03-C-70</a>	PRESSURE SAFETY VALVE
<a href="#">F-DSG-01-3C4-D24-N1-70</a>	DIRECTIONAL CONTROL VALVE 3/4
<a href="#">F-DSG-01-2B3-D24-N1-70</a>	DIRECTIONAL CONTROL VALVE 2/3
<a href="#">F-CRG-06-04-50</a>	CHECK VALVE
<a href="#">F-CPDG-06-E-20-50</a>	Pilot Alerted Check Valve
<a href="#">F-S-BSG-03-2B3A-D24-N1-L-53</a>	SELENOID CONTROLLED PRESSURE SAFETY VALVE
<a href="#">F-MSW-01-X-70</a>	PILOT WARNING CHECK VALVE
<a href="#">F-DSG-03-3C4-D24-N1-51</a>	
<a href="#">F-MPW-01-2-L-70</a>	
<a href="#">PV2R12-6-59-F-REAA-43</a>	
<a href="#">PV2R12-31-33-F-REAA-43</a>	
<a href="#">PV2R3-76-L-RAR-31</a>	
<a href="#">PV2R3-94-L-RLR-31</a>	
<a href="#">PV2R3-116-L-RRL-31</a>	
<a href="#">PV2R24-26-153-L-RLLR-31</a>	
<a href="#">PV2R4-200-L-RLR-31</a>	
<a href="#">PV2R4-200-L-LLR-31</a>	
<a href="#">DSG-01-2D2-A120-70</a>	
<a href="#">MPW-03-2-L-70</a>	Hydraulic Valve
<a href="#">DSG-01-2B3-A240-N-70</a>	valve
<a href="#">PV2R1-8-F-REA-43-MY</a>	
<a href="#">KS-DSG-01-70</a>	Seal Kit
<a href="#">PV2R2-65-F-RAB-41</a>	VANE PUMP
<a href="#">A37-L-R-05-CH-S-K-32</a>	Pump
<a href="#">A37-F-R-01-C-K-32</a>	PUMP
<a href="#">DSG-03-3C2-A240-50</a>	Hydraulic distributor Cetop5
<a href="#">PV2R4-153-F-RAA-30-MY</a>	Pump
<a href="#">F-MSW-03-X-70</a>	
<a href="#">L-DSG-01-2B3-D24-70</a>	VALVE
<a href="#">F-MSW-03-X-40</a>	
<a href="#">DSG-03-2B3-A220</a>	
<a href="#">DSHG-06-3C5-A220</a>	
<a href="#">MRP-01-C-30</a>	Hydraulic Valve
<a href="#">CJT140-CB40B520B-BCD-EK-20</a>	Hydraulic cylinder
<a href="#">CPDG-03-20-50</a>	
<a href="#">MCP-01-0-70</a>	Valve
<a href="#">CJT140-FY63C80N-BND-EK</a>	HYDRAULIC CYLINDER
<a href="#">KS-AR16-01-22</a>	Seal kit
<a href="#">MAC-01-30</a>	suction plate
<a href="#">ARL1-16-FR01S-10</a>	
<a href="#">PV2R23-47-94-F-REAA-41</a>	
<a href="#">PV2R12-23-47-F-REAA-43-MY</a>	
<a href="#">PV2R12-23-47-F-REAA-43</a>	Vane pump
<a href="#">EDG-01V-C-1-P18T17-5103</a>	
<a href="#">DSG-01-2D2-A200-70</a>	



Product	Description
<a href="#">M-VPV1-15-35-0.7.5-10</a>	
<a href="#">DSHG-06-2N2-C2-T-A120-52</a>	
<a href="#">CPG-10-E-50-50</a>	PILOT-OPERATED CHECK VALVE
<a href="#">A-BSG-10-2B3B-D24-N-47</a>	
<a href="#">A-BSG-10-2B3B-D24-N-48</a>	Solenoid Controlled Relief Valve
<a href="#">MRP-03-H-30</a>	
<a href="#">MSW-04-X-10MY</a>	
<a href="#">SB-1039-A-10</a>	
<a href="#">DSHG-04-3C4-T-D24-52</a>	
<a href="#">MDS-01-PB-30 MY</a>	
<a href="#">MHB-01-H-3016 MY</a>	counterbalance Modular valve
<a href="#">MRA-04-C-10MY</a>	
<a href="#">MRP-01-C-70</a>	
<a href="#">MBB-01-H-70</a>	
<a href="#">ZCT-10-T-22</a>	
<a href="#">MRP-06-B-70</a>	
<a href="#">MAC-03-10</a>	
<a href="#">DSHG-10-3C4-T-D24-43</a>	
<a href="#">DSHG-06-2N2-T-D24-53</a>	
<a href="#">MRP-10-H-30</a>	
<a href="#">MRP-04-C-10</a>	
<a href="#">MPW-10-4-30</a>	
<a href="#">MRP-04-B-10</a>	
<a href="#">MRP-01-B-70</a>	
<a href="#">AR22-FR01B-20</a>	Pump
<a href="#">MPW-03-4-L-70</a>	
<a href="#">CJT140-FY63C80N-BND-EK 20</a>	Hydraulic cylinder
<a href="#">MRA-01-B-7004</a>	pressure reducing valve
<a href="#">DSG-03-2D2-A120-N1-50</a>	3/8 Solenoid Operated Directional Valves, DSG-03 Series
<a href="#">pressure relief valve for A37-F-R-01-B-K-32</a>	
<a href="#">A70-LR09AS-60</a>	Hydraulic Pump
<a href="#">A56-F-R-01-H-K-32 EC:8413506190</a>	
<a href="#">GCT-02-3280</a>	
<a href="#">EDG-01-V-H-1-PNT20-5197</a>	
<a href="#">EFBG-10-1000-H-51</a>	
<a href="#">Z061-00055-99999</a>	
<a href="#">Z00A05962</a>	HYDRAULIC CYLINDER CJT140-FF63
<a href="#">DSG-01-2D2-A100-N-70</a>	
<a href="#">DSG-01-3C4-A100-N-70</a>	
<a href="#">PV2R4-136-F-RAA-30</a>	Pump
<a href="#">PV2R4-136-F-RAA-30-MY</a>	
<a href="#">PV2R12-23-41-F-REAA-41</a>	
<a href="#">Z00A06132</a>	SOLENOID VALVE
<a href="#">DSHG10-3C40-C1-C2-T-D220</a>	
<a href="#">PV2R4-200-F-RAA-30-MY</a>	hydraulic pump



Product	Description
<a href="#">PV2R4-200-F-RAA-30</a>	
<a href="#">MBK-01-03-70</a>	
<a href="#">MBK-01-02-70</a>	
<a href="#">DSG-01-2B4B-D24-N1-70L EC:8481201090</a>	
<a href="#">MBA-01-K-70 EC:8481201090</a>	
<a href="#">DSHG-04-3C12-T-D24-N1-51 EC:8481201090</a>	
<a href="#">DSG-03-2B2B-D24-N1-50 EC:8481201090</a>	
<a href="#">DSG-01-2B2B-D24-70 EC:8481201090</a>	
<a href="#">DSG-03-3C4-D24-N1-50 EC:8481201090</a>	
<a href="#">DSG-01-2B2-D24-N1-70 EC:8481201090</a>	
<a href="#">FCG-02-30-30 EC:8481201090</a>	
<a href="#">YA16-B-2-2.2-50</a>	Hydraulic unit for LEG3/HS shifter
<a href="#">PV2R12-31-59-L-REAA-43MY</a>	
<a href="#">PV2R12-31-65-F-REAA-43-MY</a>	
<a href="#">FG-06-250-30</a>	VALVE, FLOW CONTROL YUKEN
<a href="#">EFBG-03-125-H-15</a>	
<a href="#">LD80-20-S-1-X50-11</a>	Valve
<a href="#">MSW-06-Y-70 MY</a>	
<a href="#">MRA-06-C-70</a>	Reducing valve Cetop8
<a href="#">DSG-03-3C3-A220-51T</a>	
<a href="#">D36-01-3C60-D24-N-70</a>	
<a href="#">PV2R2-53-L-RAA-41-MY</a>	
<a href="#">PV2R4-136-L-RAA-30-MY</a>	
<a href="#">CPV2R4-136-R-30MY</a>	
<a href="#">C193-PK310629-1</a>	
<a href="#">M3-5.5-380-A-4010</a>	
<a href="#">PV2R34-116-237-F-RHAR-31</a>	
<a href="#">A3H180-RO1KK-10</a>	Hydraulic Piston Pump
<a href="#">DSG-03-2B8-D24-N-50</a>	Distributor
<a href="#">DCG-03-2B2-5020</a>	
<a href="#">DSHG-06-3C40-T-D24-N1-51</a>	
<a href="#">DSHG-06-3C40-T-D24-N1-5165</a>	
<a href="#">DSHG-06-3C40-T-D24-N1-5365</a>	
<a href="#">EDFHG-06-280-C340-XY-31</a>	
<a href="#">DSG-03-3C3-D24-N1-50</a>	Valve
<a href="#">PV2R2-41-L-RAA-41</a>	
<a href="#">MSP-01-50</a>	MODULAR VALVE
<a href="#">DSG-03-3C40-R24Y13</a>	VALVE
<a href="#">DSG-01-3C40-R24Y13</a>	VALVE
<a href="#">SRCG-03-50</a>	VALVE
<a href="#">DSHG-06-3C40-C1C2-T-R24Y13</a>	VALVE
<a href="#">MCP-03-2-70</a>	
<a href="#">DSG-01-2B2-D24-N1-50</a>	
<a href="#">MPW 06-2-70 V37</a>	check valve



Product	Description
<a href="#">DSG-01-2D2-D24X1-70</a>	Explosion Proof (Flameproof) Solenoid Operated Directional Valves DSG-01-***-X*-70
<a href="#">BSG-03-2B3B-A240-N1-4780</a>	Solenoid Operated Directional Valves
<a href="#">A56-L-R-01-C-K-32115</a>	PISTON PUMP
<a href="#">SB1211-06-28-10</a>	REGULATOR VALVE
<a href="#">FG-02-30-N-30</a>	
<a href="#">A90-LR04E21MA-60-70</a>	
<a href="#">DSHG-06-3C2-D24-51</a>	
<a href="#">DSHG-06-3C2-D24-53</a>	
<a href="#">M1-2.2-41</a>	Motor
<a href="#">DSG-03-3C40-A120-N1-50</a>	
<a href="#">DSG-03-3C4-A220-51T</a>	Hydraulic Electric Valve
<a href="#">MSW-03-X-30</a>	Hydraulic Electric Valve
<a href="#">PV2R12-31-47-F-REAA-43</a>	PUMP
<a href="#">EDG-01V-C-PNT13-60T</a>	
<a href="#">EFBG-03-125A-C-20T233-L</a>	
<a href="#">A56-LL-01-H-S-K-32</a>	
<a href="#">A3H71-LR01-KK-10</a>	
<a href="#">DMG-03-3D4-50</a>	DIRECTIONAL VALVE
<a href="#">MPW-03-02-10</a>	PILOT OPERATED CHECK VALVE
<a href="#">50T-26-1-RL-30</a>	
<a href="#">50T-26-L-RL-30</a>	
<a href="#">CPG-10E-30-20</a>	
<a href="#">CPG-10-30-20</a>	
<a href="#">DSG-03-3C2-D24-NI-50</a>	
<a href="#">DSG-03-3C2-D24-N1-71</a>	ELECTROMAGNETIC DIRECTIONAL VALVE
<a href="#">BSG-06-2B3B-D24-N-48</a>	ELECTRAMAGNETIC RELAY VALVE
<a href="#">GLC3-6</a>	COOLING UNIT
<a href="#">GLC3-4</a>	COOLING UNIT
<a href="#">PV2R23-47-94-F-REAA-43</a>	
<a href="#">PV2R1-17-F-RAAA-43</a>	vane pump
<a href="#">PV2R12-23-47-F-REAA-41</a>	double vane pump
<a href="#">DSG-03-3C2-D24-N1-51T</a>	electromagnetic directional valve
<a href="#">CJT140-FY40B25N-BND-EK 20</a>	hydraulic cylinder
<a href="#">DSG-03-2D2-D24-N-50</a>	
<a href="#">DSG-03-3C60-D24-N1-50</a>	Solenoid valve
<a href="#">L-DSG-01-2B2-D24-70</a>	SOLENOID VALVE
<a href="#">EDG-01V-A-PNT22-61T234</a>	
<a href="#">PV2R12-8-33-RFAL-43</a>	
<a href="#">A90-FR07S-60</a>	axial piston variable pump
<a href="#">MRA-03-C-70</a>	pressure reducing valve
<a href="#">CJT140L-LB63B1475B-DAB-EKY59-20</a>	ø36/63 hydraulic cylinder
<a href="#">MSB-06-X-70</a>	
<a href="#">DSG-01-3C4-A100</a>	SELENOID VALVE
<a href="#">DSG-01-3C2-A100</a>	



Product	Description
<a href="#">DSG-01-2B4B-A100</a>	
<a href="#">MPW-01-2-70</a>	
<a href="#">MRP-10-B-10</a>	
<a href="#">MRP-10-B-30</a>	
<a href="#">SRCF-10-50</a>	
<a href="#">SRCF-16-50</a>	
<a href="#">F-DSG-03-3C2-A200-N</a>	4/3-way slide valve
<a href="#">PV2R34-94-184-F-RGAL-31</a>	Vane pump
<a href="#">PV2R34-94-237-F-RGAL-31</a>	Vane pump
<a href="#">DSG-03-3C3-A220-50</a>	
<a href="#">EDG-01V-H-1-PNT10-60T</a>	,
<a href="#">EDG-01V-H-1-PNT10-61T</a>	,
<a href="#">DSG-03-3C60-A220-N1-50</a>	VALVE
<a href="#">DSG-03-2B2-R220-N1-50</a>	DIRECTIONAL CONTROL VALVE
<a href="#">AMN-D-20T</a>	Proportional Electro-Hydraulic Control Board
<a href="#">AR-16-FR01C</a>	Hydraulic Pump
<a href="#">DSG-01-3C2-A120-7090</a>	Directional Valve
<a href="#">PV2R2-65/RBF1</a>	
<a href="#">PV2R3-84/RBF1</a>	HYDRAULIC PUMP
<a href="#">S-BSG-06-3C3-D24-N1-L</a>	HYDRAULIC SOLENOID OPERATED VALVE
<a href="#">EBG-06-H-60T</a>	ELECTRO HYDRAULIC RELIEF VALVE
<a href="#">EBG-06-H-61T</a>	ELECTRO HYDRAULIC RELIEF VALVE
<a href="#">MSA-06-Y-70</a>	
<a href="#">F-DSG-01-2B2-A240-70"</a>	Hydraulic distributor Cetop
<a href="#">1HP4P20L</a>	
<a href="#">EDG-01V-A-1-PNT22-61T234</a>	
<a href="#">MHA-01-C-70</a>	Modular control valve with bypass
<a href="#">ML1-1,5-10</a>	Elektromotor ML Series
<a href="#">PV2R1-14-F-RAA-43</a>	PUMP
<a href="#">PV2R1-14-F-RAA-42</a>	Vane pump
<a href="#">MPB-04-2-10</a>	
<a href="#">SVPF-20-35-20</a>	Pump
<a href="#">DCT-03-2B2-50</a>	
<a href="#">DSHG-06-2B2-C1C2-A120-51</a>	
<a href="#">MRP-01-H-70</a>	
<a href="#">DSHG-06-2B2-C1C2-A120-N-53</a>	Valve
<a href="#">DSHG-06-2N2-C2-T-A120-53</a>	Valve
<a href="#">DSHG-06-3C40-C1C2-T-A100-52</a>	SELENOID OPERATED DIRECTIONAL VALVE
<a href="#">MPW-06-4-10</a>	PILOT OPERATED CHECK VALVE
<a href="#">DSHG-06-3C2-C1C2-T-A100-52</a>	PILOT OPERATED DIRECTIONAL VALVE
<a href="#">DSHG-06-3C40-C1C2-T-A120-51</a>	DIRECTION VALVE
<a href="#">A10-FR01B-1222</a>	Piston pump
<a href="#">DSG-01-2D2-D24-N-50 (24V)</a>	
<a href="#">DSG-03-3C12-D24-50</a>	valve
<a href="#">MPW-03-4-2021</a>	



Product	Description
<a href="#">DSHG-04-3C3-D24-N-52</a>	Valve
<a href="#">DSHG-04-3C3-D24-N1-50</a>	
<a href="#">DSHG-04-3C3-D24-N1-52</a>	Valve
<a href="#">DSG-01-2B3B-A120-N-70</a>	
<a href="#">DSG-01-2B2-A120-N-70</a>	
<a href="#">MRB-03-H-70</a>	Redukční ventil Cetop5
<a href="#">DSG-01-2D2-N1-D24-50</a>	
<a href="#">DSHG-06-3C40-D24-N1-50</a>	
<a href="#">MPB-03-2-L-70</a>	
<a href="#">DSG-03-2B2-A220-50</a>	
<a href="#">DSG-03-3C2-A110-51T</a>	
<a href="#">DSG-03-3C2-A120-50</a>	valve with coils
<a href="#">F-MPA-03-2-70</a>	Check Valve
<a href="#">MRB-01-H-70</a>	
<a href="#">MRB-01-H-30</a>	
<a href="#">S-DSG-01-3C4-D24-50</a>	
<a href="#">ELDFG-03EH-80-3C2L-XY-C-D-10</a>	Proportional valve
<a href="#">VPSM-PSF0-9BR-20 + M1-0.75-L-3033</a>	
<a href="#">DSLHG-06-3-D24-13</a>	Multi purpose control valve
<a href="#">BSG-03-2B3B-D24-N1-46</a>	
<a href="#">BSG-03 YCENNJO2809</a>	
<a href="#">PV2R1-19-F-R</a>	Vane pump
<a href="#">EFBG-10-500-C-1721+ EDG-01V-C-1-P18T17-5103</a>	
<a href="#">BSG-10-2B3B-A220-46</a>	
<a href="#">A10-FR07-13</a>	pump
<a href="#">SK1102-A30 BV-12147</a>	Amplifier
<a href="#">E-DSG-01-3C2-D24-70</a>	Valve
<a href="#">MSW-03-Y-70</a>	valve
<a href="#">seal kit for A145-FR04HS-60</a>	
<a href="#">DMG-01-3D4-10</a>	directional valve
<a href="#">EFBGM-03Y-1080</a>	
<a href="#">MCP-01-2-70</a>	valve
<a href="#">MSB-01-X-50</a>	valve
<a href="#">DSLHG-04-1-A100-N-13</a>	Multi purpose valve