



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)



## Finetek

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">BVP-30S</a>	Air Hammer (Impact Model)
<a href="#">Original model: CSE110EDRS (Order code: SEX10000-AAEAAA803S0100T01)</a>	ROTARY PADDLE LEVEL SWITCH
<a href="#">EC1300FX1100</a>	TRANSMITTER
<a href="#">EFB-1250</a>	magnetic switch
<a href="#">EFB-1400 / EFXCM1P-18S4420001</a>	Magnetic switch for EF series
<a href="#">PB-1471-T024121</a>	Panel Meter Display
<a href="#">SC2100R0DQ / SUS304</a>	Vibrating Probe Level Switch
<a href="#">p/n: SEX50000-AABAAA803B0100 type: SE110B</a>	rotary paddle level switch
<a href="#">SE255EERF</a>	Rotary Paddle Level Switch
<a href="#">SE3800BCRI1000</a>	Rotary Paddle Level Switch
<a href="#">SP200-L-DU-P-0 // SPX10000-AACA807MCB0040</a>	switch
<a href="#">SP201-6-BT-A-2-65</a>	Thermal Dispersion Flow Switch
<a href="#">SE3800ECRH3000</a>	Rotary Paddle Level Switch
<a href="#">BVR-100</a>	Pneumatic Roller Vibrator
<a href="#">SE3800DCRG1000</a>	Rotary Paddle Level Switch
<a href="#">SE3800BCRG3000</a>	rotary paddle level switch
<a href="#">FD3601DB15TH</a>	Mini Float Level Switch
<a href="#">FDBEM3S220235</a>	Magnetic Float Level Switch
<a href="#">FDBEM3S210200</a>	Magnetic Float Level Switch
<a href="#">SE110CEUA0500</a>	Level Switch
<a href="#">PT7620-S11100</a>	Temperature Controller
<a href="#">SE3800BCRI0300</a>	Rotary Paddle Level Switch
<a href="#">FD5001DD05X</a>	Flow Sensor
<a href="#">EFB-14</a>	2-pipe fan coil
<a href="#">SE3800EERF0500</a>	Rotary Paddle Level Switch
<a href="#">SE3802DCRG3000</a>	Rotary Paddle Level Switch
<a href="#">SE110BDRA0105</a>	Rotary Paddle Level Switch
<a href="#">SE3820DCRG1500</a>	Rotary Paddle Level Switch
<a href="#">SA130BEN0500</a>	Capacitance Level Switch
<a href="#">SC28000-DCQ</a>	Level Controller
<a href="#">Model: SE290BERH0500 / SEX40000-CABAAB103H0500</a>	Rotary Paddle Level Switch (Mini Type)
<a href="#">SE280B</a>	Rotary Paddle Level Switch
<a href="#">AA2030</a>	Air Hammer
<a href="#">PT-7620T1010-0</a>	Pressure Transmitter
<a href="#">PT7620-S441-00</a>	PT tempeature controller



<b>Product</b>	<b>Description</b>
<a href="#">SE3800ECRG3000</a>	Rotary Paddle Level Switch
<a href="#">SC281L0DCQ</a>	Fork Sensor
<a href="#">BAH-40</a>	Air Hammer
<a href="#">SE3820DCRG3000</a>	Rotary Paddle Level Switch
<a href="#">SE3800DCRG3000</a>	Rotary Paddle Level Switch
<a href="#">FF90CLO-6</a>	Side Mounting Float Level Switch
<a href="#">SC350C00EU1020XX</a>	Tuning Fork Level Switch
<a href="#">PB-1471-T010000 / PBX11400-B6BA100AAAA</a>	Microprocessor bar graph display panel meter
<a href="#">FCH11QD</a>	Flow Switch
<a href="#">SE3810ECRH3000+TB</a>	Rotary Paddle Level Switch
<a href="#">SP200-6-BR-P-5</a>	THERMAL DISPERSION FLOW SWITCH
<a href="#">SE250E.CRH3000</a>	Level sensor
<a href="#">SE3800ACRG3000</a>	Rotary paddle level switch
<a href="#">FF20CLO</a>	Side mount level switch
<a href="#">FD3501DE</a>	Float switch
<a href="#">FD7DDRAS120400A</a>	Flow Meter
<a href="#">SE3815ECRI0150</a>	ROTARY PADDLE LEVEL SWITCH
<a href="#">EFB-1420</a>	Magnetic Switch
<a href="#">SC2110R6ET0300L</a>	Vibrating Fork Level Switch
<a href="#">PT-7620-S111-10</a>	temperature controller
<a href="#">SE3815DCRI5000+TA</a>	Rotary Paddle Level Switch
<a href="#">EGS152-AF1010-115</a>	Pressure Transmitter
<a href="#">SE3810BCRG3000</a>	Rotary Paddle Level Switch
<a href="#">SC24100-DDR+TB</a>	switch
<a href="#">FA-CC05</a>	Cable Float Level Sensor
<a href="#">SB1720</a>	RF Capacitance Admittance Level Switch
<a href="#">SEX20200-BBEAAA703I01505000T02</a>	Rotary Paddle Level Switch
<a href="#">SE3825DCRI5000</a>	Rotary Paddle Level Switch
<a href="#">SB2200</a>	Level Transmitter
<a href="#">SB17110ACU0500</a>	RF Capacitance Admittance Level Switch
<a href="#">SC2110R6DQ0500</a>	Vibrating level switch
<a href="#">FDMH56CBQ (SUS316L)</a>	Mini Float Level Switch
<a href="#">FACC10</a>	Flow Switch
<a href="#">FDMH50CBQ (SUS304)</a>	Horizontal Mini Float Level Switch
<a href="#">SE814ECRF3000</a>	Level Switch
<a href="#">SA110A</a>	Capacitance Level Switch
<a href="#">PT-7620-S101-00</a>	Temperature Controller
<a href="#">SE3810ECRH5000</a>	Rotary Paddle Level Switch with LED
<a href="#">FD7NDRAS140500A</a>	Float Level Switch
<a href="#">FCH21PDD05X</a>	Mini Float Level Switch
<a href="#">SP200-0-BR-P-2</a>	Flow sensor SP200 (= SP150)
<a href="#">BVK-16</a>	pneumatic vibrator
<a href="#">SE110EDTF</a>	Rotary Paddle level switch
<a href="#">SE3810DCRG3000</a>	Rotary Paddle Level Switch.



<b>Product</b>	<b>Description</b>
<a href="#">SD204ARP1+KC</a>	Optical Level Sensor
<a href="#">SEX20000-AABAAA703I00710300 / SE3800BCRI</a>	Rotary Paddle Level Switch
<a href="#">SE3820BCRG -SEX20000-CABAAA703G00710300</a>	Rotary Paddle Level Switch
<a href="#">PB-1470-T014020</a>	Microprocessor Bargraph Display Panel Meter
<a href="#">SE130A</a>	Rotary paddle
<a href="#">SE3810CCRG3000</a>	Rotary Paddle Level Switch
<a href="#">FDMH60-BU05X</a>	Float switch
<a href="#">Model # SE290BCRF</a>	SE29 Rotary paddle level switch
<a href="#">SE130A (L=450-650mm)</a>	Rotating bezel detector
<a href="#">SE3820BCRG3000</a>	Rotary Paddle Level Switch
<a href="#">SC2110R6DU0500(275)</a>	Vibrating level switch
<a href="#">SE3810ECRH3000 / SEX20000-BAEAAA703H00713000</a>	Rotary Paddle Level Switch
<a href="#">BVP-30C=VP-30C=AC1030C</a>	vibrator
<a href="#">SEB-1191</a>	Rotary Paddle Level Switch
<a href="#">SE110EDUA</a>	Rotary Paddle Level Switch
<a href="#">SE3800EERF S/N: EB1-18070068</a>	Rotary Paddle Level Switch
<a href="#">SP202-0-BR-A-0</a>	Thermal Dispersion Flow Switch
<a href="#">SE110ADRE (50x30mm (WxH))</a>	ROTARY PADDLE LEVEL SWITCH
<a href="#">SE110ADRE (132x100mm(WxH))</a>	ROTARY PADDLE LEVEL SWITCH
<a href="#">FD3001DE</a>	Mini Float Level Switch
<a href="#">SE3810CCRG2000</a>	Rotary paddle level switch
<a href="#">SP200-0-BU-P-2</a>	Compact model
<a href="#">SP202-0-2R-A-0-0050+TA</a>	Hi temp and extension model
<a href="#">SE111B</a>	Blade rotor level sensor
<a href="#">SC24160-DDR</a>	Vibrating Fork Level Switch
<a href="#">SE3810ECRH3000+TA</a>	Rotary paddle level switch
<a href="#">SC1400R0DU / SCX10000-AABCACA807MA000105</a>	Tuning Fork Level Switch
<a href="#">BVP-40C</a>	Pneumatic Piston Vibrator
<a href="#">SE110AEUA</a>	Rotary Paddle Level Switch
<a href="#">FF90CLO</a>	Side Mounting Float Switch
<a href="#">SE3810ACRG3000</a>	Rotary Paddle Level Switch with LED
<a href="#">SE3810ECRG3000</a>	Rotary Paddle Level Switch
<a href="#">SE3820BERI</a>	Rotary Paddle Level Switch
<a href="#">SE110EDUF</a>	Rotary Paddle Level Switch
<a href="#">PB-1471-T016000</a>	Bargraph Panel Meter
<a href="#">FDMH60-BU</a>	Mini Float Level Switch
<a href="#">SE3800BCRH</a>	Rotary Paddle Level Switch
<a href="#">FCH51PPD</a>	Mini Float Level Switch
<a href="#">FDMH56-BU / FDM10000-05MCCA507291003</a>	Mini Float Level Switch
<a href="#">SC24160T-DDQ+TA</a>	Tuning fork level switch
<a href="#">EFB-1300</a>	Magnetic Switch
<a href="#">SE110EDRA0100</a>	Rotary paddle level switch
<a href="#">SE3800DCRH5000</a>	Rotary Paddle Level Switch
<a href="#">EFB-1420S</a>	Magnetic Switch



Product	Description
<a href="#">FAPW-03</a>	Cable Float Level Switch
<a href="#">FFX10000-A1HACB107CMA0290</a>	Side Mounting Float Switch
<a href="#">SE3820BCRI</a>	Rotary Paddle Level Switch
<a href="#">SP202-0-2U-A-2-0050+TA</a>	THERMAL DISPERSION
<a href="#">SF1710</a>	Pallet Flow Controller
<a href="#">SE3800EERF</a>	Rotary Paddle Level Switch
<a href="#">BAH-30</a>	Air Hammer
<a href="#">FDBEM3S210500</a>	Magnetic Float Level Switch
<a href="#">SF1800</a>	Paddle Flow Switch
<a href="#">FDM30000-75MBVGC231050</a>	switch
<a href="#">SD204ARP1</a>	Optical Level Switch/Sensor
<a href="#">FF10DFQ</a>	Side Mounting Float Level Switch
<a href="#">FG CN 40</a>	LIQUID LEVEL TRANSMITTER
<a href="#">SE3820ECRG</a>	Magnetic Switch
<a href="#">SE3815DCRI0150/5000</a>	Rotary Paddle Level Switch
<a href="#">SP201-0-BU-A-2-0050</a>	Thermal Dispersion Flow Switch
<a href="#">SAX10000-00AEAAA801RMA330150</a>	Capacitive probe
<a href="#">SE3810ECRH3000S</a>	Rotary Paddle Level Switch
<a href="#">SE3810CCRG5000+TA</a>	Rotary Paddle Level Switch with LED
<a href="#">FF96CLO1</a>	Side Mounting Level Switch
<a href="#">SEX20000-AACAAA703100710300</a>	rotary paddle level switch
<a href="#">SC1410R0DV0500</a>	tuning fork level switch
<a href="#">SP202-0-BT-A-5</a>	Thermal Dispersion Flow Switch
<a href="#">SE110EDRS+TA</a>	rotary paddle level switch
<a href="#">FF90GLO</a>	Side Mounting Float Switch
<a href="#">SPX10200-BACA207MAC0050T02</a>	Thermal Dispersion Flow Switch
<a href="#">FDM10000-06MCBA501000000</a>	mini float level switch
<a href="#">SE141BGMB0300</a>	rotary paddle level switch
<a href="#">P/N: SE3800DCRG1000 Type: SEX20000-AADAAA703G00711000</a>	Compact Rotary Paddle Level Switch
<a href="#">SA190B0DUK / SAX20000-AAACA807A190163</a>	Capacitance Level Switch
<a href="#">SA371DDQ0500</a>	capacitance level switch
<a href="#">EFX10000-B7CAKA742A501A501MB0360M4A</a>	By-Pass Level Indicator
<a href="#">FDMH60-BQ</a>	Mini Float Level Switch
<a href="#">SE120EDRF1000</a>	Rotary Paddle Level Switch
<a href="#">SC2100R0DQ</a>	Vibrating Fork Level Switch
<a href="#">SAX10200-BEACA807RMA130500</a>	Capacitance Level Switch
<a href="#">SAX10200-BEACA807RMA130300</a>	Capacity Level Switch
<a href="#">FG7DNEVBS31000L</a>	Magnetic Float Level Transmitter
<a href="#">EFXCM1P-18S4420001</a>	sensor
<a href="#">EPR13EDA00APPC / EPR10000-040B23AD0018AA</a>	flowmeter
<a href="#">EPR13FDA00APPC</a>	flowmeter
<a href="#">SEX20000-AAEAAB103S00710300T01</a>	Rotary Paddle Level Switch
<a href="#">SE110EDRS-105-SAT</a>	Paddle Level Switch
<a href="#">p/n: BVP10000-0140 type: BVP-40S</a>	pneumatic piston vibrator
<a href="#">p/n: BVP10000-0130 type: BVP-30S</a>	pneumatic piston vibrator



Product	Description
<a href="#">FCV51PDBS</a>	Mini Float Level Switch
<a href="#">p/n: SP220-0-BR-A-2 type: SPX10100-AAAA503MAC0031</a>	Thermal Dispersion Flow Switch
<a href="#">p/n: PC312-2101421001 type: 26-0504-10M</a>	cable
<a href="#">PM-1430-T010000 / PMX11400-E2BA100AAAA</a>	Microprocessor Digit Display Panel Meter
<a href="#">SEX20000-AAEAAA703G00711000</a>	Rotary Paddle Level Switch
<a href="#">FG7BNES4S30500</a>	Magnetic Float Level Transmitter
<a href="#">FCH31PDD / FCM10000-H3180DD290003</a>	Mini Float Level Switch
<a href="#">FDX10000-AEACB2071FMAS11B0580UN / FDEFU1S111000C (580)</a>	Magnetic Float Level Switch
<a href="#">EFB-1350+TA</a>	EFX Magnetic Switch
<a href="#">EPD10000-A100A42MA37MCAAFMA00</a>	EPD Electromagnetic Flow Meter
<a href="#">Type: SE110EDRS, Order code: SEX50000-AAEAAA803A0100</a>	Rotary Paddle Level Switch
<a href="#">SEX50000-AAEAAA803B0100</a>	Rotary Paddle Level Switch
<a href="#">SPX10100-AAAA503MAC0031</a>	Thermal Dispersion Flow Switch
<a href="#">SPX10100-AAAA503MAB0031</a>	Thermal Dispersion Flow Switch
<a href="#">EPD10000-A150D58MD21MCAAFMA00</a>	EPD Electromagnetic Flow Meter
<a href="#">SB2286BEU0580 / SBX10800-CBACB107MB320580</a>	Capacitance_Admittance Level Switch
<a href="#">SE3820DCRG1000 // SEX20000-CADAAA703G00711000</a>	Rotary Paddle Level Switch
<a href="#">SEX50000-AABABA805B0100</a>	Rotary Paddle Level Switch
<a href="#">SE110BERA0500 / SEX50000-AABAAB103B0100</a>	Rotary Paddle Level Switch
<a href="#">SPX10000-AAAA503MAC0031</a>	Thermal Dispersion Flow Switch
<a href="#">SE3802DCRGS3000</a>	Rotary Paddle Level Switch
<a href="#">FF70CEM / FFX1001C-A1MANB148CMA0000</a>	Side Mounting Float Switch
<a href="#">FF70CEU / FFX1001C-A1MACB107CMA0000</a>	Side Mounting Float Switch
<a href="#">SE3800ECRH3000 / SEX20000-AAEAAA703H00713000</a>	rotary paddle level switch
<a href="#">FF10CEM / FFX10000-A1HAKB140CMA0000</a>	Side Mounting Float Switch
<a href="#">SC28100-DCR</a>	Tuning Fork Level Switch
<a href="#">Model: SE110B / SEX50000-AABAAA803B0100</a>	rotary paddle level switch
<a href="#">SE141BERS0500+TA</a>	Rotary Paddle Level Switch
<a href="#">FCM100 00-V 2 181 D D 230 002</a>	FineTek Mini Float Level Switch
<a href="#">FCM100 00-V 2 181 D E 230 002</a>	FineTek Mini Float Level Switch
<a href="#">EG6022BQS4-00A0AE10</a>	EGX Magnetostrictive Level Transmitter
<a href="#">code SEX20000-CADAAA703G00713000 / type SE3820DCRG3000</a>	Rotary Paddle Level Switch
<a href="#">SE3800ECTI</a>	level sensor
<a href="#">FDE3MAS11300C (250) / FDX10000-AEAKA9401FMBS11A0250UN</a>	Magnetic Float Level Switch
<a href="#">FDM10000-05MCBA507000000</a>	Mini Float Level Switch
<a href="#">FC H41PDD</a>	float level indicator
<a href="#">FC V11QDA</a>	float level indicator
<a href="#">FC H21PDD03P</a>	float level indicator
<a href="#">SC24P00-DDR</a>	tuning fork level switch
<a href="#">PB-1471-S014000</a>	Microprocessor Bargraph Display Panel Meter
<a href="#">BVK10000-10</a>	Pneumatic Ball Vibrator
<a href="#">Order Code# SEX20000-CADAAA703G00713000, Model: SE3820DCRG3000</a>	Rotary Paddle Level Switch
<a href="#">EC1510-0X6G-BR-D-5</a>	Pressure Level Transmitter



Product	Description
<a href="#">SE3800ECRF</a>	Rotary Paddle Level Switch
<a href="#">FF10CGM</a>	Side Mounting Float Switch IP65
<a href="#">FF10CLO.SA</a>	Side Mounting Float Switch
<a href="#">SE110EDRA0095</a>	Rotary Paddle Level Switch
<a href="#">SE110BDTF</a>	Rotary Paddle Level Switch
<a href="#">FDX1001C-ANASE1571GMBS21B0120UN</a>	SWITCH,LEVEL
<a href="#">FFX10200-A4HASE357DMA0250</a>	SWITCH
<a href="#">FCV21QDA</a>	Mini Float Level Switch
<a href="#">SFX10000-A1EAAA801MBX</a>	Paddle Type Flow Switch
<a href="#">FF10CEQ</a>	Side Mounting Float Switch
<a href="#">SEX20000-BAAAAA803G00783000T01</a>	Rotary paddle level switch
<a href="#">SFX10000-A1EAAA801MAX</a>	Paddle Type Flow Switch
<a href="#">SP210-0-BU-C-2</a>	Flow switch
<a href="#">PC312-2101422M01 2m</a>	M12 Cable connector
<a href="#">PC312-2101425M01 5m</a>	Cable
<a href="#">PC312-2101425M01 10m</a>	Cabel
<a href="#">SE3800CCRI</a>	Rotary Paddle Level Switch
<a href="#">SP202-0-BT-A-5-0050</a>	Thermal Dispersion Flow Switch
<a href="#">FF62DFM</a>	Side Mounting Float Switch
<a href="#">SE3810ECRH3000+TB / EB1-22010486</a>	Rotary Paddle Level Switch
<a href="#">Type : FF10HLOS-6, Code: FFX10000-A1HAZ0000FMB0180</a>	Sensor
<a href="#">ECX10000-EAAA503MA00000X6000 (EC1510-0X6G-BR-D-5)</a>	Pressure Level Transmitter
<a href="#">EPD10000-A100A42MA21MCAAFMA00</a>	EPD Electromagnetic Flow Meter
<a href="#">SE3800EERF / SEX20000-AAEAAAB103S00710300T01</a>	Rotary Paddle Level Switch
<a href="#">SC2100R6DQ</a>	Tuning Fork Level Switch
<a href="#">SE290B CRI</a>	Rotary Paddle Level Switch
<a href="#">SE110B / SEX50000-AABAAA803B0100</a>	Rotary Paddle Level Switch
<a href="#">EFB-1430</a>	Spare Parts Magnetic Switch
<a href="#">SA120BDT0250</a>	Capacitive level switch
<a href="#">SEX50000-ACEBCB439H1000</a>	Rotary Paddle Level Switch
<a href="#">SEX50000-ABEAAB103H0250</a>	Rotary Paddle Level Switch
<a href="#">EFB-1400-1 / EFXAM1P-18S4420002</a>	Magnetic Switch
<a href="#">SE3810CCRH3000S</a>	Rotary Paddle Level Switch
<a href="#">RP80-SEB-1191</a>	Rotary Paddle Level Switch
<a href="#">SE3810ACRG5000</a>	Rotary Paddle Level Switch
<a href="#">FFX10000-A1HAAB101CMA0000</a>	Side Mounting Float Switch
<a href="#">FDMH50-SS03TH+TC</a>	mini float level switch
<a href="#">BAH10000-30A</a>	Air Hammer
<a href="#">BVP10000-0060</a>	Pneumatic Vibrator
<a href="#">SEX20000-BAEAAA703A00713000T02</a>	Rotary Paddle Level Switch
<a href="#">SE110EERF0300</a>	Rotary Paddle Level Switch
<a href="#">Order code: SAX10000-BDAAA801RMA330250</a>	Capacitance Level sensor
<a href="#">SEX2007D-AADAAA703G00711000</a>	Rotary Paddle Level Switch
<a href="#">SEX20000-AAEAAA703G00713000</a>	Rotary Paddle Level Switch
<a href="#">SE110EDTF 1 1/2</a>	Rotary Paddle Level Switch



Product	Description
<a href="#">FCV11QFD</a>	Mini Float Level Switch
<a href="#">SC1741R0EU0300</a>	Tuning Fork Level Switch
<a href="#">EBX10200-B1AKB24214A1638</a>	Transmitter, Level RF-Admittance
<a href="#">SE3810ACRG3000 - SEX20000-BAAAAA703G00713000</a>	Rotary Paddle Level Switch with LED
<a href="#">SAX10000-AEAAA801RMA330150</a>	Capacitance Level Switch
<a href="#">SEX50000-ACEBCB439B1000</a>	Rotary Paddle Level Switch
<a href="#">SEX50000-ACEBCB439B0630</a>	Rotary Paddle Level Switch
<a href="#">SEX50000-ACEBCB439B1200</a>	Rotary Paddle Level Switch
<a href="#">EFXBM1P-18S4420001</a>	Magnetic Switch
<a href="#">SE120EFTS0250</a>	Level gauge with paddle
<a href="#">FDMH56CBU</a>	Mini Float Level Switch
<a href="#">RF-MH56ABT</a>	RF Admittance Level Switch
<a href="#">PC312-2101421501 15m</a>	M12 Connector Cable
<a href="#">SE120EFTA0500</a>	Rotary Paddle Level Switch
<a href="#">FACC-10M</a>	Flow Switch
<a href="#">PM-1430-S014000</a>	Panel Meter
<a href="#">SE110EETF</a>	Rotary Paddle Level Switch
<a href="#">SE111BGMA0100</a>	Rotary Paddle Level Switch
<a href="#">EF311B1H1I3-05T</a>	By-Pass Level Transmitter
<a href="#">SE140A3UF</a>	Rotary paddle level switch
<a href="#">SE110EDR (Order Code# SEX50000-AAEAAA803A0100)</a>	Rotary Paddle Level Switch
<a href="#">FCH51PDD</a>	Mini Float Level Switch
<a href="#">BVP10000-0040</a>	pneumatic roller vibrator
<a href="#">SE110B</a>	Rotary Paddle Level Switch
<a href="#">SA150BER1000</a>	Capacitance Level Switch
<a href="#">SE130AGMA1000</a>	Rotary Paddle Level Switch
<a href="#">SE110BDRF0195</a>	Motorized sensor
<a href="#">SEX50000-AAEACA807G0100</a>	Rotary Paddle Level Switch
<a href="#">SE381OECRH3000</a>	Rotary Paddle Level Switch
<a href="#">FDBDUAS110300C-2+TA</a>	Level Switch
<a href="#">SEX50000-AABAAA803G0195T01</a>	Rotary Paddle Level Switch
<a href="#">EFB-1420S / EFXBM1P-18S4130001</a>	Magnetic Switch
<a href="#">SE3800ECRG</a>	Rotary paddle level switch
<a href="#">SP200-0-BR-P-0</a>	Thermal Dispersion Flow Switch
<a href="#">FCM 100 00 V 5 180 D 210</a>	Flow Meter
<a href="#">SAX20000-AAACA807A190163 / SA190B0DUK</a>	FineTek Capacitance Level Switch
<a href="#">SAX10200-BDAAA801RMA130388</a>	Capacitance Level Switch
<a href="#">FDMH50CBU</a>	Mini Float Level Switch
<a href="#">FDMH56CBS / FDM10000-05MCBA591000000T01</a>	Mini Float Level Switch
<a href="#">SEX40000-CABAAA703I0300</a>	Sensor
<a href="#">EB1-21110149 ( SE3810CCRG3000+TA)</a>	Rotary Paddle Level Switch
<a href="#">EB1-22120371</a>	
<a href="#">Model: EFB-1230</a>	
<a href="#">EF311A2H1B1-10</a>	
<a href="#">FF10CEU</a>	switch



Product	Description
<a href="#">SE3820ACRI</a>	
<a href="#">SE141BGMB0500</a>	
<a href="#">SUS304 / SCX1001C-CABCACA807MA340250</a>	Fork level switch
<a href="#">SC1741</a>	Fork level switch
<a href="#">FF10CEM0260SA</a>	Low level float
<a href="#">FCM10000-V5180DB210020</a>	
<a href="#">FCV31PDD</a>	
<a href="#">FGCG40 / FGX10000-A6G000000CMA2B0000B001600</a>	
<a href="#">SE110EDRF / SEX50000-AAEAAA803G0100</a>	
<a href="#">SEXBM2S-1102020002 / SEB-1193</a>	
<a href="#">SE3810ECRH000S</a>	level switch
<a href="#">EFM20000-B1CASD857A201A201MA1200N1A</a>	
<a href="#">BAH10000-80A / BAH-80</a>	
<a href="#">SEX20200-BAEAAA703I00863000T01 / SE3814ECRI3000+TA</a>	level sensor
<a href="#">FD7NSSBS210120CL6+TA</a>	
<a href="#">SEX50000-ABAANB948B0500</a>	
<a href="#">SEX40000-CAAAA703G1000 Rotary paddle level switch</a>	Paddle
<a href="#">SEX20000-CADAAA703G00710300 / SE3820DCRG</a>	
<a href="#">FAX10100-DBCM35000</a>	
<a href="#">SE3822BCQIS / SEX20000-CBBAAA701I01500300</a>	Paddle Sensor
<a href="#">SCX60000-BAADAAA801MA000210</a>	
<a href="#">SCX60000-AAADAAA801MA000160</a>	
<a href="#">SEX50000-AAEAAA803G0100 / SE110EDRF</a>	Rotary paddle level switch
<a href="#">FF73CLO</a>	
<a href="#">SE3810ACQH3000</a>	
<a href="#">SEX20000-BAEAAA703H00713000/SE3810ECRH3000</a>	rotary paddle switch
<a href="#">SE3810ECRH3000</a>	Rotary paddle limit switch
<a href="#">FDMH50ABU20</a>	level switches
<a href="#">SE3810ECR-3000+TA</a>	Rotary vane level switch
<a href="#">EGX60200-A1AAA5012DMCS500AA0AAYC0800</a>	high-temperature version (top line)
<a href="#">FDMH 66CBT</a>	contactor
<a href="#">EFB-1220</a>	By-Pass Level Transmitter
<a href="#">SEX50000-AAEAAA803A0100</a>	PADDLE LEVEL SWITCH
<a href="#">SA110BDQ0500</a>	
<a href="#">SA110BDQ1000</a>	
<a href="#">BVP-30C</a>	pneumatic piston vibrator
<a href="#">PB-1471-S014020</a>	
<a href="#">FAX10100-BDCP15000</a>	
<a href="#">SCX50001-AAFAAAA701MA00B0076</a>	
<a href="#">SEX20200-BBDA703I01503000 / SE3815DCRI0150/3000</a>	Rotary Paddle Level Switch
<a href="#">SPX20200-EAAA503MAB0031</a>	high-temperature version
<a href="#">SEX50000-AACAAB403B0100</a>	
<a href="#">FF10CLO</a>	
<a href="#">FFX10000-A5HANB248DMA0320</a>	
<a href="#">FGX10000-A1BAIB500CMA2BS300B000985T01</a>	



Product	Description
<a href="#">SDX50000-AAASI7MAAPAA2000</a>	
<a href="#">SA110BDQ0150</a>	LEVEL FLUID
<a href="#">SCX10000-AABCAAA801MA000105</a>	Tuning fork level switch
<a href="#">SC1741RLDU1000</a>	
<a href="#">SE3800ECRH5000</a>	sensor
<a href="#">FF1OCEQ</a>	Sensor
<a href="#">FACC05-X / FAXAM1F-1809011003</a>	Swim switch with cable
<a href="#">SE3814ECRK5000S</a>	Level sensor
<a href="#">SE110CGRA</a>	Rotary paddle level switch