



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)



# Uni-Oeler

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

## BRAND'S PRODUCTS

Product	Description
<a href="#">SBK 50.1 R 1/8 Uni-Oeler</a>	Set screw einstellbarSchmierbüchseStat.Waren No 84248900Ursprungsland. EU / DEGewicht: 0.271 kg
<a href="#">0109 1104 0240 0 , type ELO 1000 G 1/2</a>	Acrylglas
<a href="#">0207 11 0240 04 0</a>	Mehrfach-Elektro-Tropföler
<a href="#">0411 11 0240 0</a>	LUBRICATION SYSTEM - 1 POINT
<a href="#">0111 1104 2305 0</a>	LUBRICADOR
<a href="#">KPO 200</a>	Kompressionsöler
<a href="#">0111 1104 0240 0</a>	UNI electric drip oil
<a href="#">ELO 1000 G 1/2 Acryl NBR</a>	electric drip oiler
<a href="#">SPR 30 G 1/8 Edelstahl</a>	Öl- und Schmierpinsel
<a href="#">90 12 09 18</a>	
<a href="#">0805 2102 0</a>	Oil Reservoir
<a href="#">K8471</a>	greaser
<a href="#">90 08 12 ÖL</a>	tank cap
<a href="#">0309 11 2305 02 0</a>	
<a href="#">0309 11 1206 04 0</a>	
<a href="#">MET.H 1000.1</a>	UNI multiple electric drip oiler
<a href="#">MV24/DC/8 MS</a>	H-Magnetventil 24V DC 8 W
<a href="#">MV24/50/8 MS</a>	H-Magnetventil 24V 50Hz 8W
<a href="#">P/N: 0107 1104 0240 0 Type: ELO 500</a>	Electric Drip Feed Oiler
<a href="#">MET.H 1000.6 Acrylglas, NBR</a>	
<a href="#">NBR seals for MET.H 1000.2</a>	seal kit for MET.H1000.2
<a href="#">ELO 500 G 1/2 Acrylglas, NBR (0107 1104 0240 0)</a>	UNI electric drip oiler
<a href="#">ELO 3000 G 1/2 Acrylglas, NBR</a>	
<a href="#">ELO40-G1/8 // 0103 1101 0240 0</a>	UNI Electric - Dropper
<a href="#">EOS.B 2000 / 0410 11 0240 0</a>	
<a href="#">OMS 60 G 3/8</a>	Oil reservoir with expansion pipe
<a href="#">OBH3000</a>	
<a href="#">0107 1104 0240 0</a>	UNI electric drip lubricant
<a href="#">MET.H 3000.2 / 0311 11 0240 02 0</a>	UNI multiple electric drip oiler
<a href="#">90 08 009 02</a>	container glass
<a href="#">0110 1104 0240 1 , type ELO 2000 G 1/2 Acryl, NBR, SMM</a>	UNI Elektro-Tropföler
<a href="#">MET.H 3000.4 (Art.Nr.0311 11 0240 04 0)</a>	
<a href="#">UNI 40 G 1/8</a>	
<a href="#">UNI-V 50 G 1/4</a>	



Product	Description
<a href="#">MET.B 1000.4</a>	Acrylic glass, NBR,UNI multiple electric drop oiler for 4 lubrication points
<a href="#">ELO 1000</a>	
<a href="#">MET.H 1000.3</a>	UNI-Mehrfach-Elektro-Tropföler
<a href="#">TOL 50 G 1/4 Acrylglas, NBR</a>	oiler
<a href="#">0307 11 2305 02 0</a>	
<a href="#">0307 11 2306 02 0</a>	
<a href="#">P/N: 47 0160 11 04 Type: OAD-S MS PA</a>	Hose oil level indicator with protective tube
<a href="#">P/N: 47 0160 01 04 Type: OAD-S PA</a>	Hose oil level indicator without protective tube
<a href="#">0509 21 0240 0 Type EOS.H 1000</a>	
<a href="#">0312 31 0240 04 0 Type MET.H 5000.4</a>	oiling system
<a href="#">ELO 1000 G 1/2 Acrylglas</a>	21/5000 UNI Electric Drip Oiler
<a href="#">SBK 50.0</a>	spring-pressure lubricant
<a href="#">SBK 50.2 G 1/8</a>	Spring-loaded grease gun
<a href="#">SKS 50 (90 30 01 21 50 BS)</a>	Nozzle head SKS 50 for band saws
<a href="#">SKS 50 ( 90 30 01 21 50 KS)</a>	Nozzle head SKS 50 for circular saw
<a href="#">MOS 1000 UNI (0909 11 0)</a>	oil dispenser manually
<a href="#">MET.H 500.4</a>	
<a href="#">MET.B 500.2</a>	
<a href="#">MET.H 2000.1 /24V DC 8W</a>	
<a href="#">MET.H 2000.1 /230V 50Hz 8W</a>	
<a href="#">ELO 140 G 1/4 Acrylglas, NBR</a>	
<a href="#">ELO 140 G 3/8 Acrylglas, NBR</a>	
<a href="#">ELO 140 G 1/2 Acrylic glass, NBR / 0105 1104 2205 0</a>	
<a href="#">MET.H 200.2</a>	UNI multiple electric oiler
<a href="#">MET.B 3000.4</a>	UNI multiple electric dripper
<a href="#">12 11 04 B</a>	
<a href="#">12 11 04</a>	MTR 4 Mehrfach Öltropfer
<a href="#">90 30 001 03 00</a>	O-Ring
<a href="#">90 30 001 04 00</a>	Baffle plate
<a href="#">90 30 001 05 00</a>	Hydraulic rifle
<a href="#">90 30 001 07 00</a>	Grooved ring
<a href="#">90 30 001 06 00</a>	Compression spring
<a href="#">90 30 001 08 00</a>	Piston
<a href="#">90 30 001 09 01</a>	Regulating insert compl. for microdosing pump
<a href="#">40 25 28 21</a>	Sealing rings / Fiber
<a href="#">90 30 001 16 00</a>	Screw-in throttle / Spray Air Throttle
<a href="#">90 30 001 01 00</a>	Push-in fitting
<a href="#">40 25 28 31</a>	Sealing rings / fiber
<a href="#">90 30 001 15 00</a>	O-Ring 24 x 2
<a href="#">90 30 001 11 00</a>	O-Ring 10 x 1
<a href="#">90 30 001 14 00</a>	Adjusting Head
<a href="#">90 30 001 00 00</a>	Micro Dosing Pump
<a href="#">90 30 001 09 02</a>	Regulating insert without adjusting head
<a href="#">2501 1102</a>	



Product	Description
<a href="#">40 25 10 57</a>	
<a href="#">40 25 02 57</a>	
<a href="#">40 25 05 54</a>	
<a href="#">RSM-B 80/30 Perlon (15 830 11 00)</a>	UNI roller lubrication
<a href="#">EOS.B 1000</a>	UNI electric oil dispenser
<a href="#">OBH 2000</a>	Oil tank
<a href="#">MS24/DC/12</a>	solenoid
<a href="#">MS24/50/12</a>	coil 24V AC for type ELO2000
<a href="#">MOS 2000</a>	oil dispenser
<a href="#">0110 1104 0240 0, ELO 2000 G 1/2 Acryl, NBR 24V DC 12VA</a>	UNI electric drip lubricant
<a href="#">0110 1104 0245 0, ELO 2000 G 1/2 Acrylglas, NBR 24V 50Hz 12VA</a>	UNI Electric Drip Oiler
<a href="#">UNI 150x180 (G 1/2 Acrylglas, NBR)</a>	
<a href="#">07 200 00 00</a>	Electric Pump
<a href="#">06 8500 UN</a>	UNI Control Time
<a href="#">UNI 60 G1/4</a>	UNI 60 drip oiler manual
<a href="#">0405 11 0240 0</a>	oil dispenser
<a href="#">P/N:0107 1104 2305 0; Type:ELO 500</a>	Electric Drip Feed Oiler
<a href="#">Container glass 150 x 180 Acryl (Art.Nr.90 08 011 01)</a>	Container glass
<a href="#">OBH 3000 Art.Nr.90 08 011 25</a>	OBH 3000 Spare Part Holder Ear
<a href="#">90 30 001 25 00</a>	Micro dosing pump spare part
<a href="#">1806 1104</a>	
<a href="#">EOS.B 140</a>	
<a href="#">90 08 009 01</a>	container glass
<a href="#">MOS 500</a>	
<a href="#">0106 1104 0240 0</a>	
<a href="#">0106 2104 0240 0</a>	
<a href="#">0109 2104 0240 1</a>	
<a href="#">0209 11 0240 02 0</a>	
<a href="#">0211 11 0240 02 0</a>	
<a href="#">ELO 2000 G 1/2</a>	UNI Electric Tropics
<a href="#">0211 21 0240 02 0</a>	
<a href="#">0211 11 2305 02 0</a>	
<a href="#">0211 21 2305 02 0</a>	
<a href="#">0209 21 0240 02 0</a>	
<a href="#">0209 11 2305 02 0</a>	
<a href="#">0209 21 2305 02 0</a>	
<a href="#">0105 1104 0240 0 Type ELO 140</a>	
<a href="#">OMS 40 G 1/4</a>	Oil reservoir with expansion pipe
<a href="#">OMS 60 G 1/4</a>	Oil reservoir with expansion pipe
<a href="#">0109 2104 0240 2</a>	
<a href="#">0105 2104 0240 0</a>	UNI Electric Tropics
<a href="#">12 11 01 Type MTR 1</a>	



Product	Description
<a href="#">12 11 02 Type MTR 2</a>	Multiple oil dropper
<a href="#">12 11 03 Type MTR 3</a>	
<a href="#">12 11 04 Type MTR 4</a>	
<a href="#">12 11 05 TypeMTR 5</a>	
<a href="#">12 11 06 Type MTR 6</a>	
<a href="#">12 11 07 Type MTR 7</a>	
<a href="#">12 11 08 Type MTR 8</a>	
<a href="#">12 11 09 Type MTR 9</a>	
<a href="#">12 11 10 Type MTR 10</a>	
<a href="#">ELO 1000 G 1/2</a>	
<a href="#">40 30 00 15</a>	Flat Quick Sitting
<a href="#">40 29 55 31</a>	PA Hose
<a href="#">40 31 04 13</a>	Just up. Pipe connection
<a href="#">16 106 12 00</a>	brush holder
<a href="#">0105 1104 0240 0</a>	
<a href="#">MS24/DC/12 MS</a>	solenoid
<a href="#">0109 1104 0240 0</a>	UNI electric drip oiler
<a href="#">13 001 11 01</a>	
<a href="#">13 002 11 01</a>	
<a href="#">13 003 11 01</a>	
<a href="#">13 004 11 01</a>	Oil and Lubrication Brush
<a href="#">14 001 11 01</a>	
<a href="#">14 002 11 01</a>	
<a href="#">14 003 11 01</a>	
<a href="#">0109 1104 0245 0</a>	UNI electric drip lubricant
<a href="#">14 003 12 01</a>	
<a href="#">14 002 12 01</a>	
<a href="#">14 001 12 01</a>	
<a href="#">13 004 12 01</a>	
<a href="#">13 003 12 01</a>	
<a href="#">13 002 12 01</a>	
<a href="#">13 001 12 01</a>	
<a href="#">N2064 / 0211 11 0240 02 0</a>	
<a href="#">P/N:0709 11 0245 01 1, Type: EPO 1000 Acryl, NBR, SMM</a>	electric oil pump with oil reservoir
<a href="#">P/N: 0709 11 2305 01 1, Type: EPO 1000 Acryl, NBR, SMM</a>	electric oil pump with oil reservoir
<a href="#">P/N: 0211 11 0240 02 0, Type: MET.B 3000.2</a>	Multiple electric drip lubricant
<a href="#">P/N:90 MWI 105 VA, Type: MWI 105</a>	mounting bracket
<a href="#">P/N: 40 IQSG 186 R KUN, Type: KUN</a>	Straight push-in fitting
<a href="#">0807 2203 0</a>	EXPANSION VESSEL
<a href="#">OBH 140 R 1/4</a>	UNI oil reservoir
<a href="#">2005 2103</a>	
<a href="#">1705 2103</a>	
<a href="#">2106 2103</a>	compression oiler



Product	Description
<a href="#">P/N: 0107 1104 0240 0 / ELO 500 G 1/2 Acrylglas, NBR</a>	UNI electric dripper
<a href="#">EET 200 - 230/50</a>	pump
<a href="#">SMM 50 MS/VA / 18 450 06 00</a>	float switch
<a href="#">1803 2102 U</a>	Manual drip oiler
<a href="#">MET.H 500.2</a>	
<a href="#">MET.H 1000.4 (0309 11 1206 04 0 )</a>	Acrylglas
<a href="#">KPO 500</a>	
<a href="#">MET.H2000.3 acrylic glass</a>	
<a href="#">MET.H 2000.3 natural glass</a>	
<a href="#">P/N: 1704 1101, Type: UNI 50</a>	drip oiler manual
<a href="#">P/N: 1705 1101, Type: UNI 60</a>	drip oiler manual
<a href="#">MTM 2000 / 1010 11 020</a>	acrylic
<a href="#">MOS 1000 UNI</a>	oil dispenser
<a href="#">MET.H 1000.4</a>	Bunker Automatic lubrication hopper
<a href="#">EOS.B 2000 Acrylglas</a>	UNI electric oil dispenser
<a href="#">EOS.B 2000 Naturglas</a>	UNI electric oil dispenser
<a href="#">UNI 60x80 (Acrylglas)</a>	
<a href="#">UNI 60 x 80 (Naturglas)</a>	
<a href="#">WOL 25 G 1/4</a>	
<a href="#">OBH 1000 R 1/4 (0809 2102 0)</a>	natural glass
<a href="#">ELO 500 G 1/2 Acrylglas (0107 1104 0240 0)</a>	UNI electric dropper
<a href="#">MOS 3000 Acrylglas, NBR (0911 11 0)</a>	Manual oil dispenser
<a href="#">Typ Microspray 3P/1T/1MV</a>	
<a href="#">RSM 80 Perlon</a>	UNI roller lubrication
<a href="#">RSM 80 stainless steel</a>	UNI roller lubrication
<a href="#">ELO 3000 G 1/2 / 0111 1104 0240 0</a>	
<a href="#">MET.H 500.1, SMM</a>	UNI multiple electric drip oiler
<a href="#">90 08 007 01</a>	container glass
<a href="#">2504 1102</a>	oil tank with compensation tube
<a href="#">2504 1103</a>	oil tank with compensation tube
<a href="#">0309 11 2305 04 0</a>	
<a href="#">EOS.B 3000 24V DC 14VA</a>	Electric Oil Dispenser
<a href="#">EOS.B 3000 230V 50Hz 14VA</a>	Electric Oil Dispenser
<a href="#">UST 40</a>	
<a href="#">0409 11 2305 0</a>	UNI electric oil dispenser
<a href="#">MET.H 2000.2</a>	Oiler
<a href="#">0811 1102 0</a>	
<a href="#">0811 2202 0</a>	
<a href="#">06 8500 UU</a>	UNI Control clock
<a href="#">0209 11 0245 01 0 / MET.B 1000.1</a>	
<a href="#">42 012 01 / SBK 50.1 G 1/8</a>	spring pressure lubricant
<a href="#">SBK 50.1 R 1/8</a>	spring-pressure lubricant
<a href="#">1702 1102</a>	
<a href="#">1702 2202</a>	



Product	Description
<a href="#">0107 1102 0240 0 / ELO 500 G 1/4</a>	acrylic glass, NBR
<a href="#">0804 1102 0</a>	
<a href="#">0804 2202 0</a>	
<a href="#">1706 1102</a>	
<a href="#">1706 2202</a>	
<a href="#">OBH1000 G1/2</a>	
<a href="#">0809 1104 0</a>	
<a href="#">07 200 00 01 / EET-200</a>	
<a href="#">0106 1102 0240 0</a>	
<a href="#">0106 1102 2305 0</a>	
<a href="#">1707 1104 / UNI 80 x 100</a>	Manual dripper
<a href="#">0309 11 0240 02 0</a>	
<a href="#">SPR16</a>	
<a href="#">SPR30</a>	
<a href="#">SPF57</a>	
<a href="#">SPF 57 stainless steel</a>	
<a href="#">SPR 30 stainless steel</a>	
<a href="#">SPR 16 Stainless steel</a>	
<a href="#">EOS.H 1000</a>	electric oil dispenser
<a href="#">0309 11 0240 06 0</a>	
<a href="#">MET.B 1000.2</a>	drip feed oiler
<a href="#">SPR 25</a>	lubricating brush
<a href="#">PHA 60</a>	brush holder
<a href="#">1709 1104</a>	drip feed oiler
<a href="#">1709 2204</a>	
<a href="#">0107 2204 0240 0</a>	
<a href="#">0107 2204 2305 0</a>	
<a href="#">UNI130X150 // 1710 1104</a>	Manual dripper
<a href="#">90 MS H 230/50/8</a>	
<a href="#">EET 200 - 110/60</a>	pump
<a href="#">UNI-V 80 G 1/2 / 1806 1104</a>	
<a href="#">UNIKUM 70 G 1/2 / 1805 2104 U</a>	
<a href="#">MET.B 1000.6 Acrylglas, NBR 24V DC</a>	
<a href="#">MET.B 1000.6 Naturglas, FKM 24V DC</a>	
<a href="#">0806 1102 0</a>	
<a href="#">ELO 200 G 1/2 Naturglas (0106 2204 0240 0)</a>	
<a href="#">MET.B 1000.8</a>	
<a href="#">MET.H 1000.2</a>	
<a href="#">MET.H3000.3</a>	
<a href="#">MET.B 1000.4 Acrylglas, NBR 24V DC</a>	
<a href="#">MET.B 1000.4 Acrylglas, NBR 230V</a>	
<a href="#">MET.B 1000.6 Acrylglas, NBR 230V</a>	
<a href="#">MET.B 1000.6 Naturglas, FKM 230V</a>	
<a href="#">MET.B 1000.4 Naturglas, FKM 24V DC</a>	
<a href="#">MET.B 1000.4 Naturglas, FKM 230V</a>	



Product	Description
<a href="#">0409 11 1105 0</a>	oil
<a href="#">0310 11 0240 02 0/ MET.H 2000</a>	
<a href="#">0310 11 2305 02 0/ MET.H 2000</a>	
<a href="#">2005 1102 / TOL 60 G 1/4 acrylic glass, NBR</a>	DRIP OILER
<a href="#">MS24/DC/14 MS</a>	magnetic coil
<a href="#">MS230/50/14 MS</a>	magnetic coil
<a href="#">2005 2102 / TOL 60 G 1/4 natural glass, NBR</a>	DRIP OILER
<a href="#">0107 1104 0245 0</a>	
<a href="#">0510 11 0240 0 / EOS.H 2000</a>	
<a href="#">90 08 010 01</a>	
<a href="#">0306 11 0240 02 0</a>	
<a href="#">0509 11 0240 0 / EOS.H 1000</a>	
<a href="#">1009 11 080/ MTM 1000</a>	
<a href="#">44 080 22 02 E ES/OAS-ES 80</a>	
<a href="#">44 080 22 02 D ES/OAS.ES 80</a>	
<a href="#">0105 1104 0240 0/ELO 140 G</a>	
<a href="#">ELO 140 G 1/2 Naturglas, FKM / 0105 2204 2205 0</a>	
<a href="#">0809 1102 0/OBH 1000</a>	
<a href="#">0311 11 1105 01 2</a>	
<a href="#">ACL 7577 G 1/4</a>	
<a href="#">OAA 1/2" NPT, FKM</a>	
<a href="#">ELO 140 24V DC 12VA</a>	LUBRICATION PUMP
<a href="#">OBH 30 G1/4 (NBR.)</a>	
<a href="#">ELO 140 230V 50Hz 12VA</a>	
<a href="#">OBH 30 G 1/4 (FKM.)</a>	
<a href="#">90 30 01 20 60 BS</a>	nozzle
<a href="#">1804 1102</a>	
<a href="#">1804 2202</a>	
<a href="#">1804 1104</a>	
<a href="#">1804 2204</a>	
<a href="#">1804 1103</a>	
<a href="#">1804 2203</a>	